

Lenovo IdeaPad S200/S206

Hardware Maintenance Manual

Note:

Before using this information and the product it supports, be sure to read the general information under "Notices" on page 78.

First Edition (February 2012) © Copyright Lenovo 2012. All rights reserved.

LENOVO products, data, computer software, and services have been developed exclusively at private expense and are sold to governmental entities as commercial items as defined by 48 C.F.R. 2.101 with limited and restricted rights to use, reproduction and disclosure.

LIMITED AND RESTRICTED RIGHTS NOTICE: If products, data, computer software, or services are delivered pursuant a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

© 2012 Lenovo

Contents

About this manual	.iv
Safety information	1
General safety	
Electrical safety	
Safety inspection guide	
Handling devices that are sensitive to	
electrostatic discharge	6
Grounding requirements	6
Safety notices: multilingual translations	7
Laser compliance statement	14
Important service information	
Strategy for replacing FRUs	16
Strategy for replacing a hard disk drive	17
Important notice for replacing a system	
board Important information about replacing RoHS	17 S
compliant FRUs	
General checkout	19
What to do first	
Power system checkout	21
Checking the AC adapter	
Checking operational charging	21
Checking the battery pack	22
Related service information	23
Restoring the factory contents by using	
Recovery Disc Set	23
Start Recovery Disc (one disc)	
Operating System Recovery Disc (one or	
more discs)	23
Applications and Drivers Recovery Disc	
(one or more discs)	23
Supplemental Recovery Disc	
Passwords	
Power-on password	24
Hard-disk password	24
Supervisor password	24
Power management	
Screen blank state	
Sleep (standby) state	
Hibernation state	
Lenovo IdeaPad S200/S206	
Specifications	
Status indicators	
Fn key combinations	
Hotkeys	31

FRU replacement notices	
Screw notices	
Removing and replacing an FRU	33
1010 Battery pack	34
1020 Dummy card	36
1030 Hard disk drive	37
1040 DIMM	39
1050 PCI Express Mini Card for wireless	5
LAN/WAN	40
1060 3G Card	42
1070 Keyboard	43
1080 System board	45
1090 LCD unit	48
1100 Fan assembly and Heat Sink	
assembly	50
1110 Base cover, speakers and power	
assembly	52
1120 LCD front bezel	55
1130 LCD panel, LCD cable and hinges.	56
1140 Integrated camera	58
Locations	
Front view	59
Right-side view	60
Bottom and Left-side view	61
Parts list	
Overall	63
LCD FRUs	67
Keyboard	69
Miscellaneous parts	
AC adapters	
Power cords	
Notices	
Trademarks	79

About this manual

This manual contains service and reference information for the following Lenovo product:

Lenovo IdeaPad S200/S206

Use this manual to troubleshoot problems.

The manual is divided into the following sections:

- The common sections provide general information, guidelines, and safety information required for servicing computers.
- The product-specific section includes service, reference, and product-specific parts information.

Important:

This manual is intended only for trained servicers who are familiar with Lenovo products. Use this manual to troubleshoot problems effectively. Before servicing a Lenovo product, make sure to read all the information under "Safety information" on page 1 and "Important service information" on page 16.

Safety information

This chapter presents the following safety information that you need to get familiar with before you service a Lenovo computer:

- "General safety" on page 2
- "Electrical safety" on page 3
- "Safety inspection guide" on page 5
- "Handling devices that are sensitive to electrostatic discharge" on page 6
- "Grounding requirements" on page 6
- "Safety notices: multilingual translations" on page 7
- "Laser compliance statement" on page 14

General safety

Follow these rules below to ensure general safety:

- Observe a good housekeeping in the area where the machines are put during and after the maintenance.
- When lifting any heavy object:
 - 1. Make sure that you can stand safely without slipping.
 - 2. Distribute the weight of the object equally between your feet.
 - 3. Use a slow lifting force. Never move suddenly or twist when you attempt to lift it.
 - 4. Lift it by standing or pushing up with your leg muscles; this action could avoid the strain from the muscles in your back. Do not attempt to lift any object that weighs more than 16 kg (35 lb) or that you think is too heavy for you.
- Do not perform any action that causes hazards to the customer, or that makes the machine unsafe.
- Before you start the machine, make sure that other service representatives and the customer are not in a hazardous position.
- Please remove covers and other parts in a safe place, away from all personnel, while you are servicing the machine.
- Keep your toolcase away from walk areas so that other people will not trip it over.
- Do not wear loose clothing that can be trapped in the moving parts of the machine. Make sure that your sleeves are fastened or rolled up above your elbows. If your hair is long, fasten it.
- Insert the ends of your necktie or scarf inside clothing or fasten it with the nonconductive clip, about 8 centimeters (3 inches) from the end.
- Do not wear jewelry, chains, metal-frame eyeglasses, or metal fasteners for your clothing.

Attention: Metal objects are good electrical conductors.

- Wear safety glasses when you are hammering, drilling, soldering, cutting wire, attaching springs, using solvents, or working in any other conditions that may be hazardous to your eyes.
- After service, reinstall all safety shields, guards, labels, and ground wires. Replace any safety device that is worn or defective.
- Reinstall all covers correctly before returning the machine to the customer.
- Fan louvers on the machine help to prevent the overheating of internal components. Do not obstruct fan louvers or cover them with labels or stickers.

Electrical safety

Observe the following rules when working on electrical equipments.

Important:

Use only approved tools and test equipments. Some hand tools have handles covered with a soft material that does not insulate you when working with live electrical currents.

Many customers have rubber floor mats near their machines that contain small conductive fibers to decrease electrostatic discharges. Do not use such kind of mat to protect yourself from electrical shock.

- Find the room emergency power-off (EPO) switch, disconnecting switch, or electrical outlet. If an electrical accident occurs, you can then operate the switch or unplug the power cord quickly.
- Do not work alone under hazardous conditions or near the equipment that has hazardous voltages.
- Disconnect all power before:
 - Performing a mechanical inspection
 - Working near power supplies
 - Removing or installing main units
- Before you start to work on the machine, unplug the power cord. If you cannot unplug it, ask the customer to power-off the wall box that supplies power to the machine, and to lock the wall box in the off position.
- If you need to work on a machine that has exposed electrical circuits, observe the following precautions:
 - Ensure that another person, familiar with the power-off controls, is near you.

Attention: Another person must be there to switch off the power, if necessary.

- Use only one hand when working with powered-on electrical equipment; keep the other hand in your pocket or behind your back.

Attention: An electrical shock can occur only when there is a complete circuit. By observing the above rule, you may prevent a current from passing through your body.

- When using testers, set the controls correctly and use the approved probe leads and accessories for that tester.
- Stand on suitable rubber mats (obtained locally, if necessary) to insulate you from grounds such as metal floor strips and machine frames.

Observe the special safety precautions when you work with very high voltages; instructions for these precautions are in the safety sections of maintenance information. Be extremely careful when you measure the high voltages.

- Regularly inspect and maintain your electrical hand tools for safe operational condition.
- · Do not use worn or broken tools and testers.
- Never assume that power has been disconnected from a circuit. First, check it to make sure that it has been powered off.

- Always look carefully for possible hazards in your work area. Examples of these hazards are moist floors, nongrounded power extension cables, power surges, and missing safety grounds.
- Do not touch live electrical circuits with the reflective surface of a plastic dental mirror. The surface is conductive; such touching can cause personal injury and machine damage.
- Do not service the following parts with the power on when they are removed from their normal operating places in a machine:
 - Power supply units
 - Pumps
 - Blowers and fans
 - Motor generators

and similar units. (This practice ensures correct grounding of the units.)

- If an electrical accident occurs:
 - Use caution: do not become a victim yourself.
 - Switch off the power.
 - Send the victim to get medical aid.

Safety inspection guide

The purpose of this inspection guide is to assist you in identifying potential unsafe conditions. As each machine was designed and built, required safety items were installed to protect users and service personnel from injury. This guide addresses only those items. You should use good judgment to identify potential safety hazards due to attachment of non-Lenovo features or options not covered by this inspection guide.

If any unsafe conditions are present, you must determine how serious the apparent hazard could be and whether you can continue without first correcting the problem.

Consider these conditions and the safety hazards they present:

- Electrical hazards, especially primary power (primary voltage on the frame can cause serious or fatal electrical shock)
- · Explosive hazards, such as a damaged CRT face or a bulging capacitor
- · Mechanical hazards, such as loose or missing hardware

To determine whether there are any potential unsafe conditions, use the following checklist at the beginning of every service task. Begin the checks with the power off, and the power cord disconnected.

Checklist:

- 1. Check exterior covers for damage (loose, broken, or sharp edges).
- 2. Turn off the computer. Disconnect the power cord.
- 3. Check the power cord for:
 - a. A third-wire ground connector in good condition. Use a meter to measure third-wire ground continuity for 0.1 ohm or less between the external ground pin and the frame ground.
 - b. The power cord should be the type specified in the parts list.
 - c. Insulation must not be frayed or worn.
- 4. Check for cracked or bulging batteries.
- 5. Remove the cover.
- 6. Check for any obvious non-Lenovo alterations. Use good judgment as to the safety of any non-Lenovo alterations.
- Check inside the unit for any obvious unsafe conditions, such as metal filings, contamination, water or other liquids, or signs of fire or smoke damage.
- 8. Check for worn, frayed, or pinched cables.
- 9. Check that the power-supply cover fasteners (screws or rivets) have not been removed or tampered with.

Handling devices that are sensitive to electrostatic discharge

Any computer part containing transistors or integrated circuits (ICs) should be considered sensitive to electrostatic discharge (ESD). ESD damage can occur when there is a difference in charge between objects. Protect against ESD damage by equalizing the charge so that the machine, the part, the work mat, and the person handling the part are all at the same charge.

Notes:

- 1. Use product-specific ESD procedures when they exceed the requirements noted here.
- 2. Make sure that the ESD protective devices you use have been certified (ISO 9000) as fully effective.

When handling ESD-sensitive parts:

- Keep the parts in protective packages until they are inserted into the product.
- Avoid contact with other people.
- Wear a grounded wrist strap against your skin to eliminate static on your body.
- Prevent the part from touching your clothing. Most clothing is insulative and retains a charge even when you are wearing a wrist strap.
- Use the black side of a grounded work mat to provide a static-free work surface. The mat is especially useful when handling ESD-sensitive devices.
- Select a grounding system, such as those listed below, to provide protection that meets the specific service requirement.

Notes:

The use of a grounding system to guard against ESD damage is desirable but not necessary.

- Attach the ESD ground clip to any frame ground, ground braid, or greenwire ground.
- When working on a double-insulated or battery-operated system, use an ESD common ground or reference point. You can use coax or connectoroutside shells on these systems.
- Use the round ground prong of the ac plug on ac-operated computers.

Grounding requirements

Electrical grounding of the computer is required for operator safety and correct system function. Proper grounding of the electrical outlet can be verified by a certified electrician.

Safety notices: multilingual translations

The safety notices in this section are provided in English, French, German, Hebrew, Italian, Japanese, and Spanish.

Safety notice 1

Before the computer is powered on after FRU replacement, make sure all screws, springs, and other small parts are in place and are not left loose inside the computer. Verify this by shaking the computer and listening for rattling sounds. Metallic parts or metal flakes can cause electrical shorts.

Avant de remettre l'ordinateur sous tension après remplacement d'une unité en clientèle, vérifiez que tous les ressorts, vis et autres pièces sont bien en place et bien fixées. Pour ce faire, secouez l'unité et assurez-vous qu'aucun bruit suspect ne se produit. Des pièces métalliques ou des copeaux de métal pourraient causer un court-circuit.

Bevor nach einem FRU-Austausch der Computer wieder angeschlossen wird, muß sichergestellt werden, daß keine Schrauben, Federn oder andere Kleinteile fehlen oder im Gehäuse vergessen wurden. Der Computer muß geschüttelt und auf Klappergeräusche geprüft werden. Metallteile odersplitter können Kurzschlüsse erzeugen.

> לפני הפעלת המחשב לאחר החלמת BTI שי לוודא שכל הברגים, הקפיצים, וחלקים קטנים אחרים נמצאים במקונסם ואינם חופשיים לווז בתוך המחשב. כדי לוודא זאת, שי לטלטל את המחשב ולהקשיב לגילוי קולות שקשוק. חלקי או שבגי מתכת גולוים לגורים השמליים.

Prima di accendere l'elaboratore dopo che é stata effettuata la sostituzione di una FRU, accertarsi che tutte le viti, le molle e tutte le altri parti di piccole dimensioni siano nella corretta posizione e non siano sparse all'interno dell'elaboratore. Verificare ciò scuotendo l'elaboratore e prestando attenzione ad eventuali rumori; eventuali parti o pezzetti metallici possono provocare cortocircuiti pericolosi.

FRUの交換後、コンピュータの電源を入れる前に、ねじ、バネ、その他の小さな部品がすべて正しい位置にあり、またコンピュータの内部で緩んでいないことを確認してください。

これを確認するには、コンピュータを振って、カチャカチャと音がしないか確かめま す。金属部品や金属破片はショートの原因になることがあります。

Antes de encender el sistema despues de sustituir una FRU, compruebe que todos los tornillos, muelles y demás piezas pequeñas se encuentran en su sitio y no se encuentran sueltas dentro del sistema. Compruébelo agitando el sistema y escuchando los posibles ruidos que provocarían. Las piezas metálicas pueden causar cortocircuitos eléctricos.

🗥 DANGER

Some standby batteries contain a small amount of nickel and cadmium. Do not disassemble a standby battery, recharge it, throw it into fire or water, or short-circuit it. Dispose of the battery as required by local ordinances or regulations. Use only the battery in the appropriate parts listing. Use of an incorrect battery can result in ignition or explosion of the battery.

Certaines batteries de secours contiennent du nickel et du cadmium. Ne les démontez pas, ne les rechargez pas, ne les exposez ni au feu ni à l'eau. Ne les mettez pas en court-circuit. Pour les mettre au rebut, conformez-vous à la réglementation en vigueur. Lorsque vous remplacez la pile de sauvegarde ou celle de l'horloge temps réel, veillez à n'utiliser que les modèles cités dans la liste de pièces détachées adéquate. Une batterie ou une pile inappropriée risque de prendre feu ou d'exploser.

Die Bereitschaftsbatterie, die sich unter dem Diskettenlaufwerk befindet, kann geringe Mengen Nickel und Cadmium enthalten. Sie darf nicht zerlegt, wiederaufgeladen, kurzgeschlossen, oder Feuer oder Wasser ausgesetzt werden. Bei der Entsorgung die örtlichen Bestimmungen für Sondermüll beachten. Beim Ersetzen der Bereitschafts-oder Systembatterie nur Batterien des Typs verwenden, der in der Ersatzteilliste aufgeführt ist. Der Einsatz falscher Batterien kann zu Entzündung oder Explosion führen.

> שוללות המתנה מסוימות מטילות כמות קטנה של ניקל וקדמיום. אין לפרק סוללת המתנה, לטעון אותה מחדש, להשליד אותה לאש או למים או לקצר אותה. יש לשלק את הסוללה למים או לקצר אותה. יש לשלק את הסוללה בנדרש על ידי התקנומיים. יש המתאימה עלו המתאימה, שימוש בסוללה לא מתאימה עלול לגרום להצתה או התפוצות של הסוללה.

Alcune batterie di riserva contengono una piccola quantità di nichel e cadmio. Non smontarle, ricaricarle, gettarle nel fuoco o nell'acqua né cortocircuitarle. Smaltirle secondo la normativa in vigore (DPR 915/82, successive disposizioni e disposizioni locali). Quando si sostituisce la batteria dell'RTC (real time clock) o la batteria di supporto, utilizzare soltanto i tipi inseriti nell'appropriato Catalogo parti. L'impiego di una batteria non adatta potrebbe determinare l'incendio o l'esplosione della batteria stessa.

予備バッテリーの中には少量のニッケルとカドミウムが含まれているものがあり ます。したがって、予備バッテリーの分解、再充電、火または水の中への投棄、 またはショートさせることは決して行わないでください。バッテリーを廃棄する 場合は地方自治体の条例に従ってください。適切なパーツ・リストにあるバッテ リーだけを使用してください。誤ったバッテリーを使用すると、バッテリーが発 火したり、爆発したりすることがあります。

Algunas baterías de reserva contienen una pequeña cantidad de níquel y cadmio. No las desmonte, ni recargue, ni las eche al fuego o al agua ni las cortocircuite. Deséchelas tal como dispone la normativa local. Utilice sólo baterías que se encuentren en la lista de piezas. La utilización de una batería no apropiada puede provocar la ignición o explosión de la misma.

\Lambda DANGER

The battery pack contains small amounts of nickel. Do not disassemble it, throw it into fire or water, or short-circuit it. Dispose of the battery pack as required by local ordinances or regulations. Use only the battery in the appropriate parts listing when replacing the battery pack. Use of an incorrect battery can result in ignition or explosion of the battery.

La batterie contient du nickel. Ne la démontez pas, ne l'exposez ni au feu ni à l'eau. Ne la mettez pas en court-circuit. Pour la mettre au rebut, conformez-vous à la réglementation en vigueur. Lorsque vous remplacez la batterie, veillez à n'utiliser que les modèles cités dans la liste de pièces détachées adéquate. En effet, une batterie inappropriée risque de prendre feu ou d'exploser.

Akkus enthalten geringe Mengen von Nickel. Sie dürfen nicht zerlegt, wiederaufgeladen, kurzgeschlossen, oder Feuer oder Wasser ausgesetzt werden. Bei der Entsorgung die örtlichen Bestimmungen für Sondermüll beachten. Beim Ersetzen der Batterie nur Batterien des Typs verwenden, der in der Ersatzteilliste aufgeführt ist. Der Einsatz falscher Batterien kann zu Entzündung oder Explosion führen.

> מארו הסוללה מכיל כמות קטנה של ניקל וקדמיום. און לפרק את מארו הסוללה, להשליך אותו לאש או למיס או לקצר אותו. יש לסלק את מארו הסוללה הסוללה כנדרש על ידי התקנות והחוקים המקומיים. יש להשתמשע רק בסוללה המופיעה ברשימת החלקים המתאימה בזמן החלמת מארו הסוללה. שימוש בסוללה לא מתאימה עלול לגרום להתה או תהמצוצו של הסוללה.

La batteria contiene piccole quantità di nichel. Non smontarla, gettarla nel fuoco o nell'acqua né cortocircuitarla. Smaltirla secondo la normativa in vigore (DPR 915/82, successive disposizioni e disposizioni locali). Quando si sostituisce la batteria, utilizzare soltanto i tipi inseriti nell'appropriato Catalogo parti. L'impiego di una batteria non adatta potrebbe determinare l'incendio o l'esplosione della batteria stessa.

バッテリー・パックには少量のニッケルが含まれています。バッテリー・パック を分解したり、火または水の中に投げ込んだり、ショートさせないでください。 バッテリー・パックの廃棄にあたっては、地方自治体の条例または規則に従って ください。バッテリー・バックを交換するときは、適切なパーツ・リストにある バッテリーだけを使用してください。誤ったバッテリーを使用すると、バッテ リーが発火したり、爆発したりすることがあります。

Las baterías contienen pequeñas cantidades de níquel. No las desmonte, ni recargue, ni las eche al fuego o al agua ni las cortocircuite. Deséchelas tal como dispone la normativa local. Utilice sólo baterías que se encuentren en la lista de piezas al sustituir la batería. La utilización de una batería no apropiada puede provocar la ignición o explosión de la misma.

\land DANGER

The lithium battery can cause a fire, an explosion, or a severe burn. Do not recharge it, remove its polarized connector, disassemble it, heat it above 100°C (212°F), incinerate it, or expose its cell contents to water. Dispose of the battery as required by local ordinances or regulations. Use only the battery in the appropriate parts listing. Use of an incorrect battery can result in ignition or explosion of the battery.

La pile de sauvegarde contient du lithium. Elle présente des risques d'incendie, d'explosion ou de brûlures graves. Ne la rechargez pas, ne retirez pas son connecteur polarisé et ne la démontez pas. Ne l'exposez pas à une temperature supérieure à 100°C, ne la faites pas brûler et n'en exposez pas le contenu à l'eau. Mettez la pile au rebut conformément à la réglementation en vigueur. Une pile inappropriée risque de prendre feu ou d'exploser.

Die Systembatterie ist eine Lithiumbatterie. Sie kann sich entzünden, explodieren oder schwere Verbrennungen hervorrufen. Batterien dieses Typs dürfen nicht aufgeladen, zerlegt, über 100 C erhitzt oder verbrannt werden. Auch darf ihr Inhalt nicht mit Wasser in Verbindung gebracht oder der zur richtigen Polung angebrachte Verbindungsstecker entfernt werden. Bei der Entsorgung die örtlichen Bestimmungen für Sondermüll beachten. Beim Ersetzen der Batterie nur Batterien des Typs verwenden, der in der Ersatzteilliste aufgeführt ist. Der Einsatz falscher Batterien kann zu Entzündung oder Explosion führen.

> סוללת הליתוים עלולה לגרום לשריכה, להתפוצצות או למוויות קשות. אין לטעון אותה מחדש, לסלק את המחבר המולה על 200 מעלות עלזיוט. אין לטרוף את הסוללה ואין העולה על 200 מעלות עלזיוט. אין לטרוף את הסוללה ואין השומעים ובחוקים המקומיים. יש לשלק את הסוללה כנדרש המומיעה ברשימת החלקים המתאימים. שימוש בסוללה האותי ארת עלול לגרום לסכנת שריכה או התמוצצות.

La batteria di supporto e una batteria al litio e puo incendiarsi, esplodere o procurare gravi ustioni. Evitare di ricaricarla, smontarne il connettore polarizzato, smontarla, riscaldarla ad una temperatura superiore ai 100 gradi centigradi, incendiarla o gettarla in acqua. Smaltirla secondo la normativa in vigore (DPR 915/82, successive disposizioni e disposizioni locali). L'impiego di una batteria non adatta potrebbe determinare l'incendio o l'esplosione della batteria stessa.

リチウム・バッテリーは、火災、爆発、または重症のやけどを引き起こすことが あります。パックアップ・バッテリーの充電、その極性コネクターの取り外し、 バッテリー本体の分解、 100 ℃ (212 °F)以上への加熱、焼却、電池の中身を水に浸すことはしないでくださ い。バッテリーを廃棄する場合は地方自治体の条例に従ってください。適切な パーツ・リストにあるバッテリーだけを使用してください。誤っただバッテリーを 使用すると、バッテリーが発火したり、爆発したりすることがあります。

La batería de repuesto es una batería de litio y puede provocar incendios, explosiones o quemaduras graves. No la recargue, ni quite el conector polarizado, ni la desmonte, ni caliente por encima de los 100°C (212°F), ni la incinere ni exponga el contenido de sus celdas al agua. Deséchela tal como dispone la normativa local.

If the LCD breaks and the fluid from inside the LCD gets into your eyes or on your hands, immediately wash the affected areas with water at least for 15 minutes. Seek medical care if any symptoms caused by the fluid are present after washing.

Si le panneau d'affichage à cristaux liquides se brise et que vous recevez dans les yeux ou sur les mains une partie du fluide, rincez-les abondamment pendant au moins quinze minutes. Consultez un médecin si des symptômes persistent après le lavage.

Die Leuchtstoffröhre im LCD-Bildschirm enthält Quecksilber. Bei der Entsorgung die örtlichen Bestimmungen für Sondermüll beachten. Der LCD-Bildschirm besteht aus Glas und kann zerbrechen, wenn er unsachgemäß behandelt wird oder der Computer auf den Boden fällt. Wenn der Bildschirm beschädigt ist und die darin befindliche Flüssigkeit in Kontakt mit Haut und Augen gerät, sollten die betroffenen Stellen mindestens 15 Minuten mit Wasser abgespült und bei Beschwerden anschließend ein Arzt aufgesucht werden.

> אם מסך הגביש הנווזלי (LCD) נשבר והנוזל מתוך המסך בא במגע עם עיניכם או יזיכם, שטפו את האזורים הנגועים מיד במים במשך 15 דקות לפחות. פנו לקבלת עזרה רפואית אם תסמינים הנובעים מהמגע עם הנוזל נמשכים לאחר השטיפה.

Nel caso che caso l'LCD si dovesse rompere ed il liquido in esso contenuto entrasse in contatto con gli occhi o le mani, lavare immediatamente le parti interessate con acqua corrente per almeno 15 minuti; poi consultare un medico se i sintomi dovessero permanere.

LCD が破損し、 LCD の中の液体が目に入ったり、手に触れたりした場合は、液 体が触れた部分を少なくとも 15 分間洗い流してください。洗い流した後に、液体 によって何らかの症状が現れた場合は、医師の治療を受けてください。

Si la LCD se rompe y el fluido de su interior entra en contacto con sus ojos o sus manos, lave inmediatamente las áreas afectadas con agua durante 15 minutos como mínimo. Obtenga atención medica si se presenta algún

A DANGER

To avoid shock, do not remove the plastic cover that protects the lower part of the inverter card.

Afin d'éviter tout risque de choc électrique, ne retirez pas le cache en plastique protégeant la partie inférieure de la carte d'alimentation.

Aus Sicherheitsgründen die Kunststoffabdeckung, die den unteren Teil der Spannungswandlerplatine umgibt, nicht entfernen.

כדי למנוע התחשמלות, אין להסיר את מכסה הפלסטיק המגן על חלקו התחתון של הכרטיס ההפוך.

Per evitare scosse elettriche, non rimuovere la copertura in plastica che avvolge la parte inferiore della scheda invertitore.

感電を防ぐため、インバーター・カードの下部を保護しているプラスチック・カ バーを外さないでください。

Para evitar descargas, no quite la cubierta de plástico que rodea la parte baja de la tarjeta invertida.

Safety notice 7

A DANGER

Though the main batteries have low voltage, a shorted or grounded battery can produce enough current to burn personnel or combustible materials. Bien que le voltage des batteries principales soit peu élevé, le court-circuit ou la mise à la masse d'une batterie peut produire suffisamment de courant pour brûler des matériaux combustibles ou causer des brûlures corporelles graves.

Obwohl Hauptbatterien eine niedrige Spannung haben, können sie doch bei Kurzschluß oder Erdung genug Strom abgeben, um brennbare Materialien zu entzünden oder Verletzungen bei Personen hervorzurufen.

> אף שהסוללות הראשיות הן בעלות מתח נמוך, סוללה מקוצרת או מוארקת עלולה להפיק זרם מספיק לגרימת כוויות או להצתת חומרים דליקים.

Sebbene le batterie di alimentazione siano a basso voltaggio, una batteria in corto circuito o a massa può fornire corrente sufficiente da bruciare materiali combustibili o provocare ustioni ai tecnici di manutenzione.

メイン・バッテリーの電圧は低くても、ショートしたり、接地したバッテ リーが、作業者にやけどを負わせたり、可燃物を燃やすだけの電流を発生さ せる場合があります。

Aunque las baterías principales tienen un voltaje bajo, una batería cortocircuitada o con contacto a tierra puede producir la corriente suficiente como para quemar material combustible o provocar quemaduras en el personal.

A DANGER

Before removing any FRU, turn off the computer, unplug all power cords from electrical outlets, remove the battery pack, and then disconnect any interconnecting cables.

Avant de retirer une unité remplaçable en clientèle, mettez le système hors tension, débranchez tous les cordons d'alimentation des socles de prise de courant, retirez la batterie et déconnectez tous les cordons d'interface.

Die Stromzufuhr muß abgeschaltet, alle Stromkabel aus der Steckdose gezogen, der Akku entfernt und alle Verbindungskabel abgenommen sein, bevor eine FRU entfernt wird.

> לפני סילוק FRU כלשהו, יש לכבות את המחשב, לנתק את כל כבלי החשמל משקעי החשמל, להוציא את מארז הסוללה, ואז לנתק כבלי חיבור אחרים אם יש כאלה.

Prima di rimuovere qualsiasi FRU, spegnere il sistema, scollegare dalle prese elettriche tutti i cavi di alimentazione, rimuovere la batteria e poi scollegare i cavi di interconnessione.

FRUを取り外す前に、ThinkPadの電源を切って、すべての電源コードをコンセントから外してください。次に、バッテリー・パックを外し、相互接続ケープルを外してください。

Antes de quitar una FRU, apague el sistema, desenchufe todos los cables de las tomas de corriente eléctrica, quite la batería y, a continuación, desconecte cualquier cable de conexión entre dispositivos.

Laser compliance statement

Some models of Lenovo computer are equipped from the factory with an optical storage device such as a CD-ROM drive or a DVD-ROM drive. Such devices are also sold separately as options. If one of these drives is installed, it is certified in the U.S. to conform to the requirements of the Department of Health and Human Services 21 Code of Federal Regulations (DHHS 21 CFR) Subchapter J for Class 1 laser products. Elsewhere, the drive is certified to conform to the requirements of the International Electrotechnical Commission (IEC) 825 and CENELEC EN 60 825 for Class 1 laser products.

If a CD-ROM drive, a DVD-ROM drive, or another laser device is installed, note the following:

▲ CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein might result in hazardous radiation exposure. O uso de controles, ajustes ou desempenho de procedimentos diferentes daqueles aqui especificados pode resultar em perigosa exposição à radiação.

凡未在这里指明的任何控制用法、调整、行为, 都会导致严重后果。

Pour éviter tout risque d'exposition au rayon laser, respectez les consignes de réglage et d'utilisation des commandes, ainsi que les procédures décrites.

Werden Steuer- und Einstellelemente anders als hier festgesetzt verwendet, kann gefährliche Laserstrahlung auftreten.

Az itt előírt eljárásoktól, beállításoktól és vezérlésektől eltérni a lézersugárzás veszélye miatt kockázatos !

L'utilizzo di controlli, regolazioni o l'esecuzione di procedure diverse da quelle specificate possono provocare l'esposizione a.

Использование элементов настройки и выполнение процедур иных, чем указано здесь, может привести к опасному радиационному облучению.

Použitie kontrôl, úprav alebo iných vykonaní od iných výrobcov, ako je v tomto špecifikované, mohlo by mať za následok nebezpečenstvo vystavenia sa vyžiarovaniu.

本書で指定された内容以外の、お客様による整備、調整、または手順を行った場合、レーザー光の放射の危険があります。

El uso de controles o ajustes o la ejecución de procedimientos distintos de los aquí especificados puede provocar la exposición a radiaciones peligrosas.

Opening the CD-ROM drive, the DVD-ROM drive, or any other optical storage device could result in exposure to hazardous laser radiation. There are no serviceable parts inside those drives. **Do not open**.

A CD-ROM drive, a DVD-ROM drive, or any other storage device installed may contain an embedded Class 3A or Class 3B laser diode. Note the following:

A DANGER

Emits visible and invisible laser radiation when open. Do not stare into the beam, do not view directly with optical instruments, and avoid direct exposure to the beam.

Radiação por raio laser ao abrir. Não olhe fixo no feixe de luz, não olhe diretamente por meio de instrumentos óticos e evite exposição direta com o feixe de luz.

开启时会有激光发射时,请勿盯视激光光束,请勿直接查看 视觉仪器,并且避免直接接触在激光光束之中。

Rayonnement laser si carter ouvert. Évitez de fixer le faisceau, de le regarder directement avec des instruments optiques, ou de vous exposer au rayon.

Laserstrahlung bei geöffnetem Gerät. Nicht direkt oder über optische Instrumente in den Laserstrahl sehen und den Strahlungsbereich meiden.

Kinyitáskor lézersugár ! Ne nézzen bele se szabad szemmel, se optikai eszközökkel. Kerülje a sugárnyalábbal való érintkezést!

Aprendo l'unità vengono emesse radiazioni laser. Non fissare il fascio, non guardarlo direttamente con strumenti ottici e evitare l'esposizione diretta al fascio.

Открывая, берегитесь лазерного излучения. Не смотрите на луч, не разглядывайте его с помощью оптических инструментов, а также избегайте прямого воздействия лазерного луча.

Keď je laserová jednotka otvorená. Vyhnite sa priamemu pohľadu a nehľadte priamo s optickými nástrojmi do ľúča a vyhnite sa priamemu vystaveniu ľúčov.

開けるとレーザー光が放射されます。光線を見つめたり、光学機械を使って直接見たりしないでください。

Radiación láser al abrir. No mire fijamente ni examine con instrumental óptico el haz de luz. Evite la exposición directa al haz.

Important service information

This chapter presents the following important service information:

- "Strategy for replacing FRUs" on page 16
 - "Strategy for replacing a hard disk drive" on page 17
 - "Important notice for replacing a system board" on page 17
- "Important information about replacing RoHS compliant FRUs" on page 18

Important:

BIOS and device driver fixes are customer-installable. The BIOS and device drivers are posted on the customer support site: http://consumersupport.lenovo.com/.

Strategy for replacing FRUs

Before replacing parts:

Make sure that all software fixes, drivers, and BIOS downloads are installed before replacing any FRUs listed in this manual.

After a system board is replaced, ensure that the latest BIOS is loaded to the system board before completing the service action.

To download software fixes, drivers, and BIOS, follow the steps below:

- 1. Go to http://consumersupport.lenovo.com/.
- 2. Enter the serial number or select a product or use Lenovo smart downloading.
- 3. Select the BIOS/Driver/Applications and download.
- 4. Follow the directions on the screen and install the necessary software.

Use the following strategy to prevent unnecessary expense for replacing and servicing FRUs:

- If you are instructed to replace an FRU, but the replacement does not solve the problem, reinstall the original FRU before you continue.
- Some computers have both a processor board and a system board. If you are instructed to replace either of them, and replacing one of them does not solve the problem, reinstall that board, and then replace the other one.
- If an adapter or a device consists of more than one FRU, any of the FRUs may be the cause of the error. Before replacing the adapter or device, remove the FRUs one by one to see if the symptoms change. Replace only the FRU that changed the symptoms.

Attention: The setup configuration on the computer you are servicing may have been customized. Running Automatic Configuration may alter the settings. Note the current configuration settings (using the View Configuration option); then, when service has been completed, verify that those settings remain in effect.

Strategy for replacing a hard disk drive

Always try to run a low-level format before replacing a hard disk drive. This will cause all customer data on the hard disk to be lost. Make sure that the customer has a current backup of the data before performing this action.

Attention: The drive startup sequence in the computer you are servicing may have been changed. Be extremely careful during write operations such as copying, saving, or formatting. If you select an incorrect drive, data or programs can be overwritten.

Important notice for replacing a system board

Some components mounted on a system board are very sensitive. Improper handling can cause damage to those components, and may cause a system malfunction.

Attention: When handling a system board:

- Do not drop the system board or apply any excessive force to it.
- · Avoid rough handling of any kind.
- Avoid bending the system board and hard pushing to prevent cracking at each BGA (Ball Grid Array) chipset.

Important information about replacing RoHS compliant FRUs

RoHS, The Restriction of Hazardous Substances in Electrical and Electronic Equipment Directive (2002/95/EC) is a European Union legal requirement affecting the global electronics industry. RoHS requirements must be implemented on Lenovo products placed on the market after June 2006. Products on the market before June 2006 are not required to have RoHS compliant parts. If the original FRU parts are non-compliant, replacement parts can also be non-compliant. In all cases if the original FRU parts are RoHS compliant, the replacement part must also be RoHS compliant.

Note: RoHS and non-RoHS FRU part numbers with the same fit and function are identified with unique FRU part numbers.

Lenovo plans to transit to RoHS compliance well before the implementation date and expects its suppliers to be ready to support Lenovo's requirements and schedule in the EU. Products sold in 2005 and 2006 will contain some RoHS compliant FRUs. The following statement pertains to these products and any product Lenovo produces containing RoHS compliant FRUs.

RoHS compliant FRUs have unique FRU part numbers. Before or after the RoHS implementation date, failed RoHS compliant parts must always be replaced with RoHS compliant ones, so only the FRUs identified as compliant in the system HMM or direct substitutions for those FRUs may be used.

Products marketed before June 2006		Products marketed after June 2006	
Current orReplacementoriginal partFRU		Current or original part	Replacement FRU
Non-RoHS	Can be Non-RoHS		
Non-RoHS	Can be RoHS	Must be RoHS	Must be RoHS
Non-RoHS	Can sub to RoHS	Must be Kons	Must be Kons
RoHS	Must be RoHS		

Note: A direct substitution is a part with a different FRU part number that is automatically shipped by the distribution center at the time of the order.

General checkout

This chapter presents the following information:

- "What to do first" on page 20
- "Power system checkout" on page 21

Before you go to the checkout, make sure to read the following important notes:

Important notes:

- · Only certified trained personnel can service the computer.
- Before replacing any FRU, read the entire page on removing and replacing FRUs.
- · When you replace FRUs, use new nylon-coated screws.
- Be extremely careful during such write operations as copying, saving, or formatting. Drives in the computer that you are servicing sequence might have been altered. If you select an incorrect drive, data or programs might be overwritten.
- Replace an FRU only with another FRU of the correct model. When you replace an FRU, make sure that the machine model and the FRU part number are correct by referring to the FRU parts list.
- An FRU should not be replaced just because of a single, unreproducible failure. Single failures can occur for a variety of reasons that have nothing to do with a hardware defect, such as cosmic radiation, electrostatic discharge, or software errors. Consider replacing an FRU only when a problem recurs. If you suspect that an FRU is defective, clear the error logs and run the test again. If the error does not recur, do not replace the FRU.
- Be careful not to replace a nondefective FRU.

What to do first

When you do return an FRU, you must include the following information in the parts exchange form or parts return form that you attach to it:

- 1. Name and phone number of servicer
- 2. Date of service
- 3. Date on which the machine failed
- 4. Date of purchase
- 5. Procedure index and page number in which the failing FRU was detected
- 6. Failing FRU name and part number
- 7. Machine type, model number, and serial number
- 8. Customer's name and address

Note for warranty: During the warranty period, the customer may be responsible for repair costs if the computer damage was caused by misuse, accident, modification, unsuitable physical or operating environment, or improper maintenance by the customer.

The following is a list of some common items that are not covered under warranty and some symptoms that might indicate that the system was subjected to stress beyond normal use.

Before checking problems with the computer, determine whether the damage is covered under the warranty by referring to the following list:

The following are not covered under warranty:

- LCD panel cracked from the application of excessive force or from being dropped
- Scratched (cosmetic) parts
- · Distortion, deformation, or discoloration of the cosmetic parts
- Plastic parts, latches, pins, or connectors that have been cracked or broken by excessive force
- · Damage caused by liquid spilled into the system
- Damage caused by the improper insertion of a PC Card or the installation of an incompatible card
- · Improper disk insertion or use of an optical drive
- Diskette drive damage caused by pressure on the diskette drive cover, foreign material in the drive, or the insertion of a diskette with multiple labels
- · Damaged or bent diskette eject button
- · Fuses blown by attachment of a nonsupported device
- · Forgotten computer password (making the computer unusable)
- Sticky keys caused by spilling a liquid onto the keyboard
- Use of an incorrect AC adapter on laptop products

The following symptoms might indicate damage caused by nonwarranted activities:

- Missing parts might be a symptom of unauthorized service or modification.
- If the spindle of a hard disk drive becomes noisy, it may have been subjected to excessive force, or dropped.

Power system checkout

To verify a symptom, follow the steps below:

- 1. Turn off the computer.
- 2. Remove the battery pack.
- 3. Connect the AC adapter.
- 4. Make sure that power is supplied when you turn on the computer.
- 5. Turn off the computer.
- 6. Disconnect the AC adapter and install the charged battery pack.
- 7. Make sure that the battery pack supplies power when you turn on the computer.

If you suspect a power problem, see the appropriate one of the following power supply checkouts:

- "Checking the AC adapter" on page 21
- "Checking operational charging" on page 21
- "Checking the battery pack" on page 22

Checking the AC adapter

You are here because the computer fails only when the AC adapter is used.

- If the power-on indicator does not turn on, check the power cord of the AC adapter for correct continuity and installation.
- If the computer does not charge during operation, go to "Checking operational charging".

To check the AC adapter, follow the steps below:

- 1. Unplug the AC adapter cable from the computer.
- 2. Measure the output voltage at the plug of the AC adapter cable. See the following figure:



Pin	Voltage (V DC)
1	+20
2	0

Note: Output voltage for the AC adapter pin No. 2 may differ from the one you are servicing.

- 3. If the voltage is not correct, replace the AC adapter.
- 4. If the voltage is acceptable, do the following:
- Replace the system board.
- If the problem persists, go to "Lenovo IdeaPad S200/S206" on page 27.

Note: Noise from the AC adapter does not always indicate a defect.

Checking operational charging

To check whether the battery charges properly during operation, use a discharged battery pack or a battery pack that has less than 50% of the total power remaining when installed in the computer.

Perform operational charging. If the battery status indicator or icon does not light on, remove the battery pack and let it return to room temperature. Reinstall the battery pack. If the charge indicator or icon is still off, replace the battery pack.

If the charge indicator still does not light on, replace the system board. Then reinstall the battery pack. If it is still not charged, go to the next section.

Checking the battery pack


Battery charging does not start until the Power Meter shows that less than 95% of the total power remains; under this condition the battery pack can charge to 100% of its capacity. This protects the battery pack from being overcharged or from having a shortened life.

To check your battery, move your cursor to the Power Meter icon in the icon tray of the Windows[®] taskbar and wait for a moment (but do not click it), and the percentage of battery power remaining is displayed. To get detailed information about the battery, double-click the Power Meter icon.

Note: If the battery pack becomes hot, it may not be able to be charged. Remove it from the computer and leave it at room temperature for a while. After it cools down, reinstall and recharge it.

To check the battery pack, follow the steps below:

- 1. Turn off the computer.
- 2. Remove the battery pack and measure the voltage between battery terminals 1 (+) and 7 (-). See the following figure:



Terminal	Voltage (V DC)
1	+0 to +14
7	Ground (-)

 If the voltage is less than +11.0 V DC, the battery pack has been discharged. Note: Recharging will be continued for at least 3 hours, even though the indicator does not light on.

If the voltage is still less than +11.0 V DC after recharging, replace the battery.

4. If the voltage is more than +11.0 V DC, measure the resistance between battery terminals 5 and 7. The resistance must be 4 to 30 K Ω . If the resistance is not correct, replace the battery pack. If the resistance is correct, replace the system board.

Related service information

This chapter presents the following information:

- "Restoring the factory contents by using Recovery Disc Set" on page 23
- "Passwords" on page 24
- "Power management" on page 25

Restoring the factory contents by using Recovery Disc Set

When the hard disk drive or solid state drive is replaced because of a failure, no product recovery program is on the new drive. In this case, you must use the *Recovery Disc Set* for the computer. Order the *Recovery Disc Set* and the drive at the same time so that you can recover the new drive with the pre-installed software when they arrive.

The *Recovery Disc Set* consists of the following set of DVDs to restore the computer to the original factory configuration.

Start Recovery Disc (one disc)

This disc is used to format the hard disk drive and initiate the recovery process.

Operating System Recovery Disc (one or more discs)

This disc restores the Microsoft Windows operating system.

Applications and Drivers Recovery Disc (one or more discs)

This disc restores the pre-installed applications and drivers on the computer.

Supplemental Recovery Disc

This disc contains additional content, such as software for specific models and updates to the software that was preloaded on the computer. Not all recovery disc sets come with a *Supplemental Recovery Disc*.

To restore the computer to the original factory configuration using the recovery disc set, do the following:

- 1. Insert the bootable Start Recovery Disc into the optical drive.
- Start the computer. When the Lenovo logo comes up, immediately press F12; on the boot sequence menu, select the optical drive as the first boot-up device. The computer will boot from the *Start Recovery Disc*. Follow the on-screen instructions to begin the recovery process.
- 3. Read the license. If you agree with the terms, select **I accept these terms and conditions** and then click **Next**.
- 4. Insert the **Operating System Recovery Disc** when prompted and click **Yes** to begin the operating system recovery process.
- 5. Insert the *Applications and Drivers Recovery Disc* when prompted and then click **OK** to begin the applications and drivers recovery process.
- 6. If you have a *Supplemental Recovery Disc*, insert it when prompted and click **Yes**. If you do not have a *Supplemental Recovery Disc*, click **No**.

7. When all of the data has been copied from the last disc in the set, remove the disc and restart the computer.

Note: The remainder of the recovery process is fully automated and no action is required by you. The computer will restart into the Windows desktop several times and you might experience periods when no activity is apparent on the screen for several minutes at a time. This is normal.

 When the recovery process is complete, the Welcome to the Microsoft Windows screen is displayed. Follow the instructions on the screen to complete the Windows setup.

Passwords

As many as three passwords may be needed for any Lenovo computer: the power-on password (POP), the hard disk password (HDP), and the supervisor password (SVP).

If any of these passwords has been set, a prompt for it appears on the screen whenever the computer is turned on. The computer does not start until the password is entered.

Exception: If only an SVP is installed, the password prompt does not appear when the operating system is booted.

Power-on password

A power-on password (POP) protects the system from being powered on by an unauthorized person. The password must be entered before an operating system can be booted.

Hard-disk password

There are two hard-disk passwords (HDPs):

+ User HDP - for the user

+ Master HDP - for the system administrator, who can use it to get access to the hard disk drive even if the user has changed the user HDP

Attention: If the user HDP has been forgotten, check whether a master HDP has been set. If it has, it can be used for access to the hard disk drive. If no master HDP is available, neither Lenovo nor Lenov authorized service technicians provide any services to reset either the user or the master HDP, or to recover data from the hard disk drive. The hard disk drive can be replaced for a scheduled fee.

Supervisor password

A supervisor password (SVP) protects the system information stored in the BIOS Setup Utility. The user must enter the SVP in order to get access to the BIOS Setup Utility and change the system configuration.

Attention: If the SVP has been forgotten and cannot be made available to the servicer, there is no service procedure to reset the password. The system board must be replaced for a scheduled fee.

Power management

Note: Power management modes are not supported for APM operating system.

To reduce power consumption, the computer has three power management modes: screen blank, sleep (standby), and hibernation.

Screen blank state

If the time set on the "Turn off monitor" timer in the operating system expires, the LCD backlight turns off. You can also turn off the LCD backlight by pressing [*, m].

To end screen blank state and resume normal operation, press 🔭

Sleep (standby) state

When the computer enters sleep (standby) state, the following events occur in addition to what occurs in screen blank state:

- The LCD is powered off.
- The hard disk drive is powered off.
- The CPU stops.

Putting your computer into sleep state

If you will be away from your computer for only a short time, put the computer into sleep state.

When the computer is in sleep state, you can quickly wake it to resume use, and bypass the startup process.

To put the computer into sleep state, click O and select **Sleep** from the Start menu.

To wake the computer, do one of the following.

- Press the power button.
- Press any key on the keyboard.

Also, in the following event, the computer automatically returns from sleep (standby) state and resumes the operation:

• The time set on the resume timer elapses.

Note: The computer does not accept any input immediately after it enters sleep (standby) state. Wait a few seconds before taking any action to reenter operation mode.

Hibernation state

In hibernation state, the following occurs:

- The system status, RAM, VRAM, and setup data are stored on the hard disk.
- The system is powered off.

To cause the computer to enter hibernation state, follow the steps below:

- If you are using the ACPI operating system and have defined one of the following actions as the event that causes the system to go into hibernation state, perform that action:
 - Closing the lid.
 - Pressing the power button.

Also, the computer goes into hibernation state automatically in either of the following conditions:

- If a "hibernation time" has been set on the timer, and if the user does not do any operation with the keyboard, the hard disk drive, the parallel connector, or the diskette drive within that time.
- If the timer conditions are satisfied in suspend mode.

When the power is turned on, the computer returns from hibernation state and resumes operation. The hibernation file in the boot record on the hard disk drive is read, and system status is restored from the hard disk drive.

Lenovo IdeaPad S200/S206

This chapter presents the following product-specific service references and product-specific parts information:

- "Specifications" on page 27
- "Status indicators" on page 29
- "FRU tests" on page 31
- "Fn key combinations" on page 31
- "FRU replacement notices" on page 32
- "Removing and replacing an FRU" on page 33
- "Locations" on page 59
- "Parts list" on page 62

Specifications

The following table lists the specifications of the Lenovo IdeaPad S200/S206: *Table 1. Specifications*

	Lenovo IdeaPad S200	Lenovo IdeaPad S206
Feature	Description	
Processor	Intel Cedar Trail - M	AMD Brazos
Core Chipset	Intel NM10	AMD A50M FCH
Bus architecture	1066MHz DDR3 SDRAM (PC2-8500)	1066MHz DDR3 SDRAM (PC2-8500)
	PCI bus	PCI Express bus
	PCI Express bus	UMI
	DMI	
Graphic Chipset	Intel Integrated Graphics	AMD Radeon HD 6290 (C60)
Display	11.6" SD, LED backlight, Flat type, 1366 × 768 pixel	
Standard memory	DDR3-800 or DDR3-1066 1x2GB/4GB slot (Max Memory 4GB)	DDR3-1066 1x2GB/4GB slot (Max Memory 4GB)
CMOS RAM	256 bytes	
Hard disk drive	2.5" HDD (7mm) 500GB, 5400rpm/7200rpm* 320GB, 5400rpm/7200rpm*	
Optical drive	Support USB external ODD	

	Lenovo IdeaPad S200	Lenovo IdeaPad S206		
Feature	Description			
I/O ports	External mon	itor connector		
	Combo headphone jack			
	Combo build in Microphone jack			
	HDMI port × 1			
	USB 2.0 × 1,	, USB 3.0 × 1		
	2-in-1 memory card rea	der slot \times 1 (MMC, SD)		
Audio	Combo au	dio jack × 1		
	Speak	$xer \times 2$		
	Built-in m	Built-in microphone		
Video	HDMI port × 1			
WLAN				
WWAN				
Bluetooth	only support BT&V	VIFI combo module		
Keyboard	New Ke	ey Board		
Touch pad	One piece	touchpad		
Integrated camera	0.3 meg	a pixels		
Battery	2 cells, 27WH Li-Ion Polymer			
AC adapter		00-240V/50-60Hz, 3pin 40W DC output		
Pre-installed operating system	Windows 7 starter	r/HP/HB/Meego		

Table 1.	Specifi	cations	(continued)
----------	---------	---------	-------------

Status indicators

The system status indicators below show the computer status:




Table 2. Status indicators

Indicator	Meaning		
1 Power on	On (solid white):		
U U	The computer is powered on.		
	Blinking:		
	The computer is in sleep mode.		
	off: The computer is powered off.		
2 Battery	On (solid white):		
	The battery has more than 20% charge.		
	Solid amber:		
	The battery has between 5% and 20% charge.		
	Fast blinking amber:		
	The battery has less than 5% charge.		
	Slow blinking amber:		
	The battery is being charged. When battery charge reaches 20%, the blinking color changes to white.		
	Slow blinking white:		
	The battery has between 20% and 80% charge and i still charging. When the battery reaches 80% charg the light will stop blinking, but charging will continue until the battery is fully charged.		
	Off: The battery is detached.		

Fn key combinations

The following table shows the function of each combination of Fn with a function key.

Table 3. Fn key combinations

Key combination	Description
Fn + PgUp:	Activate the Home function.
Fn + PgDn:	Activate the End function.

Hotkeys

The hotkeys are located in the function key row of the keyboard.By pressing the appropriate hotkey, you can change system settings instantly.

The following describes the function of each hotkey.

Table	4.	Hotkeys

Hotkeys	Description
M:	Mute/Unmute.
r⊄− _{F2} :	Decrease sound volume.
¤(+ _№):	Increase sound volume.
× 14	Close active window or program.
47 F6	Refresh desktop or Web pages.
□ _{P0} :	Enable/Disable the touchpad.
(' E ') _{F7} :	Open the interface for integrated wireless devices settings (on/off).
× ₁₈ :	Enable/Disable the built-in microphone.
<u>ه</u> ک	Turn on/off the integrated camera.
	Open the interface for changing display devices.
* _{P11} :	Turn on/off the backlight of the LCD screen.
☆ - _{F12} :	Decrease display brightness.
☆+ ine	Increase display brightness.

FRU replacement notices

This section presents notices related to removing and replacing parts. Read this section carefully before replacing any FRU.

Screw notices

Loose screws can cause a reliability problem. In the Lenovo computer, this problem is addressed with special nylon-coated screws that have the following characteristics:

- They maintain tight connections.
- They do not easily come loose, even with shock or vibration.
- They are harder to tighten.
- Each one should be used only once.

Do the following when you service this machine:

- Keep the screw kit in your tool bag.
- Always use new screws.
- Use a torque screwdriver if you have one.

Tighten screws as follows:

· Plastic to plastic

Turn an additional 90° after the screw head touches the surface of the plastic part:



• Logic card to plastic

Turn an additional 180° after the screw head touches the surface of the logic card:



• Torque driver

If you have a torque screwdriver, refer to the "Torque" column for each step.

- Make sure that you use the correct screws. If you have a torque screwdriver, tighten all screws firmly to the torque shown in the table. Never use a screw that you removed. Use a new one. Make sure that all screws are tightened firmly.
- Ensure torque screwdrivers are calibrated correctly following country specifications.

Removing and replacing an FRU

This section presents exploded figures with the instructions to indicate how to remove and replace the FRU. Make sure to observe the following general rules:

- 1. Do not attempt to service any computer unless you have been trained and certified. An untrained person runs the risk of damaging parts.
- 2. Before replacing any FRU, review "FRU replacement notices" on page 32.
- Begin by removing any FRUs that have to be removed before the failing FRU. Any of such FRUs are listed at the top of the page. Remove them in the order in which they are listed.
- 4. Follow the correct sequence in the steps to remove the FRU, as given in the figures by the numbers in square callouts.
- 5. When turning a screw to replace an FRU, turn it in the direction as given by the arrow in the figure.
- 6. When removing the FRU, move it in the direction as given by the arrow in the figure.
- 7. To put the new FRU in place, reverse the removal procedures and follow any of the notes that pertain to replacement. For information about connecting and arranging internal cables, see "Locations" on page 59.
- 8. When replacing an FRU, use the correct screw as shown in the procedures.

A DANGER

Before removing any FRU, turn off the computer, unplug all power cords from electrical outlets, remove the battery pack, and then disconnect any of the interconnecting cables.

Attention: After replacing an FRU, do not turn on the computer until you have made sure that all screws, springs, and other small parts are in place and none are loose inside the computer. Verify this by shaking the computer gently and listening for rattling sounds. Metallic parts or metal flakes can cause electrical short circuits.

Attention: The system board is sensitive to, and can be damaged by, electrostatic discharge. Before touching it, establish personal grounding by touching a ground point with one hand or using an electrostatic discharge (ESD) strap (P/N 6405959) to remove potential shock reasons.


1010 Battery pack

A DANGER

Only use the battery specified in the parts list for your computer. Any other battery could ignite or explode.

Figure 1. Removal steps of battery pack

Open two rubber foot pads with a screw driver in the direction shown by arrow 1, then remove two screws 2.



Open the back cover along the device frame with a flat blade in the direction shown by arrows and then lift the back cover in the direction shown by arrow **3**.






Figure 1. Removal steps of battery pack (continued)

Detach the system board connector in the direction shown by arrows **12**, unplug the battery connector in the direction shown by arrow **3**, remove five screws **4**.




Step	Screw (quantity)	Color	Torque
3	$M2 \times 3$ mm, flat-head, nylokcoated (5)	Silver	1.5 kgfcm

Remove the battery in the direction shown by arrow **5**.



1020 Dummy card

Figure 2. Removal steps of dummy cards Remove the dummy card in the direction shown by arrows **1 2**.



1030 Hard disk drive

For access, remove these FRUs in order:


• "1010 Battery pack" on page 34

Attention:

- Do not drop the hard disk drive or apply any physical shock to it. The hard disk drive is sensitive to physical shock. Improper handling can cause damages and permanent loss of data.
- Before removing the drive, suggest the customer to backup all the information on it if possible.
- Never remove the drive while the system is operating or is in suspend mode.

Figure 3. Removal steps of hard disk drive


Remove the frame fixing screws **1**. Pull the HDD bracket in the direction shown by arrow **2**.



Step	Screw (quantity)	Color	Torque
1	$M2 \times 3$ mm, flat-head, nylok-coated (4)	Silver	1.5 kgfcm

Figure 3. Removal steps of hard disk drive (continued)

Take out the hard disk drive secured in a metal frame in the direction shown by arrows **3 4**.



When installing: Make sure that the HDD connector is attached firmly.


1040 DIMM

For access, remove these FRUs in order:

• "1010 Battery pack" on page 34

Figure 4. Removal steps of DIMM

Release the two latches on both edges of the socket at the same time in the direction shown by arrows **1**, and then unplug the DIMM in the direction shown by arrow **2**.




When installing: Insert the notched end of the DIMM into the socket. Push the DIMM firmly, and pivot it until it snaps into the place. Make sure that it is firmly fixed in the slot and difficult to be moved.

1050 PCI Express Mini Card for wireless LAN/WAN

For access, remove these FRUs in order:

• "1010 Battery pack" on page 34

Figure 5. Removal steps of PCI Express Mini Card for wireless LAN/WAN Disconnect the two wireless LAN cables **1**, and then remove the screws **2**.




In step **1**, unplug the jacks by using the removal tool antenna RF connector (P/N: 08K7159), or pick up the connectors with your fingers and gently unplug them in the direction shown by arrows.

Notes: wireless LAN card has 2 cables in step **1**.

wireless LAN card in some models may have 3 cables in step 1.

Step	Screw (quantity)	Color	Torque
1	$M2 \times 5$ mm, flat-head, nylok-coated (2)	Black	1.5 kgfcm

Figure 5. Removal steps of PCI Express Mini Card for wireless LAN/WAN (continued) Remove the card in the direction shown by arrow **3**.



When installing:

- In models with a wireless LAN card that has two antenna connectors, plug the black cable (1st) (MAIN) into the jack labeled **1**, and the white cable (2nd) (AUX) into jack labeled **2** on the card.
- In models with a wireless LAN card that has three antenna connectors, plug the black cable (1st) (MAIN) into the jack labeled **1**, the grey cable (3rd) into jack labeled **3**, and the white cable (2nd) (AUX) into jack labeled **2** on the card.


1060 3G Card

For access, remove these FRUs in order:

• "1010 Battery pack" on page 34


Figure 6. Removal steps of 3G Card

Disconnect two connectors **1** and remove the screw **2**.



Step	Screw (quantity)	Color	Torque
1	$M2 \times 3$ mm, flat-head, nylok-coated (1)	Silver	1.5 kgfcm

Remove the card in the direction shown by arrow 3.




1070 Keyboard

For access, remove this FRU:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42

Figure 7. Removal steps of keyboard

Remove the screw **1**.



Step	Screw (quantity)	Color	Torque
1	M2 × 3 mm, flat-head, nylok-coated (1)	Silver	1.5 kgfcm

Loosen the keyboard with fingers in the direction shown by arrow **2**.





Figure 7. Removal steps of keyboard (continued)

Lift the keyboard a little 3, and then detach the connector in the direction shown by arrow 4.



When installing: Make sure that the FPC connector is attached firmly.

1080 System board

Important notices for handling the system board:

When handling the system board, bear the following in mind.


- Be careful not to drop the system board on a bench top that has a hard surface, such as metal, wood, or composite.
- Avoid rough handling of any kind.
- In the whole process, make sure not to drop or stack the system board.
- If you put a system board down, make sure to put it only on a padded surface such as an ESD mat or conductive corrugated material.

For access, remove these FRUs in order:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43

Figure 8. Removal steps of system board

Remove six screws 1 on the system board, two screws 1 on the IO board and single screw 2 on the fan. Detach the power board connector in the direction shown by arrows 5 6 , unplug the speaker connector in the direction shown by arrow 7 , system board power connector in the direction shown by arrow 3 , two LCD connectors in the direction shown by arrows 3 4.



When installing: Make sure that all the connectors are attached firmly.

Step	Screw (quantity)	Color	Torque
1	M2 X 3 mm, flat-head, nylok-coated (2)	Silver	1.5 kgfcm
1	$M2 \times 2.5$ mm, flat-head, nylok-coated (6)	Black	1.5 kgfcm
1	$M2 \times 2.5$ mm, flat-head, nylok-coated (1)	Black	1.5 kgfcm




Figure 8. Removal steps of system board (continued) Remove the system board in the direction shown by arrow **[9**].

When installing: When attaching the system board to the base cover, adjust the placement of the USB, HDMI, Power jacks as shown in **a b c**, and make sure that they are attached to the holes on the base cover as shown. Improper placement of those jacks might cause a damage.


1090 LCD unit

For access, remove these FRUs in order:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43
- "1080 System board" on page 45

Figure 9. Removal steps of LCD unit


Remove four screws 1.




Step)	Screw (quantity)	Color	Torque
1		$M2\times3.5$ mm, flat-head, nylok-coated (4)	Silver	1.5 kgfcm

When installing:

- Route the antenna cables along the cable guides. As you route the cables, make sure that they are not subjected to any tension. Tension could cause the cables to be damaged by the cable guides, or a wire to be broken.
- Make sure that the LCD connector is attached firmly and make sure that you do not pinch the antenna cables when you attach the LCD assembly. Route the LCD cable along the cable guides.





1100 Fan assembly and Heat Sink assembly

For access, remove these FRUs in order:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43
- "1080 System board" on page 45


Figure 10. Removal steps of fan assembly and heat sink assembly

Detach the fan connector in the direction shown by arrow **1**.




When installing: Make sure that the fan connector is attached firmly to the system board.

Remove four screws 2 and single screw 3.



Step	Screw (quantity)	Color	Torque
2	$M2 \times 2.5$ mm, flat-head, nylok-coated (4)	Black	1.5 kgfcm
2	$M2 \times 2.5$ mm, flat-head, nylok-coated (1)	Black	1.5 kgfcm

Lift the fan assembly and heat sink assembly in the direction shown by arrow **4**. Be careful not to damage the connector.




1110 Base cover, speakers and power assembly

For access, remove these FRUs in order:


- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43
- "1080 System board" on page 45
- "1090 LCD unit" on page 48
- "1100 Fan assembly and Heat Sink assembly" on page 50

Figure 11. Removal steps of base cover, speakers and power assembly

Remove screw 1. Lift the power assembly in the direction shown by arrow 2.



Step	Screw (quantity)	Color	Torque
1	$M2 \times 3$ mm, flat-head, nylok-coated (1)	Silver	1.5 kgfcm



Remove four screws 3, and then remove the speakers in the direction shown by arrows 4.

Step	Screw (quantity)	Color	Torque
2	$M2 \times 3$ mm, flat-head, nylok-coated (4)	Silver	1.5 kgfcm

Note: Applying labels to the base cover

The new base cover FRU is shipped with a kit containing labels of several kinds. When you replace the base cover, you need to apply the following label:

The following labels need to be peeled off from the old base cover, and need to be put on the new base cover.


- a CPU Label
- b e-Standby Label (KOR)
- C Rating Label
- d COA Label
- e 3G Label

i

- f Malaysia WLAN Label
- g Israel WLAN Label
- h Brazil WLAN Label
 - WLAN Label for CA/US/TW/Indonesia/Israel
- j KCC Label

For some models, you also need to apply one or two FCC labels. Check the old base cover; if it has one or two FCC labels, find duplicates of them in the label kit and apply them to the new base cover.

For the location of each label, refer to the following figure:




1120 LCD front bezel

For access, remove these FRUs in order:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43
- "1080 System board" on page 45
- "1090 LCD unit" on page 48
- "1100 Fan assembly and Heat Sink assembly" on page 50
- "1110 Base cover, speakers and power assembly" on page 52

Figure 12. Removal steps of LCD front bezel

Remove the LCD front bezel in the direction shown by arrows 1.




1130 LCD panel, LCD cable and hinges

For access, remove these FRUs in order:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43
- "1080 System board" on page 45
- "1090 LCD unit" on page 48
- "1100 Fan assembly and Heat Sink assembly" on page 50
- "1110 Base cover, speakers and power assembly" on page 52
- "1120 LCD front bezel" on page 55


Figure 13. Removal steps of LCD panel, LCD cable and hinges

Remove four screws **2** , disconnect the connector in the direction shown by arrow **1** .



Step	Screw (quantity)	Color	Torque
1	$M2 \times 3.5$ mm, flat-head, nylok-coated (4)	Silver	1.5 kgfcm


Disconnect the connector 3, lift the LCD panel in the direction shown by arrow 4.



When installing: Make sure that the connector is attached firmly.

Figure 13. Removal steps of LCD panel, LCD cable and hinges

Remove eight screws **5** and the hinges in the direction shown by arrows **6**.



Step	Screw (quantity)	Color	Torque
3	$M2 \times 3.5$ mm, flat-head, nylokcoated (8)	Silver	1.5 kgfcm

Note: The LCD cables are attached to the LCD panel by a metal connector.


1140 Integrated camera

For access, remove these FRUs in order:

- "1010 Battery pack" on page 34
- "1030 Hard disk drive" on page 37
- "1040 DIMM" on page 39
- "1050 PCI Express Mini Card for wireless LAN/WAN" on page 40
- "1060 3G Card" on page 42
- "1070 Keyboard" on page 43
- "1080 System board" on page 45
- "1090 LCD unit" on page 48
- "1100 Fan assembly and Heat Sink assembly" on page 50
- "1110 Base cover, speakers and power assembly" on page 52
- "1120 LCD front bezel" on page 55
- "1130 LCD panel, LCD cable and hinges" on page 56

Figure 14. Removal steps of integrated camera

Note: The integrated camera is stuck on the top center of the LCD cover. Remove the integrated camera from the LCD cover





When installing: Stick the integrated camera to the top center of the LCD cover and ajust the placement of it to make sure the connector is attached firmly.

Locations

Front view


- 1 Integrated camera (On select models)
- 2 Wireless module antennas (On select models)
- 3 Computer display
- 4 Power button
- 5 Fan louvers
- 6 Touchpad





Bottom and Left-side view

- 1 Louvers
- 2 Speakers
- 3 System status indicators
- 4 AC power adapter jack
- 5 HDMI port
- 6 USB 3.0 port
- 7 Combo audio jack
- 8 SIM card slot (on select models)
- 9 Built-in microphone




Parts list

This section presents the following service parts:

- "Overall" on page 63
- "LCD FRUs" on page 67
- "Keyboard" on page 69
- "Miscellaneous parts" on page 73
- "AC adapters" on page 74
- "Power cords" on page 75

Notes:

• Each FRU is available for all types or models, unless specific types or models are specified.



|--|

No.	FRU	FRU no.	CRU ID	
1	LCD unit (see "LCD FRUs" on page 67.)			
2	Keyboard (see "Keyboard" on page 69.)			
3	WOODY IO BD (ASSY S200)	90200285	N	
3	WOODY IO BD (S206)	90200285	Ν	
4	WINNIE Upper Case Black (Ccover_Grey S200)	90200250	N	
4	WINNIE Upper Case Black (S206)	90200250	N	
5	WINNIE MB N2800 (MB N2800 Group S200)	90000090	N	
5	WINNIE MB N2600 (MB N2600 Group S200)	9000089	N	
5	WOODY MB C50 WO/WWAN (S206)	90000094	N	
5	WOODY MB C60 WO/WWAN (S206)	9000093	N	
6	3G, WCDMA, Ericsson, Ericsson F5321gw HSPA +	20200034	N	
	Qual-bands WWAN card			
6	3G, WCDMA, Huawei, Huawei EM820w HSPA + 850/ 900/1900/2100MHz	11012850	N	
6	3G, EVDO, Huawei, Huawei EM660 EVDO + GPS WWAN card	11012299	N	
6	3G, EVDO, Sierra wireless, Sierra MC8355 GOBI3000 dualmode WWAN card	20200163	N	
6	3G, TD-SCDMA, TengChuang, Leadcoretech TD-SCDMA LC5740 mini-card	11012849	N	
6	3G, AT&T LTE, Sierra wireless, Sierra MC7700 AT&T LTE module	20200164	N	
7	WLAN card, WiFi 1x2 BGN + WiMAX, Intel 6150NX MOW M PCIE NB HMC WLAN card (LI) (S200 only)	20002484	N	
7	WLAN card, WiFi 1x2 BGN + WiMAX, Intel 6150NX BSB M PCIE NB HMC WLAN card (LI) (S200 only)	20002543	N	
7	WLAN card, WiFi 1x2 BGN, Intel 1000N MOW M PCIE NB HMC WLAN card (S200 only)	20002329	N	
7	WLAN card, WiFi 2x2 BGN, Intel 2200N MOW M PCIE NB HMC WLAN card (S200 only)	20200048	N	
7	WLAN card, WiFi 1x1, BGN, CyberTan, Cbt RT3090 MOW M PCIE NB HMC WLAN card	20002515	N	
7	WLAN card, WiFi 1x1, BGN, Liteon AR9285 HB95 BGN MOW NB WLAN card-IN	20002357	N	
7	WLAN card, WiFi 1x1 BGN + BT4.0, CyberTan, Cbt BCM4313HMGB BGN + BT HMC WLAN card	20002501	**	
7	WLAN card, WiFi 1x1 BGN + BT 3.0, Liteon, Liteon WB195 BGN + BT HMC WLAN card		**	
8	WINNIE Thernal Module W/Fan (S206)	90200261	**	
8(1)	WINNIE THM Fan (S200)	90200283	**	
8(1)	WINNIE HeatSink (S200)	90200284	**	
9(1)	Chipset, Cedar Trail, Intel, Intel Tiger Point 82NM10 B0 (S200)	1007357	**	
9(1)	Chipset, Brazos, AMD, AMD A50M FCH (S206)	1007341	**	
9	Intel N2600 1.6G B2 3.5W 2cBGA processor (S200)	102500105	**	

Table 4. F	Parts list—	-Overall	(continued)
------------	-------------	----------	-------------

No.	FRU	FRU no.	CRU ID	
9	Intel N2800 1.86G B2 6.5W 2cBGA processor (S200)	102500106	**	
9	Intel N2100 1.6G B2 3W 1cBGA ES processor (S200)	TBD	**	
9	AMD C60 1.3G/1.0G 1M 2C C0 BGA CPU (S206)	102500084	**	
9	AMD C50 1.0G 1M 2C B0 BGA CPU (S206)	102001132	**	
10	WINNIE Lower Case Grey (Dcover_Grey S200)	90200252	**	
10	WINNIE Lower Case Grey (S206)	90200252	**	
11	Battery, 2S1P, 2cell, 3740mAh, 27Wh, SMP, S200 SMP/ATL	121500057	**	
	L11M2P01 2S1P 27Wh bty			
11	Battery, 2S1P, 2cell, 3600mAh, 27Wh, Sanyo, S200 Sanyo	121500061	**	
	L11S2P01 2S1P 27Wh bty			
12	Hard disk drive, 320G 5400rpm, HGST HTS545032A7E380	16200068	*	
	5400PRM7mm 320G HDD			
12	Hard disk drive, 320G 5400rpm, HGST HTS543232A7A384	16005024	*	
	5.4K RPM 320G HDD			
12	Hard disk drive, 320G 5400rpm,Seagate ST320LT020	16005211	*	
	5400RPM 7MM 320G HDD			
12	Hard disk drive, 500G 5400rpm,HGST HTS545050A7E380	16200067	*	
10	5400PRM7mm 500G HDD	1 (200104	*	
12	Hard disk drive, 320G 7200rpm,HTS725032A7E630 7.2K	16200194	*	
12	rpm 7mm 320G HDD Hard disk drive, 320G 7200rpm,Seagate ST320LT007	1(005020	*	
12	7200RPM 7MM 320G HDD	16005030	`	
12	Hard disk drive, 500G 7200rpm,HTS725050A7E630 7.2k	16200195	*	
12	RPM 7MM 500G HDD	10200195		
12	Hard disk drive, 32G SSD, Samsung, PM830 32G mSATA	16200108	*	
12	SSD	10200100		
12	Hard disk drive, 32G SSD, Sandisk, mSATA X100 32G	16200162	*	
13	WINNIE Speaker W/Cable (ASSY S200)	90200280	**	
13	WINNIE Speaker W/Cable (S206)	90200280	**	
14	DDR3 1600 2GB, Hynix, HMT325S6CFR8C-PB DDR3 1600	11200343	**	
	2GB			
14	DDR3 1600 2GB, Micron, MT8KTF25664HZ-1G6M1 DDR3	11200346	**	
	1600 2GB			
14	DDR3 1600 2GB, Ramaxel, RMT3150ED58E8W-1600 DDR3	11200392	**	
	1600 2GB			
14	DDR3 1600 2GB, Sharetronic (Micron), SM321NH08IAF	11200396	**	
	DDR3 1600 2GB			
14	DDR3 1600 2GB, Samsung, M471B5773DH0-CK0 DDR3	11200340	**	
	1600 2GB			
14	DDR3 1600 4GB, Samsung, M471B5273DH0-CK0 DDR3	11200341	**	
	1600 4GB			
14	DDR3 1600 4GB, Micron, MT16KTF51264HZ-1G6M1 DDR3	11200347	**	
	1600 4GB			
14	DDR3 1600 4GB, Hynix, HMT351S6CFR8C-PB DDR3 1600	11200344	**	
	4GB			


No.	FRU	FRU no.	CRU ID
14	DDR3 1600 4GB, Ramaxel, RMT3160ED58E9W-1600 DDR3 1600 4GB	11200393	**
14	DDR3 1600 4GB, Sharetronic (Micron), SM322NQ08IAF DDR3 1600 4GB	11200397	**
15	Touchpad, 55*90, Synaptics, TM-02042-001	73040641	*
15	Touchpad, 55*90, Cypress, CYTRA-104008-00	73040625	*
15	WINNIE TP Module (ASSY S200)	90200265	*
15	WINNIE TP Module (S206)	90200265	*
15(1)	WINNIE TouchPad Button Board (ASSY S200)	90200311	*
15(1)	WINNIE TouchPad Button Board (S206)	90200311	*
15(1)	WINNIE TP PMMA (S200)	90200281	*
15(1)	WINNIE TP PMMA (S206)	90200281	*

Table 4. Parts list—Overall (continued)

LCD FRUs

In Lenovo IdeaPad S200/S206, there are following types of LCDs.

• "17.3 -in. HD TFT"



17.3-in. HD TFT

Table 5. Parts list-17.3-in. HD TFT

No.	FRU	FRU no.	CRU ID
1	WINNIE LCD Bezle Grey (Bcover_Grey S200)	90200260	Ν
1	WOODY LCD Bezle Black (S206)	90200299	Ν
2	Panel, 11.6 Flat, AUO, AUO B116XW03 V0 HD G F LED1 NB LCD	18200146	N
2	Panel, 11.6 Flat, CMI, CMI N116BGE-L42 HD G F LED1 NB LCD	18200147	N
2	Panel, 11.6 Flat, SEC, SEC LTN116AT06 L02 HD G F LED1 NB LCD	18200148	N
2	Panel, 11.6 Flat, IVO, IVO M116NWR1 R4 HD G F LED1 NB LCD	18200149	N
3	WINNIE Camera Board 0.3M (CAM 0.3M S200)	90200279	Ν
3	WINNIE Camera Board 0.3M (S206)	90200279	Ν
4	WINNIE LCD Cover Grey (Acover_Grey S200)	90200256	Ν
4	WINNIE LCD Cover Grey (S206)	90200256	Ν
5	WINNIE LCD Hinge Cover (ASSY S200)	90200264	Ν
5	WINNIE LCD Hinge Cover (S206)	90200264	Ν
6	WINNIE LCD Hinge L (ASSY S200)	90200262	Ν
6	WINNIE LCD Hinge L (S206)	90200262	Ν
7	WINNIE LCD Hinge R (ASSY S200)	90200263	Ν
7	WINNIE LCD Hinge R (S206)	90200263	Ν
8	WINNIE Camera LED Sponge (ASSY S200)	90200278	Ν
8	WINNIE Camera LED Sponge (S206)	90200278	Ν
9	WINNIE LVDS Cable (ASSY S200)	90200266	Ν
9	WINNIE LVDS Cable (S206)	90200266	Ν

Keyboard

Table 6. Parts list—Keyboard

Language			P/N	CR ID
		Bulgarian	25201724	**
		Czechoslovakian	25201723	
		International English	25201722	
		Swiss	25201721	-
		Slovenian	25201720	
		Icelandic	25201719	-
		Belgian	25201718	-
		Four Nordic countries	25201717	
		Hungarian	25201716	
		Hebrew	25201715	
		Greek	25201714	
		Dutch	25201713	
		Japanese	25201712	-
	Sunrex	Brazilian	25201711	
	(black)	Arabic	25201710	
	(black)	German	25201709	-
		French	25201708	-
		Russian	25201707	-
		Traditional Chinese	25201706	-
		Korean	25201705	
		Canadian English&French	25201704	
		Latin	25201703	
S200/S206		Portuguese	25201702	
		Thai	25201701	-
		Turkish	25201700	-
		Spanish	25201699	
		Italian	25201698	-
		U.K. English	25201697	-
		English	25201696	-
		Bulgarian	25201754	-
		Czechoslovakian	25201753	-
		International English	25201752	-
		Swiss	25201751	-
		Slovenian	25201750	
		Icelandic	25201749	
		Belgian	25201748	
	Sunrex	Four Nordic countries	25201747	
	(white)	Hungarian	25201746	
	ĺ	Hebrew	25201745	-
		Greek	25201744	-
		Dutch	25201743	-
		Japanese	25201742	-
		Brazilian	25201741	-
		Arabic	25201740	-
		German	25201739	-

Language			P/N	CRU ID
		French	25201738	**
		Russian	25201737	
		Traditional Chinese	25201736	1
		Korean	25201735	
		Canadian English&French	25201734	
	Sunrex	Latin	25201733	
	(white)	Portuguese	25201732	
	(continued)	Thai	25201731	
		Turkish	25201730	
		Spanish	25201729	
		Italian	25201728	
		U.K. English	25201727	
		English	25201726	
		Bulgarian	25201664	
		Czechoslovakian	25201663	
		International English	25201662	
		Swiss	25201661	-
		Slovenian	25201660	
		Icelandic	25201659	
		Belgian	25201658	
S200/S206		Four Nordic countries	25201657	
(continued)		Hungarian	25201656	
		Hebrew	25201655	-
		Greek	25201654	
		Dutch	25201653	-
		Japanese	25201652	-
	C1 ·	Brazilian	25201651	-
	Chicony	Arabic	25201650	-
	(black)	German	25201649	_
		French	25201648	
		Russian	25201647	-
		Traditional Chinese	25201646	_
		Korean	25201645	-
		Canadian English&French	25201644	
		Latin	25201643	
		Portuguese	25201642	
		Thai	25201641	
		Turkish	25201640	-
		Spanish	25201639	
		Italian	25201638	-
		U.K. English	25201637	-
		English	25201636	-

Table 6. Parts list—Keyboard (continued)

Language			P/N	CRU ID
		Bulgarian	25201694	**
		Czechoslovakian	25201693	
		International English	25201692	
		Swiss	25201691	
		Slovenian	25201690	_
		Icelandic	25201689	
		Belgian	25201688	_
		Four Nordic countries	25201687	_
		Hungarian	25201686	_
		Hebrew	25201685	_
		Greek	25201684	_
		Dutch	25201683	_
		Japanese	25201682	_
	<i></i>	Brazilian	25201681	
	Chicony	Arabic	25201680	
	(white)	German	25201679	_
		French	25201678	_
		Russian	25201677	_
		Traditional Chinese	25201676	_
		Korean	25201675	-
		Canadian English&French	25201674	_
		Latin	25201673	-
S200/S206		Portuguese	25201672	-
(continued)		Thai	25201671	-
		Turkish	25201670	_
		Spanish	25201669	_
		Italian	25201668	_
		U.K. English	25201667	_
		English	25201666	-
		Bulgarian	25201784	-
		Czechoslovakian	25201783	-
		International English	25201782	-
		Swiss	25201781	-
		Slovenian	25201780	-
		Icelandic	25201700	-
	Dafon (black)	Belgian	25201779	-
		Four Nordic countries	25201777	-
		Hungarian	25201777	-
		Hebrew	25201775	-
		Greek	25201773	-
		Dutch	25201774	-
		Japanese	25201773	-
		Brazilian	25201772	-
		Arabic	25201771	-
		German	25201770	-
		Gennan	23201709	

Table 6. Parts list—Keyboard (continued)

Language			P/N	CRU ID
		French	25201768	**
		Russian	25201767	
		Traditional Chinese	25201766	
		Korean	25201765	1
		Canadian English&French	25201764	
	Dafon	Latin	25201763	
	(black)	Portuguese	25201762	
	(continued)	Thai	25201761	
		Turkish	25201760	
		Spanish	25201759	
		Italian	25201758	
		U.K. English	25201757	
		English	25201756	
		Bulgarian	25201814	
		Czechoslovakian	25201813	
		International English	25201812	
		Swiss	25201811	
		Slovenian	25201810	-
		Icelandic	25201809	
		Belgian	25201808	
S200/S206		Four Nordic countries	25201807	
(continued)		Hungarian	25201806	
		Hebrew	25201805	
		Greek	25201804	
		Dutch	25201803	
		Japanese	25201802	
	Dafon	Brazilian	25201801	
		Arabic	25201800	
	(white)	German	25201799	
		French	25201798	
		Russian	25201797	
		Traditional Chinese	25201796	
		Korean	25201795	
		Canadian English&French	25201794	-
		Latin	25201793	
		Portuguese	25201792	
		Thai	25201791	
		Turkish	25201790	
		Spanish	25201789	
		Italian	25201788	-
		U.K. English	25201787	-
		English	25201786	-

Table 6. Parts list—Keyboard (continued)

Miscellaneous parts

Table 7. Parts list—Miscellaneous parts

FRU	P/N	CRU ID
System miscellaneous parts:		Ν
 (a) WINNIE DIMM Gasket (ASSY S200) 	90200287	
• (a) WINNIE DIMM Gasket (S206)	90200287	
• (b) WOODY CPU THM PAD	90200312	
• (c) WINNIE CPU THM PAD (ASSY S200)	90200282	
 (d) WINNIE HDD Bracket (ASSY S200) 	90200267	
• (d) WINNIE HDD Bracket (S206)	90200267	
 (e) WINNIE TP Battery Sponge (ASSY S200) 	90200277	
(e) WINNIE TP Battery Sponge (S206)	90200277	
 (f) WINNIE HDD Sponge (ASSY S200) 	90200271	
• (f) WINNIE HDD Sponge (S206)	90200271	
• (g) WOODY LED BD (ASSY S200)	90200286	
• (g) WOODY LED BD (S206)	90200286	
Cable miscellaneous parts:		N
• (h) WINNIE IO BD Cable (ASSY S200)	90200269	
• (h) WINNIE IO BD Cable (S206)	90200269	
• (i) WINNIE LED BD Cable (ASSY S200)	90200270	
• (i) WINNIE LED BD Cable (S206)	90200270	
• (j) WINNIE TP Cable (ASSY S200)	90200268	
• (j) WINNIE TP Cable (S206)	90200268	
Note: Italicized letters in parentheses are references to the exploded view in "Overall" on page 71.		

AC adapters

Table 8. Parts list—3-pin AC adapters

FRU	P/N	CRU ID
40W, Brazil PA-1400-12LB adapter (Only Brazil local buy)	36001715	Ν
40W, Delta ADP-40NH B20V2A adapter	36001648	Ν
40W, Liteon PA-1400-12LC 20V2A adapter	36001653	Ν
40W, HIPRO LN-A0403A3C 20V2A adapter	36001672	Ν

Power cords

A Lenovo power cord for a specific country or region is usually available only in that country or region:

Table 9. Parts list—3-pin power cords

Region	P/N	CRU ID
CCC	145000600	*
 LINETEK PC323+RVV300/300+LS15 1m 		
Argentina	145000599	
 LINETEK LS15+H03VV-F+LP39 1m 		
Danmark	145000598	
 LINETEK LS15+H03VV-F+LP-38 1m 		
Switzerland	145000597	
 LINETEK LS15+H03VV-F+LP-37 1m 		
Brazil	145000596	
 LINETEK LS15 H03VV-F LP26A 1m 		
Israel	145000595	
 LINETEK LS15+H03VV-F+LP-41 1m 		
UL	145000594	
 LINETEK LP-30B + SPT-2 + LS15 1m 		
UK	145000593	
 LINETEK LP-61L+ H03VV-F+ LS15 1m 		
Indian	145000592	-
 LINETEK PE-361+ H05VV-F+ LS15 1m 		
Italy	145000591	-
 LINETEK LS15+H03VV-F+PE-336 1m 		
Korea	145000590	-
 LINETEK LS15+H05VV-F+LP-E04A 1m 		
Australia	145000589	-
 LINETEK LS15+H03VV-F+LP-23A 1m 		
Taiwan	145000588	-
 LINETEK LS15+VCTF+LP-53 1m 		
Japan	145000587	-
• LINETEK LS15+VCTF+LP-54 1m		
Africa	145000586	-
 LINETEK LS15+H03VV-F+PE-364 1m 		
CE	145000585	-
 LINETEK LP-34+H03VV-F + LS15 1m 		
CCC	145000568	-
• Longwell LSG-31+RVV300/300+LS-18 1m		
Argentina	145000567	-
 Longwell LP-24+H03VV-F+LS-18 1m 	11000000	
Danmark	145000566	-
Longwell LP-40+H03VV-F+LS-18 1m	145000500	
Switzerland	145000565	-
 Longwell LP-37+H03VV-F+LS-18 1m 	145000505	

Region	P/N	CRU ID
Brazil	145000564	*
 Longwell LP-46+H03VV-F+LS-18 1m 		
Israel	145000563	
 Longwell LP-41+H03VV-F+LS-18 1m 		
UL	145000562	
Longwell LP-30B+SPT-2 18AWG+LS-18 1m		-
UK	145000561	
Longwell LP-61L+H03VV-F+LS-18 1m Indian	145000560	-
Longwell LP-67+BIS+LS-18 1m	143000360	
Italy	145000559	-
 Longwell LP-22+H03VV-F+LS-18 1m 	145000555	
Korea	145000558	-
Longwell LP-486+KTLH03VV-F+LS-5 1m	110000000	
Australia	145000557	
• Longwell LP-23A+LFC-3R+LS-18 1m		
Taiwan	145000556	
 Longwell LP-71+VCTF+LS-33 1m 		
Japan	145000555	1
 Longwell LP-54+VCTF+LS-18 1m 		
Africa	145000554	
 Longwell LP-39+H03VV-F+LS-18 1m 		
CE	145000553	
Longwell LP-34A+H03VV-F+LS-18 1m		_
CCC	145000538	
VOLEX GB10S3+RVV 300/500+VAC5S 1m	145000525	-
UL	145000537	
Volex US15S3+SPT-2 +VAC5S 1m Indian	145000536	-
VOLEX IA6A3+IS694+VAC5S 1m	143000336	
Italy	145000535	-
VOLEX IT10S3+HO3VV-F+VAC5S 1m	110000000	
Danmark	145000534	
 VOLEX MP233D+H03VV-F+VAC5S 1m 		
Korea	145000533	
 VOLEX M2511+KETI IEC+VAC5S 1m 		
Australia	145000532	
 VOLEX AU10S3+H03VV-F+VAC5S 1m 		
Taiwan	145000531	1
 VOLEX TW15CS3+VCTF+VAC5S 1m 		
Japan	145000530	
 VOLEX VAC5S+VCTF+M755 1m 		
Argentina	145000528	
 VOLEX VA2073+H03VV-F+VAC5S 1m 		

Table 9. Parts list—3-pin power cords (continued)

Region	P/N	CRU ID
Brazil	145000527	*
 VOLEX CH10S3+H03VV-F+VAC5S 1m 		*
Israel	145000526	
 VOLEX SI16S3+H03VV-F+VAC5S 1m 		
CE	145000525	
 VOLEX M2511+HO3VV-F+VAC5S 1m 		
Switzerland	145000524	
 VOLEX MP232+H03VV-F+VAC5S 1m 		
UK	145000605	
 VOLEX MP5004+H03VV-F+VAC5S 1m 		

Table 9. Parts list—3-pin power cords (continued)

Notices

Lenovo may not offer the products, services, or features discussed in this document in all countries. Consult your local Lenovo representative for information on the products and services currently available in your area. Any reference to a Lenovo product, program, or service is not intended to state or imply that only that Lenovo product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any Lenovo intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any other product, program, or service.

Lenovo may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents.

LENOVO GROUP LTD. PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. Lenovo may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

The products described in this document are not intended for use in implantation or other life support applications where malfunction may result in injury or death to persons. The information contained in this document does not affect or change Lenovo product specifications or warranties. Nothing in this document shall operate as an express or implied license or indemnity under the intellectual property rights of Lenovo or third parties. All information contained in this document was obtained in specific environments and is presented as an illustration. The result obtained in other operating environments may vary.

Lenovo may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any references in this publication to non-Lenovo Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this Lenovo product, and use of those Web sites is at your own risk. Any performance data contained herein was determined in a controlled environment. Therefore, the result obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Trademarks

The following terms are either registered trademarks or trademarks of Lenovo in the United States and/or other countries:

Lenovo[®] Lenovo logo[®] IdeaPad[®] VeriFace[®] OneKey Rescue[®] (OneKey Recovery, OneKey Antivirus) APS[®] Power Express[®] Energy Management and ReadyComm[®]

The following terms are trademarks of Microsoft Corporation in the United States, other countries, or both:

Windows[®] Windows[®] 7

The following are trademarks of Intel Corporation or its subsidiaries in the United States, other countries, or both: ${\rm Intel}^{\textcircled{0}}$

Intel[®]CoreTM 2 Duo

The following is a trademark of Advanced Micro Devices, Inc. $\mathrm{AMD}^{\textcircled{B}}$

Other company, product, or service names may be the trademarks or service marks of others.