



# CLK Cabriolet Operator's Manual

CLK 320 CLK 430 Our company and staff congratulate you on the purchase of your new Mercedes-Benz.

Your selection of our product is a demonstration of your trust in our company name. Further, it exemplifies your desire to own an automobile that will be as easy as possible to operate and provide years of service.

Your Mercedes-Benz represents the efforts of many skilled engineers and craftsmen. To ensure your pleasure of ownership, and for your safety and that of your passengers, we ask you to make a small investment of your time:

- Please read this manual carefully before putting it aside. Then return it to your vehicle where it will be handy for your reference.
- Please abide by the recommendations contained in this manual. They are designed to acquaint you with the
  operation of your Mercedes-Benz.
- Please abide by the warnings and cautions contained in this manual. They are designed to help improve the safety of the vehicle operator and occupants.

We extend our best wishes for many miles of safe, pleasurable driving.

DaimlerChrysler AG

#### BabySmart<sup>TM</sup> airbag Introduction deactivation system ......64 Mechanical keys ...... 33 Self-test BabySmart<sup>TM</sup> without Operator's manual ......8 special child seat installed .......64 Central locking switch ...... 36 Supplemental restraint Automatic central locking ....... 37 Reporting Safety Defects ...... 15 system (SRS) ......65 Emergency unlocking Emergency tensioning in case of accident .......37 Instruments and controls retractor (ETR) ......65 Trunk ...... 38 Airbags ......66 Instruments and controls ...... 18 Safety guidelines for the Trunk lid emergency release .......41 Center console ......20 seat belt, emergency Antitheft alarm system ...... 42 Overhead control panel ......21 tensioning retractor Tow-away alarm ......44 and airbag ......72 Operation Power seats, front ...... 45 Infant and child Front head restraints ......51 restraint systems .......74 Vehicle keys ......24 Roll bar and Adjusting telescoping Start lock-out ......27 head restraints, rear ......52 General notes on the Backrest ...... 54 central locking system ......27 Multicontour seat ...... 55 Antiglare night position ......77 Central locking system ......28 Heated seats ......56 Radio frequency and infrared Seat belts and integrated Instrument cluster ......82 remote control ......28 restraint system ...... 58 Indicator lamps in the Opening and closing Seat belts ...... 58 instrument cluster ......84 windows from outside ......32 Seat belt nonusage Multifunction steering wheel,

warning system ...... 59

multifunction display ......88

Contents

Trip and main odometer,	Engine oil consumption113	Interior lighting149
vehicle speed, FSS and	Exterior lamp switch114	Sun visors150
engine oil level indicator92	Night security illumination 115	Illuminated vanity mirrors 150
Audio systems93	Headlamp cleaning system 116	Interior 15
Radio93	Combination switch117	Storage compartments,
CD player94	Hazard warning flasher	armrest and cup holder 15
Cassette player95	switch119	Glove box152
Telephone96	Automatic climate control 120	Ashtray 154
Telephone book96	Display and controls 122	Lighter155
Redialing98	Basic setting 122	Cargo tie down rings150
Incoming call100	Economy 123	Parcel net in front
Navigation system 101	Special settings 123	passenger footwell150
Trip computer 102	Rear window defroster 124	Armrest, rear bench150
Malfunction message	Air recirculation125	Telephone, general157
memory104	Residual engine	Cellular telephone157
Individual settings106	heat utilization 125	Garage door opener158
Setting the audio volume 108	Dust filter 126	Soft top162
Flexible service system	Audio and telephone,	Wind screen 170
(FSS)109	operation 127	
Engine oil level indicator 112	Power windows 146	

# **Driving**

Control and operation of	
radio transmitters1	78
The first 1 000 miles	
(1 500 km)1	79
Maintenance1	79
Catalytic converter1	80
Emission control 1	81
Tele Aid1	82
Steering lock1	92
Starting and turning off	
the engine1	94
Automatic transmission1	95
Parking brake2	04
Driving instructions2	05
Drive sensibly - save fuel2	05
Drinking and driving2	05
Pedals2	05
Power assistance	06

Brakes206	In
Driving off207	
Parking207	Ma
Tires208	
Snow chains210	
Winter driving instructions 211	,
Deep water212	·
Passenger compartment213	,
Traveling abroad213	
ruise control214	
rake assist system	j
(BAS)216	,
antilock brake system	]
(ABS)218	
lectronic stability program	
(ESP)220	
Vhat you should know	j
at the gas station224	
check regularly and	j
before a long trip226	,

# **Instrument cluster display**

alfunction and	
indicator lamps in the	
instrument cluster	.228
On-board diagnostic system	
Check engine malfunction	
indicator lamp	.228
Brake warning lamp	
Supplemental restraint	
system (SRS)	
indicator lamp	.230
Fuel reserve and fuel cap	
placement warning	.230
Electronic stability program	
(ESP) – warning lamp	.231
BAS/ESP malfunction	
indicator lamp	. 231
ABS malfunction	
indicator lamp	. 231
Telescoping steering column -	
indicator lamp	.232
Seat helt warning lamp	

Contents

Contents

Malfunction and indicator	
lamps in the	
center console23	33
AIRBAG OFF	
indicator lamp23	33
Roll bar warning lamp23	3
Malfunction and	
warning messages in the	
multifunction display23	34
DISPLAY DEFECTIVE	
(engine control unit)23	35
DISPLAY DEFECTIVE	
(several systems)23	35
BATTERY/ALTERNATOR23	36
ABS-SYSTEM23	37
BRAKE ASSIST23	37
BRAKE LINING WEAR23	88
BRAKE FLUID23	88

PARKING BRAKE	239
ENGINE FAN	239
COOLANT	
(coolant level)	240
COOLANT TEMP.	
(coolant temperature)	241
LIGHTING SYSTEM	242
LIGHT SENSOR	243
STEER. WHEEL ADJUST	243
ENGINE OIL LEVEL	244
ELEC. STABIL. PROG.	
(Electronic stability	
program)	
REMOVE KEY	245
WASHER FLUID	246
TELE AID	247

# 9 Practical hints

First aid kit	250
Shelf below rear window	250
Stowing things in	
the vehicle	250
Luggage cover	250
Fuses	
Hood	254
Checking engine oil level	256
Automatic transmission	
fluid level	257
Coolant level	257
Adding coolant	.258
Windshield washer / headlamp	
cleaning system	259
Windshield and headlamp	
washer fluid mixing ratio	259

Spare wheel, vehicle tools,	
storage compartment	.260
Vehicle jack	. 261
Wheels	.262
Tire replacement	.262
Rotating wheels	.263
Spare wheel	.264
Changing wheels	.266
Tire inflation pressure	
Battery	.272
Jump starting	.274
Towing the vehicle	. 276
Exterior lamps	
Headlamp assembly	.281
Taillamp assemblies	.283
Adjusting headlamp aim	.285
Changing batteries in	
the electronic main key	.288
Synchronizing	
remote control	.290

Raising soft top manually 291
Antenna298
Manual release for
fuel filler flap298
Trunk lamp299
Replacing wiper
blade insert299
Vehicle care
Cleaning and care
of the vehicle302
Power washer 303
Paintwork, painted body
components303
Engine cleaning304
Tar stains304
Vehicle washing304
Ornamental moldings304
Headlamps, taillamps,
turn signal lenses305

Window cleaning	305
Plastic and rubber parts	
Wiper blade	
Light alloy wheels	
Instrument cluster	306
Steering wheel and	
gear selector lever	306
Cup holder	
Seat belts	
Headliner	
Upholstery	
Hard plastic trim items	307
Plastic and rubber parts	
Wind screen	
Rubber weatherstrip	
Soft top	

Contents 5

Technical data	Engine oil additives319	Index
	Air conditioner	
Spare parts service 310	refrigerant319	Index325
Warranty coverage310	Brake fluid319	
Identification labels 311	Premium unleaded	
Layout of poly-V-belt drive 312	gasoline320	
Technical data313	Fuel requirements320	
Fuels, coolants, lubricants etc	Gasoline additives321	
capacities317	Coolants321	
Engine oils	Consumer information323	

#### **Product information**

Kindly observe the following in your own best interest:

We recommend using Mercedes-Benz original parts as well as conversion parts and accessories explicitly approved by us for your vehicle model.

We have tested these parts to determine their reliability, safety and their special suitability for Mercedes-Benz vehicles.

We are unable to make an assessment for other products and therefore cannot be held responsible for them, even if in individual cases an official approval or authorization by governmental or other agencies should exist. Use of such parts and accessories could adversely affect the safety, performance or reliability of your vehicle. Please do not use them.

Mercedes-Benz original parts as well as conversion parts and accessories approved by us are available at your authorized Mercedes-Benz Center where you will receive comprehensive information, also on permissible technical modifications, and where proper installation will be performed.

Introduction 7

Introduction

#### Operator's manual

This Operator's Manual contains a great deal of useful information. We urge you to read it carefully and familiarize yourself with the vehicle before driving.

8

For your own safety and longer service life of the vehicle, we urge you to follow the instructions and warnings contained in this manual. Ignoring them could result in damage to the vehicle or personal injury to you or others. Vehicle damage caused by failure to follow instructions is not covered by the Mercedes-Benz Limited Warranty.

Your vehicle may have some or all of the equipment described in this manual. Therefore, you may find explanations for optional equipment not installed in your vehicle. If you have any questions about the operation of any equipment, your authorized Mercedes-Benz Center will be glad to demonstrate the proper procedures.

## Service and warranty information

The Service and Warranty Information Booklet contains detailed information about the warranties covering your Mercedes-Benz, including:

- New Car Limited Warranty,
- Emission System Warranty,
- Emission Performance Warranty,
- California, Massachusetts, and Vermont Emission Control System Warranty (California, Massachusetts, and Vermont only),
- State Warranty Enforcement Laws (Lemon Laws).

#### Important notice for California retail buyers of Mercedes-Benz automobiles

Under California law you may be entitled to a replacement of your vehicle or a refund of the purchase price, if Mercedes-Benz USA, LLC or its authorized Mercedes-Benz Center fails to conform the vehicle to its express warranties after a reasonable number of repair attempts during the period of one year or 12 000 miles from original delivery of the vehicle. A reasonable number of repair attempts is presumed for a retail buyer (1) if the vehicle is out of service by reason of repair of substantial nonconformities for a cumulative total of more than 30 calendar days or (2) the same substantial non-conformity has been subject to repair four or more times and you have at least once directly notified us in writing of the need to repair the non-conformity and have given us an opportunity to perform the repair ourselves. Notifications should be sent to the nearest Mercedes-Benz Regional Office listed in the Service and Warranty Information Booklet.

#### Maintenance

The Service Booklet describes all the necessary maintenance work which should be performed at regular intervals.

Always have the Service Booklet with you when you take the vehicle to your authorized Mercedes-Benz Center for service. The service advisor will record each service in the booklet for you.

Introduction 9

#### Roadside assistance

The Mercedes-Benz Roadside Assistance Program provides factory trained technical help in the event of a breakdown. Calls to the toll-free Roadside Assistance number:

1-800-FOR-MERCedes (in the USA) 1-800-387-0100 (in Canada)

will be answered by Mercedes-Benz Client Assistance Representatives 24 hours a day, 365 days a year.

For additional information refer to the Mercedes-Benz Roadside Assistance Program brochure in your glove box.

## Change of address or ownership

If you change your address, be sure to send in the "Change of Address Notice" found in the Service and Warranty Information Booklet, or simply call the Mercedes-Benz Client Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100. It is in your own interest that we can contact you should the need arise.

If you sell your Mercedes, please leave all literature with the vehicle to make it available to the next operator.

If you bought this vehicle used, be sure to send in the "Notice of Purchase of Used Car" found in the Service and Warranty Information Booklet, or call the Mercedes-Benz Client Assistance Center (in the USA) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100.

## Operating your vehicle outside the USA or Canada

If you plan to operate your vehicle in foreign countries, please be aware that:

- Service facilities or replacement parts may not be readily available,
- unleaded gasoline for vehicles with catalytic converters may not be available; the use of leaded fuels will damage the catalysts,
- gasoline may have a considerably lower octane rating, and improper fuel can cause engine damage.

Certain Mercedes-Benz models are available for delivery in Europe under our European Delivery Program. For details, consult your authorized Mercedes-Benz Center or write to:

In the USA:

Mercedes-Benz USA, LLC European Delivery Department One Mercedes Drive Montvale, NJ 07645-0350 In Canada:

Mercedes-Benz Canada, Inc. European Delivery Department 849 Eglinton Avenue East Toronto, Ontario M4G 2L5

Introduction 11

We continuously strive to improve our product, and ask for your understanding that we reserve the right to make changes in design and equipment. Therefore, information, illustrations and descriptions in this Operator's Manual might differ from your vehicle.

Optional equipment is also described in this manual, including operating instructions wherever necessary. Since they are special-order items, the descriptions and illustrations herein may vary slightly from the actual equipment of your vehicle.

If there are any equipment details that are not shown or described in this Operator's Manual, your authorized Mercedes-Benz Center will be glad to inform you of correct care and operating procedures.

The Operator's Manual and Service Booklet are important documents and should be kept with the vehicle.

#### Where to find it

The Operator's Manual is divided into eight sections:

- Instruments and controls: An overview of all the controls that can be operated from the driver's seat.
- **Operation:** Information on the vehicle's equipment and its operation.
- Driving: Important information on driving.
- Instrument cluster display: Displays and indicator lamps on the instrument cluster with brief instructions.
- **Practical hints:** Assistance and instructions in the event of an emergency.
- Car care: Instructions on caring for your vehicle.
- **Technical data:** All the important technical data for your vehicle as well as consumer information such as fuels, coolants, lubricants etc. is contained here.
- **Index:** Key terms to help you find a topic quickly.

Other documents may also be supplied, depending on your vehicle's equipment.

Explanation of color used:

Warning notices for the protection of yourself and others appear on red background.

Introduction 13

Introduction 14

# Problems with your vehicle

If you should experience a problem with your vehicle, particularly one that you believe may affect its safe operation, we urge you to immediately contact your authorized Mercedes-Benz Center to have the problem diagnosed and corrected if required. If the matter is not handled to your satisfaction, please discuss the problem with the Mercedes-Benz Center management, or if necessary contact us at the following addresses:

In the USA: Client Assistance Center

Mercedes-Benz USA, LLC

One Mercedes Drive

Montvale, NJ 07645-0350

In Canada: Customer Relations Department

Mercedes-Benz Canada, Inc. 849 Eglinton Avenue East Toronto, Ontario, M4G 2L5 For the USA only:

The following text is published as required of manufacturers under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

# **Reporting Safety Defects**

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Mercedes-Benz USA, LLC.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your retailer, or Mercedes-Benz USA, LLC.

To contact NHTSA, you may either call the Auto Safety Hotline toll-free at 1-800-424-9393 (or 366-0123 in Washington, D.C. area) or write to: NHTSA, U.S. Department of Transportation, Washington, D.C. 20590. You can also obtain other information about motor vehicle safety from the Hotline.

Introduction 15

# **Instruments and controls**

Instruments and controls	18
Center console	20
Overhead control panel	2

**Contents - Instruments and controls** 



Car care

Technical data

Index

**Instruments** Instrument **Technical** Operation Driving **Practical hints** Car care and controls cluster display

**Instruments and controls** 

18

Index

data

## **Instruments and controls**



For more detailed descriptions see Index on page 325.

For adjustment of air outlets, refer to automatic climate control, see page 120.

- 1 Side air outlet, adjustable
- 2 Air volume control for side air outlet
- 3 Exterior lamp switch, see page 114
- 4 Parking brake release, see page 204
- 5 Parking brake pedal, see page 204
- 6 Hood lock release, see page 254
- 7 Combination switch, see page 117
- 8 Cruise control switch, see page 214
- 9 Multifunction steering wheel, see page 88 Horn (with electronic key in steering lock position 1 or 2)
- 10 Instrument cluster, see page 82
- 11 Voice recognition system switch, see separate operating instructions
- 12 Steering lock with ignition/starter switch, see page 192

- 13 Center air outlets, adjustable
- 14 Air volume control for center air outlets
- 15 Left front seat heater switch, see page 56
- 16 Headlamp washer switch, see page 116
- 17 Roll bar switch, see page 53 Roll bar warning lamp, see page 233
- 18 Hazard warning flasher switch, see page 119
- 19 Central locking switch, see page 36
- 20 Switch for tow-away alarm, see page 44 Indicator lamp for antitheft alarm system, see page 42
- 21 Right front seat heater switch, see page 56
- 22 Automatic climate control, see page 120 Rear window defroster switch, see page 124
- 23 Glove box (illuminated with electronic key in steering lock position 1 or 2), see page 151
- 24 Audio system, see page 127
- **25** Storage compartment
- 26 Ashtray with lighter, see page 154

Instruments and controls

Instruments and controls

Operation

Driving

Instrument cluster display

Practical hints

Car care

Technical data

Index

Instruments and controls

## Center console



20

- 1 Soft top switch, see page 162
- **2** ESP control switch, see page 222
- **3** Program mode selector switch, see page 202
- **4** Left power window switch (front), see page 146
- 5 Right power window switch (front), see page 146
- 6 Left power window switch (rear), see page 146
- 7 Trunk lid release switch, see page 40
- **8** Mirror adjustment switch, see page 78
- 9 Right power window switch (rear), see page 146
- **10** Airbag Off indicator lamp, see page 233

## Overhead control panel



- 1 Tele Aid (emergency call system), see page 182
- 2 Interior lighting, see page 149
- **3** Hands-free microphone for Tele Aid, telephone and voice recognition system.
- 4 Rear view mirror, see page 77
- **5** Garage door opener, see page 158

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Contents - Operation			2:	2			
Vo St G	ehicle keysehicle keysentral lock-outeneral notes on the central locking system locking and closin windows from outsi locking lockin		Roll bar and head restraints, Backrest	rear	Adjusting telesconsteering columnside rear view Antiglare night Exterior rear view Instrument clusted Indicator lamps instrument of Multifunction standing multifunction	ems oping mn in t position ew mirrors in the luster deering wheel, in display	76 77 77 78 82
D	Mechanical keys oors entral locking switch	34	BabySmart <sup>TM</sup> airbag deactivation syst Self-test BabySm	tem 64	Trip and main o vehicle speed engine oil lev	,	.92

Supplemental restraint

Emergency tensioning

Safety guidelines for the

seat belt, emergency

tensioning retractor

special child seat installed ....... 64

system (SRS) ......65

retractor (ETR) ......65

Airbags ...... 66

and airbag ......72

Audio systems ......93 Radio ......93

CD player ......94

Cassette player ......95

Telephone book ......96

Redialing ......98

Incoming call ......100

Navigation system ......101

Telephone ......96

Automatic central locking .......37

in case of accident ......37

Trunk ......38

Trunk lid release switch ......40

Trunk lid emergency release ........ 41

Antitheft alarm system ......42

Tow-away alarm ......44

Emergency unlocking

Trip computer 102	Automatic climate control 120	Illuminated vanity mirrors 150
Malfunction message	Display and controls 122	Interior151
memory104	Basic setting 122	Storage compartments,
Individual settings106	Economy 123	armrest and cup holder151
Setting the audio volume 108	Special settings 123	Glove box151
Flexible service system	Rear window defroster 124	Ashtray154
(FSS)109	Air recirculation 125	Lighter155
Engine oil level indicator 112	Residual engine	Cargo tie down rings156
Engine oil consumption113	heat utilization 125	Parcel net in front
Exterior lamp switch114	Dust filter 126	passenger footwell156
Night security illumination115	Audio and telephone,	Armrest, rear bench156
Headlamp cleaning system116	operation127	Telephone, general157
Combination switch117	Power windows 146	Cellular telephone157
Hazard warning flasher	Interior lighting 149	Garage door opener158
switch119	Sun visors150	Soft top162
		**** 1

Driving

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Central lockin	og system		2	· <b>1</b>			

locking syste

# Vehicle keys

Included with your vehicle are:

• 2 electronic main keys with integrated radio frequency and infrared remote controls plus removable mechanical key.

The locking tabs for the mechanical key portion of the two electronic main keys are a different color to help distinguish it.

• 1 electronic reserve key without remote control functions, plus removable mechanical key.

24

# Warning!

When leaving the vehicle always remove the electronic key from the steering lock, and lock your vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause serious personal injury.

## Electronic main key



The electronic main key has an integrated radio frequency and infrared remote control, plus removable mechanical key.

The remote control (1) operates all locks on the vehicle.

The mechanical key (2) works only in the driver's door, trunk, and storage compartment locks.

When using the mechanical key (2) for lock operations, it can be removed by sliding it out of the remote control. To do so, move locking tab (3) to the right and slide the mechanical key (2) in direction of arrow (4).

The remote control transmitter is located in the electronic main key.

The infrared receivers are located in the door handles.

#### Notes:

Remove the mechanical key from the electronic main key when using valet parking service. To prevent access to trunk or storage compartments lock them separately and retain the mechanical key.

See page 38 for separate locking of trunk and page 151 for locking of glove box.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

# Central locking system

# Electronic reserve key



The electronic reserve key is without remote control functions, but with removable mechanical key.

26

The electronic reserve key (1) works only in the steering lock. There are no batteries inside the electronic reserve key.

The mechanical key (2) works only in the driver's door, trunk, and storage compartment locks.

To use the mechanical key (2), remove it from its electronic reserve key (1).

#### Note:

We recommend that you carry the electronic reserve key plus mechanical key with you and keep it in a safe place (e.g. your wallet) so that it is always handy. Never leave the electronic reserve key in the vehicle.

#### Obtaining replacement keys

Your vehicle is equipped with a theft deterrent locking system requiring a special key manufacturing process. For security reasons, replacement keys can only be obtained from your authorized Mercedes-Benz Center.

#### Start lock-out

## Important!

Removing the electronic key from the steering lock activates the start lock-out. The engine cannot be started.

Inserting the electronic key in the steering lock deactivates the start lock-out.

#### Note:

In case the engine cannot be started (vehicle's battery is in order), the system is not operational. Contact an authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes (in the USA) or 1-800-387-0100 (in Canada).

#### General notes on the central locking system

If the electronic key is inserted in the steering lock, the vehicle cannot be locked or unlocked with the remote control.

If the vehicle cannot be locked or unlocked:

- Aim transmitter eye at a receiver of either door handle. Check the batteries of the electronic main key, see page 288, or synchronize the remote control, see page 290.
- Use the mechanical key to unlock the driver's door. To start the engine, insert the electronic main key in the steering lock. There could be a slight delay until the electronic main key can be turned in the steering lock.

#### Important!

When unlocking the driver's door with the mechanical key, the exterior lamps will flash and the alarm will sound.

To cancel the alarm, insert the electronic key in the steering lock or press button or on the electronic main key.

Index

Central locking system

28

## Central locking system

## Radio frequency and infrared remote control

The electronic main key has an integrated radio frequency and infrared remote control.

Due to the extended operational range of the remote control, it could be possible to unintentionally lock or unlock the vehicle by pressing the transmit button. If one of the transmit buttons is pressed, the battery check lamp lights up briefly – indicating that the batteries are in order. See page 288 for checking batteries.

The vehicle doors, trunk and fuel filler flap can be centrally locked and unlocked via remote control.


Opening and closing the windows remotely can only be done with the infrared portion of the remote control. Aim transmitter eye at a receiver (6 or 7), press and hold transmit button or .

If the electronic key is inserted in steering lock, the vehicle cannot be locked or unlocked with the remote control.




Index

- 1 Transmit button
  - Locking
  - Unlocking
  - Opening trunk (if not separately locked)
- 2 Lamp for battery check (see page 288 for changing batteries if it does not light up briefly)
- 3 PANIC button
- 4 Transmitter eye
- 5 Locking tab for mechanical key



6 Infrared receiver in driver's door handle



7 Infrared receiver in passenger door handle

30

Central locking system

# Locking and unlocking with remote control

# Unlocking:

Press transmit button . All turn signal lamps blink once to indicate that the vehicle is unlocked.

The remote control can be programmed for two kinds of unlocking modes (see below):

Selective unlocking mode -

Press transmit button once to unlock driver's door and fuel filler flap.

Press transmit button of twice to unlock both doors, fuel filler flap, and trunk.

Global unlocking mode –
Press transmit button once to unlock both doors, fuel filler flap, and trunk.

#### Notes:

If the trunk was previously locked separately, it will remain locked, see page 38.

The presently active unlocking mode (selective or global) can only be determined by unlocking the vehicle with the remote control (see below for changing mode).

If within 40 seconds of unlocking with the remote control, neither door nor trunk is opened, the electronic key is not inserted in the steering lock, or the central locking switch is not activated, the vehicle will automatically lock.

#### Locking:

Press transmit button once. All turn signal lamps blink three times to indicate that the vehicle is locked.

If they do not blink three times, a door or trunk is not properly closed.

#### Note:

If the vehicle cannot be locked or unlocked by pressing the transmit button, then it may be necessary to change the batteries in the electronic main key (if ok, battery check lamp in electronic main key will light briefly when pressing transmit button) or to synchronize the remote control, see pages 288 and 290.

## Choosing global or selective mode on remote control

Press and hold transmit buttons and and simultaneously for approx. 6 seconds to reprogram the remote control. Battery check lamp will blink two times indicating the completed mode change.

## Opening the trunk

Press transmit button until trunk lid is released.

A minimum height clearance of 5.9 ft. (1.8 m) is required to open the trunk lid.

#### Important!

Do not place remote control in trunk since trunk is locked when the lid is closed if the vehicle is centrally locked.

#### Note:

If the trunk was previously locked separately, it will remain locked, see page 38.

Central locking system



31

locking syste

# Opening and closing windows from outside

Aim transmitter eye of remote control at a door receiver.

To open:

Continue to press transmit button of after unlocking the vehicle.

The windows begin to open after approx. 1 second.

To interrupt opening procedure, release transmit button.

To close:

Continue to press transmit button after locking the vehicle.

The windows begin to close after approx. 1 second.

To interrupt closing procedure, release transmit button.

#### Note:

If the windows cannot be operated automatically by pressing the transmit button of the remote control then it may be necessary to change the batteries in the electronic main key (if ok, battery check lamp in electronic main key will light briefly when pressing transmit button), or to synchronize the remote control, see page 288 and 290.

## Warning!

Never operate the windows if there is the possibility of anyone being harmed by the opening or closing procedure.

In case the procedure causes potential danger, the procedure can be immediately halted by releasing the remote control button. To reverse direction of movement press for opening or for closing.

#### Panic button



To activate press and hold button (1) for at least one second. An audible alarm and blinking exterior lamps will operate for approximately 3 minutes.

To deactivate press button (1) again, or insert electronic key in steering lock.

#### Note:

For operation in the USA only: This device complies with Part 15, Subpart C, Section 209 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modification not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.

## Mechanical keys

The mechanical keys work only in the driver's door, trunk, and storage compartment locks.

#### Notes:


The mechanical key does not operate the central locking system or antitheft alarm system.

The fuel filler flap cannot be locked or unlocked with the mechanical key.


Central locking system

34

## **Doors**



- 1 Opening pull handle
- 2 Unlocking driver's door
- 3 Locking driver's door
- 4 Individual door from inside:
  - · Push lock button down to lock.
  - · Pull inside door handle to unlock.



## Important!

The mechanical key does not operate the central locking system or antitheft alarm system.

When you lock the driver's door with the mechanical key, the door lock button should move down.

The passenger door must be locked with the door lock button – the driver's door can only be locked when it is closed.

If the vehicle has previously been locked from the outside, opening a door from the inside will trigger the alarm. When opening a door while the central locking system is in the:

- · selective unlocking mode, only that individual door is unlocked. The remaining door, the trunk and fuel filler flap remain locked,
- global unlocking mode, both doors, the trunk and fuel filler flap are unlocked.

#### Notes:

When opening a door, the door window lowers slightly. After closing the door, the window closes again.

In case of a malfunction in the central locking system the doors can be locked and unlocked individually.

To lock, push down lock button and turn mechanical key in driver's door lock to position 3. In addition lock the trunk.

To unlock, pull inside door handle and turn mechanical key in driver's door lock to position 2.

When unlocking the driver's door with the mechanical key, the exterior lamps will flash and the alarm will sound.

To cancel the alarm, insert the electronic key in the steering lock or press button or on the electronic main key.

**Practical hints** 

35

Operation

Driving

Instrument cluster display

**Practical hints** 


Car care

Technical data

Index

Central locking system

Central locking switch



- 1 Locking
- 2 Unlocking

The central locking switch is located in the center console.

The doors and trunk can only be locked with the central locking switch, if both doors are closed.

If the vehicle was previously locked with the central locking switch, while in the selective remote control mode, only the door opened from the inside is unlocked.

If the vehicle was previously locked with the central locking switch, while in the global remote control mode, the complete vehicle is unlocked when a door is opened from the inside.

## Notes:

36

If the vehicle was previously locked with the remote control, the doors and trunk cannot be unlocked with the central locking switch.

If the vehicle has previously been locked from the outside, opening a door with the inside door handle will trigger the alarm. To cancel the alarm, insert the electronic key in the steering lock or press button or on the electronic main key.

The fuel filler flap cannot be locked or unlocked with the central locking switch.

## Warning!

When leaving the vehicle always remove the electronic key from the steering lock, and lock your vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause serious personal injury.

## **Automatic central locking**

The central locking switch also operates the automatic central locking.

With the automatic central locking system activated, the doors and trunk are locked at vehicle speeds of approx. 9 mph (15 km/h) or more. The fuel filler flap remains unlocked.

#### To activate:

With electronic key in steering lock position 2 hold upper portion of switch (1) for a minimum of 5 seconds.

#### To deactivate:

With electronic key in steering lock position 2 hold lower portion of switch (2) for a minimum of 5 seconds.

#### Notes:

If doors are unlocked with the central locking switch after activating the automatic central locking, and neither door is opened, then the doors remain unlocked even at vehicle speeds of approx. 9 mph (15 km/h) or more.

If a door is opened from the inside at speeds of approx. 9 mph (15 km/h) or less with the automatic central locking activated, the door will again be automatically locked at speeds of approx. 9 mph (15 km/h) or more.

## Important!

When towing the vehicle, or with the vehicle on a dynamometer test stand, please, note the following:

With the automatic central locking activated and the electronic key in steering lock position 2, the vehicle doors will lock if the left front wheel as well as the right rear wheel spin at vehicle speeds of approx. 9 mph (15 km/h) or more.

To prevent the vehicle door locks from locking, deactivate the automatic central locking.

## Emergency unlocking in case of accident

The doors unlock automatically a short time after a strong deceleration is detected, such as in a collision (this is intended to aid rescue and exit).

Driving on rough roads may cause the vehicle to unlock. If necessary, the vehicle can be locked again with the central locking switch, see page 36.

Central locking system

	7
J	/
_	-

#### 38

#### Trunk

When the trunk is separately locked, it remains locked when centrally unlocking the vehicle.


To deny any unauthorized person access to the trunk, lock it separately with the mechanical key. Leave only the electronic main key less its mechanical key with the vehicle.

## Notes:

The mechanical key does not operate the central locking system or antitheft alarm system.

When unlocking the trunk with the mechanical key, the exterior lamps will flash and the alarm will sound.

To cancel the alarm, insert the electronic key in the steering lock or press button or on the electronic main key.



Index

- **0** Neutral position push to open (arrow)
- 1 Unlocking
- 2 Separate locking of trunk remove mechanical key in this position.

The trunk lid cannot be opened by the trunk lid release switch or the electronic main key when previously locked separately with the mechanical key.

#### Notes:

In case of a malfunction in the central locking system the trunk can be unlocked individually.


To unlock and open the trunk lid, turn mechanical key to position 1, hold and push to open.

If the fuel filler flap cannot be opened, see page 298.

## Important!

Do not place mechanical key inside trunk, since trunk is locked when the lid is closed if the vehicle has been previously centrally locked.


To prevent damage to the trunk lid and the soft top compartment cover, do not open the trunk lid while the soft top is being raised or lowered.



Lower trunk lid using handle (1) and close it with hands placed flat on trunk lid. Please remember to keep your fingers out of the space between the lid and the vehicle.

# Central locking system

## Trunk lid release switch



The switch is located on the center console.

40

A minimum height clearance of 5.9 ft. (1.8 m) is required to open the trunk lid.

To open the trunk, the vehicle must be at standstill. Pull up on switch until trunk lid is open.

The indicator lamp in the switch remains on with trunk lid open.


#### Notes:

The trunk can also be opened by using the electronic main key. Press button.

The trunk lid cannot be opened by the switch or the remote control when previously locked separately with the mechanical key. To open, see page 38.

The trunk lid cannot be opened with the trunk lid release switch when the vehicle was previously locked with the central locking switch. To unlock vehicle with the central locking switch, see page 36.

## Trunk lid emergency release



The emergency release button (1) is located in the trunk lid.

Briefly press emergency release button (1). All doors, the fuel filler flap, and the trunk unlock; and the trunk lid opens.

#### Note:

The emergency release button (1) only unlocks and opens the trunk while the vehicle is standing.

#### Important!

The emergency trunk lid release button (1) does not open the trunk lid, if:

- the vehicle battery is discharged or disconnected,
- the trunk lid was previously locked separately with the mechanical key, see page 38.

Illumination of the emergency release button (1):

The button will blink for 30 minutes after opening the trunk.

The button will blink for 60 minutes after closing the trunk.

# Antitheft alarm system

## Antitheft alarm system



1 Indicator lamp in switch located in center console

42

The antitheft alarm is automatically armed or disarmed with the remote control by locking or unlocking the vehicle.

The antitheft alarm is armed within approx. 10 seconds after locking the vehicle.

A blinking lamp (1) indicates that the alarm is armed.

## Operation:

Once the alarm system has been armed, the exterior vehicle lamps will flash and an alarm will sound when someone:

- opens a door,
- opens the trunk,
- · opens the hood,
- attempts to raise the vehicle.

The alarm will last approximately 3 minutes in form of flashing exterior lamps. At the same time an alarm will sound for 30 seconds. The alarm will stay on even if the activating element (a door, for example) is immediately closed. The antitheft alarm system is switched off automatically if the vehicle is unlocked with the electronic main key. If the alarm stays on for more than 20 seconds, an emergency call is initiated automatically. See Tele Aid on page 182.

#### Notes:

We recommend that you carry the electronic reserve key plus mechanical key with you and keep it in a safe place (e.g. your wallet) so that it is always handy. Never leave the electronic reserve key in the vehicle.

When you unlock the driver's door with the mechanical key, the exterior lamps will flash and the alarm will sound.

To interrupt the alarm, insert the electronic key in the steering lock or press button or on the electronic main key.

**Technical** 

data

Index

Antitheft alarm system



44

on page 182.

Tow-away alarm

## Tow-away alarm



The switch is located in the center console.

- 1 Press to switch off
- 2 Indicator lamp

Once the alarm system has been armed, the exterior vehicle lamps will flash and an alarm will sound when someone attempts to raise the vehicle.

The alarm will last approximately 3 minutes in form of flashing exterior lamps. At the same time an alarm will sound for 30 seconds. The alarm will stay on even if the vehicle is immediately lowered. The tow-away alarm

system is switched off automatically if the vehicle is

unlocked with the electronic main key.

If the alarm stays on for more than 20 seconds, an emergency call is initiated automatically. See Tele Aid

To prevent triggering the tow-away alarm feature, switch off the tow-away alarm before towing the vehicle, or when parking on a surface subject to movement, such as a ferry or auto train.

To do so, turn electronic key in steering lock to position 1 or 0, or remove electronic key from steering lock. Press tow-away alarm switch (1). The indicator lamp (2) illuminates briefly.

Exit vehicle, and lock vehicle with the remote control.

The tow-away alarm remains switched off until the vehicle is locked again with the remote control, at which time it is automatically reactivated.

## Power seats, front

## Warning!

Do not adjust the driver's seat while driving. Adjusting the seat while driving could cause the driver to lose control of the vehicle.

Never ride in a moving vehicle with the backrest reclined. Sitting in an excessively reclined position can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The backrest and seat belt provide the best restraint when the wearer is in an upright position and the belt is properly positioned on the body.

Never place hands under seat or near any moving parts while a seat is being adjusted.

## Warning!


When leaving the vehicle always remove the electronic key from the steering lock, and lock your vehicle.

The power seats can also be operated with the driver's or passenger door open. Do not leave children unattended in the vehicle or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause serious personal injury.

To operate the front power seat adjustment switches, turn electronic key in steering lock to position 1 or 2 (with the driver's or passenger's door open, the power seats can also be operated with the electronic key removed or in steering lock position 0).

Seats 45

Seats 46



The slide switches are located in each door.

We recommend to adjust the power seat in the following order:

## 1 Seat, up/down

Press the switch (up/down direction) until comfortable seating position with still sufficient headroom is reached.

## 2 Seat, fore/aft

Press the switch (fore/aft direction) until a comfortable seating position is reached that still allows you to reach the accelerator/brake pedal

safely. The position should be as far rearward as possible, consistent with ability to properly operate controls.

#### Note:

Do not move the front passenger seat completely forward if objects are stored in the parcel net in the front passenger side footwell. Items in the net may be damaged.

#### 3 Seat cushion tilt

Press the switch in the direction of the arrow until your legs are lightly supported.

#### 4 Backrest tilt

Press the switch in the direction of the arrow until your arms are slightly angled when holding the steering wheel.

#### 5 Head restraint

During seat adjustment, the head restraint is automatically adjusted based on seat (fore/aft) position to support the back of the head approximately at ear level. Please check the position of the head restraint to assure that it supports the back of the head approximately at ear level. The head restraint angle can also be adjusted manually.

#### Notes:

Your vehicle is equipped with power head restraints, do not try to raise or lower them manually.

Only minor personal adjustments, as described below, should then be required. For steering wheel adjustment, see page 76; inside rear view mirror, see page 77; exterior rear view mirrors, see page 78.

#### Caution!

Do not remove head restraints except when mounting seat covers. For removal see page 51. Whenever restraints have been removed be sure to reinstall them before driving.

Index

Seats 47

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data
unu comunic			crubter dispid			uuu

Seats

# Memory storing and recalling



- 6 Memory button
- **7** Position buttons

48

## **Storing**

Three sets of seat/head restraint and exterior rear view mirror positions may be programmed into memory. After the seat/head restraint and exterior rear view mirrors are positioned, push memory button (6), release, and within 3 seconds push position button "1". A second and third set of positions for the same seat/head restraint and exterior rear view mirrors can be programmed into memory by pushing first memory button (6) and then "2", respectively "3".

#### Note:

See page 78 for instructions on adjustment of mirrors.

## Recalling

To recall a seat/head restraint and exterior rear view mirror position, push and hold position button "1", "2" or "3" until seat/head restraint and exterior rear view mirror movement has stopped. The seat/head restraint and exterior rear view mirror movement stops when the position button is released.

#### Caution!

Do not operate the power seats using the memory button if the backrest is in an excessively reclined position. Doing so could cause damage to front or rear seats.

First move the backrest to an upright position.

## Synchronizing power seats and head restraints

If the power supply was interrupted (battery disconnected or empty), the power seats and head restraints are no longer adjusted automatically.

To resynchronize the adjustment feature, turn electronic key in steering lock to position 2, move the seat completely forward and the head restraint fully down, and hold respective buttons for approx.

2 seconds

Seats 49

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	operation	Dilving	cluster display	Tractical mints	Cui cui c	data	Hidex

Seats 50

## Important!

Prior to operating the vehicle, the driver should adjust the seat height for proper vision as well as fore/aft placement and backrest angle to insure adequate control, reach, operation, and comfort. The head restraint should also be adjusted for proper height. See also airbag section on page 66 for proper seat positioning.

In addition, also adjust the steering wheel to ensure adequate control, reach, operation, and comfort.

Both the inside and outside rear view mirrors should be adjusted for adequate rearward vision.

Fasten seat belts. Infants and small children should be seated in a properly secured restraint system that complies with U.S. Federal Motor Vehicle Safety Standard 213 and Canadian Motor Vehicle Safety Standard 213.

All seat, head restraint, steering wheel, and rear view mirror adjustments as well as fastening of seat belts should be done before the vehicle is put into motion.

## Warning!

Children 12 years old and under must never ride in the front seat, except in a Mercedes-Benz authorized BabySmart compatible child seat, which operates with the BabySmart system installed in the vehicle to deactivate the passenger side front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury can result.

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating positions. Infants and small children must ride in back seats and be seated in an appropriate infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

#### Front head restraints

## Warning!

For your protection, drive only with properly positioned head restraints.

Adjust head restraint to support the back of the head approximately at ear level.

Do not drive the vehicle without the seat head restraints. Head restraints are intended to help reduce injuries during an accident.

#### Removal:

Tilt the backrest rearward for easier removal of the front head restraints.

Push button (1) up to bring the power adjustable head restraint to its highest position.

Pull out head restraint completely with both hands.



#### Installation:

Push button (1) of the power adjustable head restraint up for approximately 5 seconds.

Insert the head restraint and push it down to the stop.

Adjust head restraint to the desired position.

For positioning of head restraints see also power seats, front on page 45, and head restraints, rear on page 53.

Seats 51

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 Tactical IIIIts	Car care	data	IIIucx

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
			• 1				

Seats 52

## Roll bar and head restraints, rear

The rear head restraints are integrated in the roll bar.

The roll bar will be automatically raised in an accident or in a potentially dangerous driving situation. A ratchet noise can be heard when the roll bar is automatically raised.

The roll bar can be lowered again after an automatic deployment by pressing the upper half of the roll bar switch (for at least 8 seconds) until the roll bar drive mechanism audibly engages. Then press the lower half of the switch to lower the roll bar.

If the roll bar was raised using the switch, it will be automatically lowered when activating the soft top switch.

## Warning!

Raising or lowering of the roll bar could injure rear seated occupants.

Before operating the roll bar switch make sure that the roll bar's path is clear and no persons due to inattention are injured by the moving roll bar.

For your own safety we recommend to drive with the roll bar raised, if

- the outside temperature is below  $+5^{\circ}F$  (-15°C).
- · the rear seats are occupied by passengers.

Before working on the vehicle, e.g. when changing wheels, the roll bar should be raised with the switch, and the electronic key should be removed from the steering lock, to prevent possible injury.

In case of potential danger release the switch to immediately interrupt the operating procedure.

## Switch for roll bar and head restraints, rear



The switch is located in the center console.

Turn electronic key in steering lock to position 2.

Press switch:

- 1 Raise roll bar
- 2 Lower roll bar

The lowering or raising procedure is immediately interrupted by releasing the roll bar switch.

With the engine running and the roll bar lowered, the warning lamp in the roll bar switch will blink for approx. 15 seconds. The blinking is reminding you to raise the roll bar if the rear passenger seats are occupied. See also page 233 for roll bar warning lamp.

#### Important!

The roll bar is intended to be a safety enhancement to the other features designed into the vehicle. No system in any vehicle can eliminate the possibility of serious injury or fatality in an accident. Properly fastened seat belts and child restraints must be used!

#### Notes:

If the warning lamp in the switch comes on, then a malfunction has been detected. In this case, drive only with the roll bar raised until the problem has been corrected. Raise the roll bar by pressing the upper half of the roll bar switch.

Have the system checked at your authorized Mercedes-Benz Center as soon as possible.


Items being transported in the rear passenger compartment should be placed in such a manner as not to affect the movement of the roll bar when being raised.

Seats 53

Instruments	Operation	Driving	Instrument	Practical hints	Car cara	Technical	Indov
and controls	Operation	Dilving	cluster display	r ractical illits	Car care	data	Index

Seats 54

#### **Backrest**



## 1 Release lever

## Folding forward:

Lift release lever (1) and fold backrest forward. The seat will automatically slide forward and the head restraint will move down.

## Folding back:

Lift release lever (1) and fold backrest back. The seat and head restraint return to their previous positions.

To interrupt the procedure, activate the power seat switch.

#### Notes:

The automatic seat slide is provided with a safety feature. The automatic process is interrupted, if the backrest of the sliding seat is pushed against an occupant or object. The seat will slide forward, stop, and make 3 attempts sliding backward.

To halt the automatic process, activate the power seat switch. Investigate and correct the cause of interruption. Now use memory button or power seat switch to bring seat into desired position.

The backrest release lever (1) also serves as a rest for the front seat belt, bringing it within easy reach.


## Warning!

When leaving the vehicle always remove the electronic key from the steering lock, and lock your vehicle.

The power seats can also be operated with the driver's or passenger door open. Do not leave children unattended in the vehicle or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause serious personal injury.

Never place hands under seat or near any moving parts during a seat adjustment procedure.

## Multicontour seat (optional)



Some models may be equipped with multicontour seats. These seats have movable seat cushions, and inflatable air cushions built into the backrest to provide additional lumbar and side support.

We recommend to adjust the multicontour seat in the following order:

- 1 Seat cushion depth Slide the switch fore or aft until your legs are supported comfortably.
- 2 Backrest bottom
- 3 Backrest center
- 4 Side bolster adjustment Adjust the side bolster to provide good lateral support.

The seat cushion movement and amount of backrest cushion height and curvature can be continuously varied with regulators (1, 2 and 3) after turning the electronic key in steering lock to position 2.

The side bolsters of the backrest can be adjusted with rocker switch (4):

- press to the right increase side support,
- press to the left decrease side support.

If the engine is turned off, the last cushion setting is retained in memory, and automatically adjusts the cushion to this setting when the engine is restarted.

Seats 55

Inst	ruments
and	controls

# **Practical hints**

# Car care

## Technical data

Seats 56

## **Heated seats, front** (optional)



The front seat heater switches are located in the center console.

The front seat heaters can be switched on with the electronic key in steering lock positions 1 or 2.

Press switch to turn on seat heater:

- 1 Normal seat heating mode. One indicator lamp in the switch lights up.
- 2 Rapid seat heating mode. Both indicator lamps in the switch light up.

After approximately 5 minutes in the rapid seat heating mode, the seat heater automatically switches to normal operation and only one indicator lamp will stay on.

Turning off seat heater:

If one indicator lamp is on, press upper half of switch.

If both indicator lamps are on, press lower half of switch.

If left on, the seat heater automatically turns off after approximately 30 minutes of operation.

#### Notes:

When in operation, the seat heater consumes a large amount of electrical power. It is not advisable to use the seat heater longer than necessary.

The seat heaters may automatically switch off if too many power consumers are switched on at the same time, or if the battery charge is low. When this occurs, the indicator lamp in the switch will blink (both indicator lamps blink during rapid seat heating mode). The seat heaters will switch on again automatically as soon as sufficient voltage is available.

If the blinking of the indicator lamps is distracting to you, the seat heaters can be switched off.

Seats 57

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Restraint systems

**58** 

## Seat belts and integrated restraint system

Your vehicle is equipped with seat belts for all seats, emergency tensioning retractors for the front seat belts, dual front airbags, door mounted side impact airbags and knee bolsters for driver and front passenger. Their protective functions are designed to complement one another.

## Seat belts

## Important!

Laws in most states and all Canadian provinces require seat belt use.

All states and provinces require use of child restraints that comply with U.S. Federal Motor Vehicle Safety Standard 213 and Canadian Motor Vehicle Safety Standard 213.

All child restraint systems are designed to be secured in vehicle seats by lap belts or the lap belt portion of a lap-shoulder belt.

For your safety and that of your passengers we strongly recommend their use.

## Warning!

Children 12 years old and under must never ride in the front seat, except in a Mercedes-Benz authorized BabySmart<sup>TM</sup> compatible child seat, which operates with the BabySmart<sup>TM</sup> system installed in the vehicle to deactivate the passenger side front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury will result.

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating positions. Infants and small children must ride in back seats and be seated in an appropriate infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

#### Warning!

Never ride in a moving vehicle with the backrest reclined. Sitting in an excessively reclined position can be dangerous. You could slide under the seat belt in a collision. If you slide under it, the belt would apply force at the abdomen or neck. That could cause serious or even fatal injuries. The backrest and seat belt provide the best restraint when the wearer is in an upright position and the belt is properly positioned on the body.

#### Note:

For cleaning and care of the seat belts, see page 306.

#### Seat belt nonusage warning system

With the electronic key in steering lock position 2, a warning sounds for a short time if the driver's seat belt is not fastened. See also seat belt warning lamp on page 232.

## Warning!

Failure to wear and properly fasten and position your seat belt greatly increases your risk of injuries and their likely severity in an accident. You and your passengers should always wear seat belts.

If you are ever in an accident, your injuries can be considerably more severe without your seat belt properly buckled. Without your seat belt buckled, you are much more likely to hit the interior of the vehicle or be ejected from it. You can be seriously injured or killed.


In the same crash, the possibility for injury or death is lessened if you are wearing your seat belt.

## Warning!

Never let more people ride in the vehicle than there are seat belts available. Be sure everyone riding in the vehicle is correctly restrained with a separate seat belt.

Restraint systems

## Fastening of seat belts



- 1 Latch plate
- 2 Buckle
- 3 Release button


**60** 

Push latch plate (1) into buckle (2) until it clicks. Do not twist the belt. A twisted seat belt may cause injury.

To help avoid severe or fatal injuries, the lap belt must be positioned as low as possible on your hips and not across the abdomen.

# Warning!

Always fasten your seat belt before driving off. Always make sure your passengers are properly restrained – even those sitting in the rear.




Tighten the lap portion to a snug fit by pulling shoulder portion up.

The shoulder portion of the seat belt must be pulled snug and checked for snugness immediately after engaging it.

Adjust seat belt so that shoulder portion is located as close as possible to the middle of your shoulder (it should not touch the neck).

## Unfastening of seat belts



Push the release button (3) in the belt buckle (2). Allow the retractor to completely rewind the seat belt by guiding the latch plate (1).

## Operation

The inertia reel stops the belt from unwinding during sudden vehicle stops or when quickly pulling on the belt. The locking function of the reel may be checked by quickly pulling out the belt.

**Restraint systems** 

Instruments
and controls

Driving

Instrument cluster display

Practical hints

Car care

Technical data

Index

Restraint systems

62

#### Caution!

For safety reasons, avoid adjusting the seat or backrest into positions which could affect the correct seat belt position.

## Warning!

#### USE SEAT BELTS PROPERLY.

Operation

- Seat belts can only work when used properly. Never wear seat belts in any other way than as described in this section, as that could result in serious injuries in case of an accident.
- Each occupant should wear their seat belt at all times, because seat belts help reduce the likelihood of and potential severity of injuries in accidents, including rollovers. The integrated restraint system includes "SRS" (driver airbag, front passenger airbag, door mounted side impact airbags), "ETR" (seat belt emergency tensioning retractors), and front seat knee bolsters. The system is designed to enhance the protection offered to properly belted occupants in certain frontal (front airbags) and side (side impact airbags) impacts which exceed preset deployment thresholds.

- Never wear belts over rigid or breakable objects in or on your clothing, such as eyeglasses, pens, keys etc., as these might cause injuries.
- Never wear the shoulder belt under your arm, against your neck or off your shoulder. In a crash, your body would move too far forward. That would increase the chance of head and neck injuries. The belt would also apply too much force to the ribs or abdomen, which could severely injure internal organs such as your liver or spleen.
- Position the lap belt as low as possible on your hips and not across the abdomen. If the belt is positioned across your abdomen, it could cause serious injuries in a crash.
- Each seat belt should never be used for more than one person at a time. Do not fasten a seat belt around a person and another person or other objects.
- Belts should not be worn twisted. In a crash, you wouldn't have the full width of the belt to manage impact forces. The twisted belt against your body could cause injuries.

- Pregnant women should also use a lapshoulder belt. The lap belt portion should be positioned as low as possible on the hips to avoid any possible pressure on the abdomen.
- Never place your feet on the instrument panel or on the seat. Always keep both feet on the floor in front of the seat.

## Warning!

#### USE CHILD RESTRAINTS PROPERLY.

Children 12 years old and under must never ride in the front seat, except in a Mercedes-Benz authorized BabySmart<sup>TM</sup> compatible child seat, which operates with the BabySmart<sup>TM</sup> system installed in the vehicle to deactivate the passenger front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury will result.

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating positions. Infants and small children must ride in back seats and be seated in an appropriate infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

A child's risk of serious or fatal injuries is significantly increased if the child restraints are not properly secured in the vehicle and the child is not properly secured in the child restraint.

Children too big for child restraint systems must ride in back seats using regular seat belts. Position shoulder belt across chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper belt positioning.

**Restraint systems** 

Restraint systems

64

## BabySmart<sup>TM</sup> airbag deactivation system

Special BabySmart<sup>TM</sup> compatible child seats, designed for use with the Mercedes-Benz system and available at any authorized Mercedes-Benz Center are required for use with the BabySmart<sup>TM</sup> airbag deactivation system.

With the special child seat properly installed, the passenger front airbag will not deploy. The indicator lamp located on the center console will be illuminated, except with electronic key removed or in steering lock position 0. The system does not deactivate the door mounted side impact airbag.

 $BabySmart^{TM}$  is a trademark of Siemens Automotive Corp.

## Warning!

The BabySmart<sup>™</sup> airbag deactivation system will ONLY work with a special child seat designed to operate with it. It will not work with child seats which are not BabySmart<sup>™</sup> compatible.

Never place anything between seat cushion and child seat (e.g. pillow), since it reduces the effectiveness of the deactivation system.

Follow the manufacturer's instructions for installation of special child seats.

The passenger side front airbag will not deploy only if the ARBAG indicator lamp remains illuminated.

Index

Please be sure to check the indicator every time you use the special system child seat.

Should the light go out while the restraint is installed, please check installation. If the light remains out, do not use the BabySmart restraint to transport children on the front passenger seat until the system has been repaired.

# $\label{eq:self-test-BabySmart} Self-test\ BabySmart^{TM} \\ without\ special\ child\ seat\ installed$

After turning electronic key in steering lock to position 1 or 2, the indicator lamp located on the center console comes on for approx. 6 seconds and then extinguishes.

If the indicator lamp should not come on or is continuously lit, the system is not functioning. You must see an authorized Mercedes-Benz Center before seating any child on the front passenger seat.

BabySmart<sup>™</sup> is a trademark of Siemens Automotive Corp.

## Supplemental restraint system (SRS)

Airbags are intended as a supplement to seat belts. Airbags alone cannot protect as well as airbags plus seat belts in impacts for which the airbags were designed to operate, and do not afford any protection whatsoever in crashes for which the airbags are not designed to deploy.

The SRS uses two crash severity levels (thresholds) to activate either the emergency tensioning retractor (ETR) or front airbag or both. Activation depends on the direction and severity of the impact exceeding the preset thresholds and whether the seat belt is fastened.

#### Seat belt fastened

- first threshold exceeded: ETR activates
- second threshold exceeded: airbag also activates

#### Seat belt not fastened

• first threshold exceeded: airbag activates, but not ETR

Driver and front passenger systems operate independently of each other.

## **Emergency tensioning retractor (ETR)**

The seat belts for the front seats are equipped with emergency tensioning retractors. These tensioning retractors are located in each belt's inertia reel and become operationally ready with the electronic key in steering lock position 1 or 2.

The emergency tensioning retractors are designed to activate only when the seat belts are fastened during frontal impacts exceeding the first threshold of the SRS and in rear impacts exceeding a preset severity level. They remove slack from the belts in such a way that the seat belts fit more snugly against the body restricting its forward movement as much as possible.

In cases of other frontal impacts, angled impacts, roll-overs, certain side impacts, or other accidents without sufficient frontal or rear impact forces, the emergency tensioning retractors will not be activated. The driver and passengers will then be protected by the fastened seat belts and inertia reel in the usual manner.

For seat belt and emergency tensioning retractor safety guidelines see page 72.

Index

Restraint systems


66

## **Airbags**



1 Driver airbag

The driver airbag is located in the steering wheel hub.



**2** Front passenger airbag

The passenger front airbag is located in the dashboard ahead of the front passenger.



## 3 Side impact airbag

The side impact airbags are located in the doors.

The most effective occupant restraint system yet developed for use in production vehicles is the seat belt. In some cases, however, the protective effect of a seat belt can be further enhanced by an airbag.

In conjunction with wearing the seat belts, the driver and front passenger airbags can provide increased protection for the driver and front passenger in certain frontal impacts exceeding preset thresholds. Door mounted side impact airbags can provide increased protection to belted front passengers on the impacted side of the vehicle in side impacts exceeding its preset threshold.

## Important!

The operational readiness of the airbag system is verified by the indicator lamp "SRS" in the instrument cluster when turning the electronic key in steering lock to position 1 or 2. If no fault is detected, the lamp will go out after approximately 4 seconds; after the lamp goes out, the system continues to monitor the components and circuitry of the airbag system and will indicate a malfunction by coming on again. If the lamp does not come on at all or if it fails to extinguish after approximately 4 seconds or if it comes on thereafter, a malfunction in the system has been detected.

The following system components are monitored or undergo a self-check: crash-sensor(s), airbag ignition circuits, front seat belt buckles, emergency tensioning retractors, seat sensor.

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
-----------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Restraint systems

Initially, when the electronic key is turned from steering lock position 0 to positions 1 or 2, malfunctions in the crash-sensor are detected and indicated (the "SRS" indicator lamp stays on longer than 4 seconds or does not come on).

Have the system checked at your authorized Mercedes-Benz Center immediately.

In the operational mode, after the indicator lamp has gone out following the initial check, interruptions or short circuits in the airbag ignition circuit and in the driver and front passenger seat belt buckle harnesses, and low voltage in the entire system are detected and indicated.

## Warning!

In the event a malfunction of the "SRS" is indicated as outlined above, the "SRS" may not be operational. For your safety, we strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked; otherwise the "SRS" may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

68

## Front airbags

The driver and front passenger front airbags are designed to activate only in certain frontal impacts exceeding a preset threshold.

The front passenger airbag deploys only if the front passenger seat is occupied and the indicator lamp on the center console is not illuminated.

#### Note:

Heavy objects on the front passenger seat can appear to the "SRS" to indicate the presence of an occupant in that seat which causes the passenger front airbag to deploy in a crash exceeding the appropriate threshold.

## Side impact airbags

The side impact airbags are designed to activate only in certain side impacts exceeding a preset threshold. Only the side impact airbag on the impacted side of the vehicle deploys.

The side impact airbag for the front passenger deploys only if the front passenger seat is occupied.

Side impact airbags operate best in conjunction with a properly positioned and fastened seat belt.

#### Note:

Heavy objects on front passenger seat can cause the side impact airbag to deploy in a crash.

## Important!

Airbags are designed to activate only in certain frontal (front airbags) impacts, or side (side impact airbags) impacts which exceed preset thresholds.

Only during these types of impacts, if of sufficient severity to meet the deployment thresholds, will they provide their supplemental protection.

The driver and passenger should always wear their seat belts, otherwise it is not possible for the airbags to provide their intended supplemental protection.

In cases of other frontal impacts, angled impacts, roll-overs, other side impacts, rear collisions, or other accidents in which the airbags are not designed to deploy, the airbags will not be activated. The driver and passenger will then be protected by the fastened seat belts.

We caution you not to rely on the presence of the airbags in order to avoid wearing your seat belt.

Restrai

Instruments

and controls

int systems	
-------------	--

**Operation** 

69

Instruments and controls

Operation

Driving

Instrument cluster display

Practical hints

Car care

Technical data

70

Restraint systems

#### Warning!

Airbags are designed to reduce the potential of injury in certain frontal (front airbags) impacts, and side (side impact airbags) impacts which may cause significant injuries, however, no system available today can totally eliminate injuries and fatalities.

The activation of the "SRS" temporarily releases a small amount of dust from the airbags. This dust, however, is neither injurious to your health, nor does it indicate a fire in the vehicle. The dust might cause some temporary breathing difficulty for people with asthma or other breathing trouble. To avoid this, you may wish to get out of the vehicle as soon as it is safe to do so. If you have any breathing difficulty but cannot get out of the vehicle after the airbag inflates, then get fresh air by opening a window or door.

Your vehicle was originally equipped with airbags which are designed to activate in certain impacts exceeding a preset threshold to reduce the potential and severity of injury. It is important to your safety and that of your passengers that you replace deployed airbags and repair any malfunctioning airbags to ensure the vehicle will continue to provide crash protection for occupants.

Index

#### Warning!

To reduce the risk of injury when the front airbags inflate, it is very important for the driver and front passenger to always be in a properly seated position and to wear their seat belts.

For maximum protection in the event of a collision always be in normal seated position with your back against the backrest. Fasten your seat belt and ensure that it is properly positioned on your body.

Since the airbag inflates with considerable speed and force, a proper seating and hands on steering wheel position will help to keep you at a safe distance from the airbag. Occupants who are unbelted, out of position or too close to the airbag can be seriously injured by an airbag as it inflates with great force in the blink of an eye:

- Sit properly belted in an upright position with your back against the backrest.
- Adjust the driver seat as far as possible rearward, still permitting proper operation of vehicle controls. The distance from the center of the driver's breastbone to the center of the airbag cover on the steering wheel must be at least ten inches (25 cm) or more. You should be able to accomplish this by a combination of adjustments to the seat and steering wheel. If you have any problems, please see your authorized Mercedes-Benz Center.
- Do not lean with your head or chest close to the steering wheel or dashboard.
- Keep hands on the outside of steering wheel rim. Placing hands and arms inside the rim can increase the risk and potential severity of hand/arm injury when the driver front airbag inflates.
- Adjust the front passenger seat as far as possible rearward from the dashboard when the seat is occupied.

Driving

- Occupants, especially children, should never lean their heads in the area of the door where the side airbag inflates. This could result in serious injuries or death should the airbag be triggered. Always sit upright, properly use the seat belts, and appropriate size infant or child restraint system.
- Children 12 years old and under must never ride in the front seat, except in a Mercedes-Benz authorized BabySmart<sup>™</sup> compatible child seat, which operates with the BabySmart<sup>™</sup> system installed in the vehicle to deactivate the passenger front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury can result.

Failure to follow these instructions can result in severe or fatal injuries to you or other occupants.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

72

Restraint systems

#### Warning!

Accident research shows that the safest place for children in an automobile is in the rear seat. Should you choose to place a child 12 years old or under in the front passenger seat of your vehicle, you must properly use a BabySmart<sup>TM</sup> child restraint which will turn off the passenger side front airbag. BabySmart<sup>TM</sup> will not, however, turn off the passenger's side impact airbag.

It should be noted however that there is a possibility for a side airbag related injury if occupants, especially children, are not properly seated or restrained when next to a side airbag which needs to deploy rapidly in a side impact in order to do its job.

To help avoid the possibility of injury, please follow these guidelines: (1) occupants, especially children, should never place their bodies or lean their heads in the area of the door where the side airbag inflates. This could result in serious injuries or death should the side airbag be activated; (2) always sit upright, properly use the seat belts and use an appropriately sized infant or child restraint system for all children 12 years old or under; and (3) always wear seat belts properly.

Safety guidelines for the seat belt, emergency tensioning retractor and airbag

#### Warning!

- Damaged seat belts or belts that were highly stressed in an accident must be replaced and their anchoring points must also be checked. Use only belts installed or supplied by an authorized Mercedes-Benz Center.
- · Do not pass belts over sharp edges.
- Do not make any modification that could change the effectiveness of the belts.
- Airbags and ETR's are designed to function on a one-time-only basis. An airbag or emergency tensioning retractor (ETR) that was activated must be replaced.

- No modifications of any kind may be made to any components or wiring of the "SRS". This includes changing or removing any component or part of the "SRS", the installation of additional trim material, badges etc. over the steering wheel hub, front passenger airbag cover, or front door trim panels, and installation of additional electrical/electronic equipment on or near "SRS" components and wiring. Keep area between airbags and occupants free of objects (e.g. packages, purses, umbrellas, etc.).
- An airbag system component within the steering wheel gets hot after the airbag has inflated. Do not touch.
- Improper work on the system, including incorrect installation and removal, can lead to possible injury through an unintended activation of the "SRS".
- In addition, through improper work there is the risk of rendering the "SRS" inoperative or causing unintended airbag deployment. Work on the "SRS" must therefore only be performed by an authorized Mercedes-Benz Center.

- For your protection and the protection of others, when scrapping the airbag unit or emergency tensioning retractor, our safety instructions must be followed. These instructions are available at your authorized Mercedes-Benz Center.
- Given the considerable deployment speed and the textile structure of the airbags, there is the possibility of abrasions or other injuries resulting from airbag deployment.

When you sell the vehicle we strongly urge you to give notice to the subsequent owner that it is equipped with an "SRS" by alerting him to the applicable section in the Operator's Manual.

**Restraint systems** 

**Operation** 

**Practical hints** 

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
		_					

Restraint systems

#### Infant and child restraint systems

We recommend all infants and children be properly restrained at all times while the vehicle is in motion. All lap-shoulder belts except the driver's seat belt have special seat belt retractors for secure fastening of child restraints.

To activate, pull shoulder belt out completely and let it retract. During the seat belt retraction a ratcheting sound can be heard to indicate that the special seat belt retractor is activated. The belt is now locked.

To deactivate, release seat belt buckle and let seat belt retract completely. The seat belt can again be used in the usual manner.

#### Warning!

Never release the seat belt buckle while vehicle is in motion, since the special seat belt retractor will be deactivated. 74

#### Important!

The use of infant or child restraints is required by law in all 50 states and all Canadian provinces.

Infants and small children should be seated in an appropriate infant or child restraint system properly secured by a lap-shoulder belt, and that complies with U.S. Federal Motor Vehicle Safety Standard 213 and Canadian Motor Vehicle Safety Standard 213. A statement by the child restraint manufacturer of compliance with this standard can be found on the instruction label on the restraint and in the instruction manual provided with the restraint.

When using any infant or child restraint system, be sure to carefully read and follow all manufacturer's instructions for installation and use.

Please read and observe warning labels affixed to inside of vehicle and to infant or child restraints.

#### Warning!

Children 12 years old and under must never ride in the front seat, except in a Mercedes-Benz authorized BabySmart™ compatible child seat, which operates with the BabySmart™ system installed in the vehicle to deactivate the passenger front airbag when it is properly installed. Otherwise they will be struck by the airbag when it inflates in a crash. If this happens, serious or fatal injury can result.

According to accident statistics, children are safer when properly restrained in the rear seating positions than in the front seating positions. Infants and small children must ride in back seats and be seated in an appropriate infant or child restraint system, which is properly secured with the vehicle's seat belt, fully in accordance with the child seat manufacturer's instructions.

Infants and small children should never share a seat belt with another occupant. During an accident, they could be crushed between the occupant and seat belt.

Children too big for child restraint systems must ride in back seats using regular seat belts. Position shoulder belt across chest and shoulder, not face or neck. A booster seat may be necessary to achieve proper belt positioning for children from 41 lbs. to the point where a lap/shoulder belt fits properly without one.

When the child restraint is not in use, remove it from the vehicle or secure it with the seat belt to prevent the child restraint from becoming a projectile in the event of an accident.


**Restraint systems** 

Index

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Adjusting telescoping steering column

#### Adjusting telescoping steering column



### Warning!

Do not adjust the steering wheel while driving. The telescoping adjustment must be locked while driving. Adjusting the steering wheel while driving, or driving without the telescoping adjustment locked could cause the driver to lose control of the vehicle.

**76** 

#### Unlocking:

Pull handle (1) out to its stop. The indicator lamp, located in the instrument cluster, comes on.

#### Adjusting:

To lengthen or shorten the steering column, pull out or push in steering wheel.

#### Locking:

Push handle (1) in until it engages. The indicator lamp, located in the instrument cluster, goes out.

#### **Important!**

With the electronic key in steering lock position 2, the indicator lamp in the instrument cluster comes on. It should go out when the engine is running.

If the indicator lamp does not go out after starting the engine, the adjustable steering column is not locked properly.

Do not drive the vehicle until you have properly locked the steering column.

#### Inside rear view mirror

Manually adjust the mirror.

Use your inside mirror to determine the size and distance of objects seen in the passenger side convex mirror.

#### Antiglare night position

With the electronic key in steering lock position 2, the mirror reflection brightness responds to changes in light sensitivity.

With gear selector lever in position "R", or with the interior lamp switched on, the mirror brightness does not respond to changes in light sensitivity.

#### Note:

The automatic antiglare function does not react, if incoming light is not aimed directly at sensors in the mirror.

#### Warning!

In the case of an accident liquid electrolyte may escape the mirror housing when the mirror glass breaks.

Electrolyte has an irritating effect. Do not allow the liquid come into contact with eyes, skin, clothing, or respiratory system. In cases it does, immediately flush affected area with water, and seek medical help if necessary.

Rear view mirrors 77

# Practical hints


## Car care

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

78

Rear view mirrors

#### Exterior rear view mirrors



The switch is located on the center console.

Turn electronic key in steering lock to position 2.

First select the mirror to be adjusted – press button:

☐ Left mirror

Right mirror

To adjust, toggle the switch forward, backward or to either side.

With the electronic key in steering lock position 2, the driver's side mirror reflection brightness responds to changes in light sensitivity.

With gear selector lever in position "R", or with the interior lamp switched on, the driver's side mirror brightness does not respond to changes in light sensitivity.

#### Warning!

Exercise care when using the passenger-side mirror. The passenger-side exterior mirror is convex (outwardly curved surface for a wider field of view). Objects in mirror are closer than they appear. Check your inside rear view mirror or glance over your shoulder before changing lanes.

#### Notes:

The exterior mirrors have electrically heated glass. The heater switches on automatically, depending on outside temperature.

If an exterior mirror housing is forcibly pivoted from its normal position, it must be repositioned by applying firm pressure until it snaps into place.

#### Warning!

In the case of an accident liquid electrolyte may escape the mirror housing when the mirror glass breaks.

Electrolyte has an irritating effect. Do not allow the liquid come into contact with eyes, skin, clothing, or respiratory system. In cases it does, immediately flush affected area with water, and seek medical help if necessary.

#### Important!

Electrolyte drops coming into contact with the vehicle paint finish can only be completely removed while in their liquid state, by applying plenty of water.

#### Storing mirror positions in memory

The exterior rear view mirror positions are stored in memory with the seat/head restraint position and can be recalled when necessary, see page 48.

Rear view mirrors

Inst	rument
and	control

#### Instrument cluster display

79

# **Practical hints**

# Car care

Index

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data
Rear view mirrors		8	0			

5 11

## Parking position

The passenger-side exterior mirror can be adjusted and programmed to assist the driver during parking maneuvers (e.g. to observe the curb or other objects close to the vehicle).

With electronic key in steering lock position 2, and the exterior rear view mirror switch in the passenger side position, the passenger-side mirror will be turned downward when placing the gear selector lever in "R" Reverse.

,,

The mirror position can now be adjusted as desired.

Index

At speeds above approx. 6 mph (10 km/h), upon shifting gear selector lever from "R" Reverse, or upon pressing the driver's side mirror button, the passenger-side mirror will return to its previous position.

Readjust the mirror as desired.

One passenger-side mirror position can be stored in memory. To do so:

- Turn electronic key to steering lock position 2.
   The vehicle must be stationary.
- 2. Select passenger-side mirror and adjust the mirror to view the curb.

- 3. Press green memory button located in switch cluster for driver seat, see page 48.
- Within 3 seconds pull the mirror toggle switch rearward. The mirror should not move.
   Repeat the memory procedure if the mirror moves.
- 5. Select driver side mirror. The passenger-side mirror will return to its previous position.


Rear view mirrors

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

82

Instrument cluster

#### **Instrument cluster**



- 1 Push buttons ♠ and ♥ for intensity of instrument lamps, see page 85
- 2 Push button **(B)** for resetting trip odometer, see page 87, or to acknowledge a malfunction or warning message, see page 104.
- 3 Coolant temperature gauge, see page 86
- 4 Fuel gauge with reserve and fuel cap placement warning lamp, see page 230
- 5 Outside temperature indicator, see page 86
- 6 Left turn signal indicator lamp, see combination switch on page 117
- 7 ESP warning lamp, see page 231

- 8 Speedometer
- 9 Trip odometer, see page 87
- 10 Main odometer
- 11 Multifunction indicator, see page 88 or FSS indicator, see page 109 or engine oil level indicator, see page 112
- 12 Right turn signal indicator lamp, see combination switch on page 117
- 13 Tachometer, see page 87
- 14 Gear range indicator display, see selector lever positions on page 198
- 15 Clock, see page 106

**Instrument cluster** 

Index

Operation Driving

Instrument cluster display

Practical hints

Car care

Technical In

Index

# Instrument cluster

### Indicator lamps in the instrument cluster



High beam



ABS malfunction, see page 231



Brake fluid low (except Canada), see page 229 Parking brake engaged, see page 229



Brake fluid low (Canada only), see page 229 Parking brake engaged, see page 229



BAS malfunction, see page 231 ESP malfunction, see page 231 and 245



ESP. Adjust driving to road condition, see page 220



Fasten seat belts, see page 232

84



Telescoping steering column not locked, see page 232



SRS malfunction, see page 230



If the "CHECK ENGINE" malfunction indicator lamp comes on when the engine is running, it indicates a malfunction of the fuel management system, emission control system, systems which impact emissions, or the fuel cap is not closed tight. In all cases, we recommend that you have the malfunction checked as soon as possible, see page 228.

#### Function indicator lamp on the center console



Front passenger airbag automatically switched off, see page 64.

#### Activating instrument cluster display

The instrument cluster is activated by:

- · Opening the door.
- Pressing button 
   ⊕, 
   or 
   on the instrument cluster.
- Turning the electronic key in steering lock to position 1 or 2.
- Switching on the exterior lamps.


#### **Display illumination**

The display for temperature, odometer, multifunction indicator, FSS indicator and clock is illuminated briefly when opening the driver's door.

The display illumination brightness responds automatically according to changes in the surrounding light sensitivity.

To briefly illuminate the display (with electronic key removed or in steering lock position 0), press button  $\blacksquare$ .

#### **Instrument lamps**



Activate the instrument cluster.

Press ♠ or ♥ button to vary intensity of instrument lamps.

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Instrument cluster

86

#### Coolant temperature gauge (3)

During severe operating conditions and stop-and-go city traffic, the coolant temperature may rise close to the red marking.

The engine should not be operated with the coolant temperature in the red zone. Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

#### Warning!

- Driving when your engine is badly overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.
- Steam from an overheated engine can cause serious burns and can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the vehicle and do not stand near the vehicle until it cools down.

#### Outside temperature indicator (5)

The temperature sensor is located in the front bumper area. Due to its location, the sensor can be affected by road or engine heat during idling or slow driving. This means that the accuracy of the displayed temperature can only be verified by comparison to a thermometer placed next to the sensor, not by comparison to external displays (e.g. bank signs etc.).

Adaptation to ambient temperature takes place in steps and depends on the prevailing driving conditions (stop-and-go or moderate, constant driving) and amount of temperature change.

#### Warning!

The outside temperature indicator is not designed to serve as an Ice-Warning Device and is therefore unsuitable for that purpose. Indicated temperatures just above the freezing point do not guarantee that the road surface is free of ice.

#### Trip odometer (9)

To reset to "0" miles/km:

Activate the instrument cluster if it is not already activated by pressing the **B** button on the instrument cluster.

Press button or on the multifunction steering wheel repeatedly until the trip odometer appears if it is not displayed. See page 92.

Press button **(A)** on the instrument cluster to reset trip odometer.

#### Tachometer (13)

The red marking on tachometer denotes excessive engine speed.

Avoid this engine speed, as it may result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

To help protect the engine, the fuel supply is interrupted if the engine is operated within the red marking.

Instrument cluster




**Practical hints** 

Multifunction steering wheel, multifunction display

88

#### Multifunction steering wheel, multifunction display



Depending on your vehicle's equipment, you may use the buttons on the multifunction steering wheel to call up, control and set the following systems in the multifunction display:

- 1 Trip odometer and main odometer, see page 92
  Vehicle speed, see page 92
  Flexible service system (FSS), see page 109
  Engine oil level indicator, see page 112
- 2 Audio systems, see page 93

Radio, see page 93 CD player (optional), see page 94 Cassette player, see page 95

- 3 Navigation system (optional), see page 101
- 4 Malfunction message memory, see page 104
- 5 Individual settings, see page 106
- 6 Trip computer, see page 102

After start After reset Fuel tank content

7 Telephone (if so equipped), see page 96

Press the press

Pressing the button advances the display to the next system.

Pressing the button returns the display to the previous system.

You may call up additional displays within some of these categories by pressing the  $\triangle$  or  $\heartsuit$  button.

#### Warning!

A driver's attention to the road must always be his/her primary focus when driving.

For your safety and the safety of others, selecting features through the multifunction steering wheel should only be done by the driver when traffic and road conditions permit it to be done safely. Programming individual settings in the system can only be made while the vehicle is at standstill.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

#### Multifunction steering wheel, multifunction display



- 1 Multifunction steering wheel
- **2** Multifunction display

90

Turn the electronic key in steering look to position 1 or 2.

#### Press button:

- 3 for next system
- 4 for previous system
- 5 for next display in system
- 6 for previous display in system
- 7 to increase the volume
- **8 —** to decrease the volume
- 9 to dial a telephone number, see page 96 See page 100 for instructions on answering an incoming call.
- 10 so to end a call

Press the or button repeatedly until the required system is displayed.

Pressing the button advances the display to the next system.

Pressing the button returns the display to the previous system.

You may call up additional displays in some systems by pressing the  $\triangle$  or  $\heartsuit$  button.

#### Note:

The displays in the multifunction display can be set to German, English, French, Italian or Spanish language. See the "TEXT" individual setting on page 106 for instructions on changing the language setting.

The displays for the audio systems (radio, CD player, cassette player) will appear in English, regardless of the language selected.

Multifunction steering wheel, multifunction display

Inst	rume	ents
and	cont	ral


**Practical hints** 

91

Index

Multifunction steering wheel, multifunction display

# Trip and main odometer, vehicle speed, FSS and engine oil level indicator



92

- 1 Trip odometer and main odometer See page 87 for instructions on resetting the trip odometer.
- 2 Vehicle speed
- **3** FSS (Flexible service system), see page 109.
- **4** Engine oil level indicator, see page 112.


Press or button repeatedly until the trip odometer and main odometer display (1) appears.

Press the  $\triangle$  or  $\bigcirc$  button repeatedly until the required display (2, 3, 4, 1) appears.

Pressing the or button displays the next or previous system.

#### Audio systems

#### Radio



**Driving** 

- 1 Audio system is switched off.
- **2** The radio is switched on.
- 3 Wave band setting and memory location number, where appropriate.
- 4 Station frequency.
- 5 This only appears when "MEMORY" rather than "FREQUENCY" has been selected in the individual settings. See page 106.

The radio must be switched on.

Press the or button repeatedly until display (2) appears.

Press button or repeatedly until the required station or frequency is displayed.

Use the \( \sigma \) of \( \sigma \) button to select a stored station or station frequency. This depends on the selection made in the "STATION SEARCH USING" setting menu. See page 106.

Pressing the previous system.

Instruments and controls

Operation

Driving

Instrument cluster display


Practical hints

Car care

are Technical data

Multifunction steering wheel, multifunction display

### CD player (optional)



94

- **1** Audio system is switched off.
- **2** The CD player is switched on.
- **3** The number of the CD currently playing is displayed if you are using a CD changer.
- 4 Track number.

The radio must be switched on.

The CD player must be switched on.

Press the or button repeatedly until display (2) appears.


Press the or button repeatedly until the required track number (4) is displayed.

Pressing the or button displays the next or previous system.

#### Note:

To select a CD from the magazine, press a number on the audio system or the (optional) COMAND system key pad located in the center dashboard.

#### Cassette player



**Driving** 

- 1 Audio system is switched off.
- **2** The cassette player is switched on.
- **3** Side being played.

The radio must be switched on.

The cassette player must be switched on.

Press the or button repeatedly until display (2) appears.

Pressing the button fast forwards on to the next track.

Pressing the button rewinds the cassette to the beginning of the current track.

Pressing the or button displays the next or previous system.

#### Note:


To select the reverse side of the tape, press button below track number on the audio system display, or enter request on the (optional) COMAND system located in the center dashboard.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Multifunction steering wheel, multifunction display

### Telephone

#### Telephone book



96

- 1 The telephone is switched off.
- 2 The vehicle is currently outside the transmitter or receiver range.
- **3** The telephone is ready for use.
- 4 Name selected from the telephone book.
- **5** Number for the name selected. Dialing commences.
- **6** Dialing is completed. The name is displayed. The display remains for the duration of the call.
- **7** Duration of call.
- 8 Memory location number.

The telephone must be switched on.

Press the or button repeatedly until the display (3) appears. Refer to the separate telephone instruction manual.

Pressing  $\triangle$  or  $\heartsuit$  "browses" alphabetically forwards or backwards through the telephone book, providing it was previously downloaded. See telephone operator's manual for details concerning downloading. Pressing button  $\triangle$  or  $\nabla$  for longer than a second "browses" rapidly through the telephone book. The name selected appears in the display.

Note:

Press the button if you do not wish to make a call.

The procedure is cancelled and display (3) appears.

Press the button when the name you require appears in the display (4). The telephone number (5) is dialed.

The name will be displayed when dialing is completed. Display (6) remains for the duration of the call.


Pressing the button hangs up and display (3) appears.

Pressing the or button displays the next or previous system.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Technical data

Multifunction steering wheel, multifunction display

#### Redialing



98

- 1 The telephone is ready for use.
- **2** Number or name stored in the redial memory.

Index

- 3 Number in the redial memory redialing has commenced.
- 4 Dialing is completed and the name stored in the telephone book is displayed or the number dialed will remain displayed if no name has been stored. The display remains for the duration of the call.
- **5** Duration of call.
- Memory location numbers the 10 most recently dialed numbers are stored.
  L0, most recently dialed number,
  L1 to L9, previously dialed numbers.

The telephone must be switched on.

Press the or button repeatedly until the display (1) appears.

Pressing the button activates the redial memory and the most recently dialed number is displayed.

Pressing the or button "browses" forwards or backwards through the redial memory. The number selected appears in the display.

Note:

Instruments

and controls

Press the button if you do not wish to make a call.

Driving

The procedure is cancelled and display (1) appears.

Press the button when the required number or name appears in the display (2).

The telephone number (3) is dialed.

Once dialing is completed the name (4) is displayed if the name is stored in the telephone book; failing that the number dialed will remain displayed. The display remains for the duration of the call.

Pressing the button hangs up and display (1) appears.

Pressing the or button displays the next or previous system.

**Operation** 

Instrument

cluster display

Instruments	
and controls	

# Operation

# Driving

cluster display

Instrument

Multifunction steering wheel, multifunction display

#### **Incoming call**



The telephone must be switched on.

100

**Practical hints** 

**1** "CALL" – you are being called

Press the button to answer the call.

Press the button to hang up or if you do not wish to answer the incoming call.


Car care

**Technical** 

data

Index

#### Navigation system (optional)



- 1 The navigation system is switched off.
- 2 The navigation system is switched on but no destination has been specified.
- **3** The navigation system is switched on and destination guidance is active.

Press the or button repeatedly until the required system is displayed.


See the separate COMAND (Cockpit Management and Data System) operator's manual for notes on the navigation system.

Pressing the previous system.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Multifunction steering wheel, multifunction display

#### Trip computer



#### 102

- 1 "AFTER START" trip odometer records distance from first engine start after more than five hours of electronic key not being in steering lock position 2
- 2 "AFTER RESET" trip odometer records distance from first engine start until reset
- 3 Estimated driving range remaining and fuel tank contents
- 4 Distance covered "AFTER START" respectively "AFTER RESET"
- 5 Elapsed time "AFTER START" respectively "AFTER RESET"
- 6 Average speed "AFTER START" respectively "AFTER RESET"
- 7 Average fuel consumption "AFTER START" respectively "AFTER RESET"

Press the button or repeatedly until the display (1) appears.

Press the or button until the display for trip odometer memory "AFTER START" (1) and "AFTER RESET" (2), or the display (3) for estimated driving range remaining and fuel tank contents appears.

#### Important!

The reading in the display "TANK CONTENT" might be off by approximately +/- 2.2 US qt (2 l). Please refuel in time.

Pressing the or button displays the next or previous system.

Note:

The "AFTER START" display (1) always appears when the trip computer is called up.

Driving

To reset the "AFTER START" (1) or "AFTER RESET" (2) odometer memory at any time:


Call up the relevant display (1 or 2) using the or button and press the button in the instrument cluster until the values are reset to "0".

The "AFTER START" trip odometer reading is automatically reset after four hours of electronic key not being in steering lock position 2.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care data

 $\label{eq:multifunction} \mbox{ Multifunction steering wheel, multifunction display}$ 

#### Malfunction message memory



104

1 There are no messages stored in the system

Index

2 Number of messages stored in the system

Press the or button repeatedly until the malfunction message memory (1 or 2) is displayed.

Press the or button if display (2) appears. The stored malfunction messages will now be displayed in order. See page 234 for malfunction and warning messages. Display (2) will reappear after you have scanned all the malfunction messages.

Should any malfunctions be stored while driving, they will reappear in the display (2) when the electronic key is in steering lock position 0 or removed from the steering lock.

Specific malfunctions can be recalled by pressing button **B**. Each malfunction or warning message must be acknowledged by pressing button **a**. Once all messages are cancelled, the odometer display should reappear.

Pressing the **A** button in the instrument cluster immediately switches to the next malfunction message.

The malfunction message memory will be cleared when the electronic key is turned in the steering lock to position 1 or 2. Should any subsequent malfunctions occur, they will be displayed in the malfunction message memory.

Pressing the or button displays the next or previous system.

#### Important!

Malfunction and warning messages are only indicated for certain systems and displayed to a low level of detail.

The malfunction and warning messages are simply a reminder with respect to the operation of certain systems and do not replace the driver's responsibility to maintain the vehicle's operating safety by having all required maintenance and safety checks performed on the vehicle and by bringing the vehicle to an authorized Mercedes-Benz Center to address the malfunction and warning messages. See page 228.

Multifunction steering wheel, multifunction display

1	0	5
---	---	---


#### **Technical** data

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Multifunction steering wheel, multifunction display

106

## **Individual settings**



- 1 Preliminary display of the individual settings
- 2 "SET TIME HOURS"
  (Only vehicles without COMAND)
- 3 "SET TIME MINUTES"
  (Only vehicles without COMAND)
- 4 "12/24 HOURS" the unit set is displayed in the instrument cluster (Only vehicles without COMAND)
- 5 "TEMP. INDICATOR" the unit set is displayed in the outside temperature display in the instrument cluster and in the automatic air conditioner display
- 6 "DISPLAY VALUES IN" the unit set is displayed in the trip and main odometer
- 7 "TEXT" sets the language used in the multifunction display

- 8 "STATION SEARCH USING" radio adjustment
  - "FREQUENCY" use the △ or ⋄ button to select a frequency
  - "MEMORY" use the ♠ or ♥ button to select a stored station (preset memory)
- 9 See page 108 for instructions on returning the setting menus to the factory settings
- 10 Selection marker indicates the setting selected

#### Notes:

These settings may only be performed with the vehicle at standstill and with the key in steering lock position 1 or 2.

Multifunction steering wheel, multifunction display

Index

Operation

Driving

Instrument cluster display

Practical hints

Car care

Technical data

Index

Multifunction steering wheel, multifunction display

Press the for button repeatedly until the individual setting preliminary display (1) appear.

Press the or button until the required setting menu (2 to 8) is displayed.

Pressing the or button sets the time in setting menus (2, 3) and controls the selection marker in setting menus (4 to 8).

The settings made are stored and applied immediately.

The individual setting preliminary display (1) will appear again after you have run through all the setting menus.

Pressing the or button displays the next or previous system.

#### Notes:

Settings can only be selected with the vehicle stationary or moving slowly.

The individual setting preliminary display (1) will appear if you speed up.

The setting menu previously called up will reappear when the vehicle stops or slows down, providing no other system has been called up in the meantime. 108

To return setting menus (4 to 8) to their factory settings:

- Call up the individual setting preliminary display (1).
- Press the **B** button in the instrument cluster for approximately 3 seconds. Display (9) will appear.
- Press the **(B)** button once more, the message "RESET TO FACTORY SETTINGS" appears in the display.

The individual setting preliminary display (1) will appear if you do not press the **\( \mathbb{B} \)** button within about 5 seconds. The setting menus will not be reset.

#### Setting the audio volume

You can only adjust the volume of the system currently in use. The volume setting for each system (audio, telephone, navigation and voice recognition system) is stored separately.

Setting button:

increases the volume.

reduces the volume.

# Flexible service system (FSS) (service indicator)



The FSS permits a flexible service schedule that is directly related to the operating conditions of the vehicle.

The symbol or appears together with a message in the multifunction indicator prior to the next suggested service. Depending on operating conditions throughout the year, the next service is calculated and displayed in days or distance remaining.

The message is displayed for approx. 10 seconds when turning the electronic key in steering lock to position 2, or while driving when reaching the service warning threshold.

The symbols and messages indicate the type of service to be performed:

Service A

Service B

One of the following messages will appear in the display (e.g. Service A):

"SERVICE A - IN xx DAYS"

"SERVICE A - IN xx MILES" (Canada: KM)

"SERVICE A - EXCEEDED BY xx DAYS"

"SERVICE A – EXCEEDED BY xx MILES" (Canada: KM)

"SERVICE A - DUE NOW"

The next service due date is displayed either in days or in miles, depending on your driving style.

Once the suggested service term has passed, the symbol and message appear for approx. 30 seconds and a signal sounds every time when turning the electronic key in steering lock to position 2.

and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Flexible servi	ce system		11	10			

The service indicator disappears automatically after 30 seconds or if button **(B)** on the instrument cluster is pressed.

Calling up service indicator manually:

Turn the electronic key in steering lock to position 1.

Call up the trip odometer and main odometer, by pressing button or on the multifunction steering wheel until the display appears. See page 92.

Press button ♦ or ♥ until the FSS indicator appears.

Pressing the or button displays the next or previous system.

### **Important!**

The FSS indicator is not an engine oil level indicator. See page 112 for engine oil level indicator.

Notes:

When disconnecting vehicle battery for one or more days at a time, such days will not be counted. Any such days not counted by the FSS can be added by your Mercedes-Benz Center.

The interval between services is determined by the type of driving for which the vehicle is used. For example, driving at extreme speeds, and cold starts combined with short distance driving in which the engine does not reach operating normal temperature, reduce the interval between services.

Following a completed A or B service the Mercedes-Benz Center sets the counter mileage to 10 000 miles (Canada: 15 000 km) and 365 days.

The counter can also be set by any individual. To do so:

Turn the electronic key in steering lock to position 2.

To call up the trip odometer and main odometer, press button or on the multifunction steering wheel until the display appears. See page 92.

Press button  $\bigcirc$  or  $\bigcirc$  until the FSS indicator appears.

Press button **(B)** on the instrument cluster for approximately 2 seconds.

The multifunction display will show the question: "DO YOU WANT TO RESET SERVICE INTERVAL? – CONFIRM BY PRESSING R"

Press button **(B)** on the instrument cluster again, and hold until a signal sounds. The message "SERVICE INTERVAL HAS BEEN RESET" appears in the multifunction display.

The new service indicator is displayed with the reset distance of 10 000 miles (Canada 15 000 km).

If the FSS counter was inadvertently reset, have a Mercedes-Benz Center correct it.

However you choose to set your reference numbers, the scheduled services as posted in the Service Booklet must be followed to properly care for your vehicle.

Flexible service system



Inst	ruments
and	controls

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Engine oil level indicator

## Engine oil level indicator



To check the engine oil level, park vehicle on level ground, with engine at normal operational temperature.

Check oil level approximately 5 minutes after stopping the engine, allowing for the oil to return to the oil pan. 112

Turn the electronic key in steering lock to position 2.

To call up the trip odometer and main odometer, press button or on the multifunction steering wheel until the display appears. See page 92.

Press button or on the multifunction steering wheel repeatedly until the "MEASUREMENT CORRECT – ONLY IF VEH. LEVEL" engine oil level indicator appears. This indicator is only a reminder. Measurement can be cancelled by pressing button or if the vehicle is not parked on level ground. An incorrect reading will be recorded if you do not cancel the measurement. Move the vehicle to level ground and measure again.

The electronic key in steering lock is not in position 2 if the "ENGINE OIL LEVEL – SWITCH ON IGNITION" message appears.

The "ENGINE OIL LEVEL - MEASURING NOW" message is displayed after approximately 3 seconds.

One of the following messages will subsequently appear on the indicator:

"ENGINE OIL LEVEL - O.K."

No oil needs to be added.

"ENGINE OIL LEVEL - ADD 1.0 QUART"

(Canada: 1.0 L)

"ENGINE OIL LEVEL - ADD 1.5 QUART"

(Canada: 1.5 L)

"ENGINE OIL LEVEL - ADD 2.0 QUART"

(Canada: 2.0 L)

See page 256 for instructions on adding engine oil.

"ENGINE OIL LEVEL - REDUCE OIL LEVEL"

Do not overfill the engine.

Excessive oil must be siphoned or drained off. It could cause damage to the engine and catalytic converter not covered by the Mercedes-Benz Limited Warranty.

The message "PERF. SERV. ON TIME" (perform service [engine oil level check] on time) will be displayed if a proper oil level check cannot be performed. The engine oil level check can be repeated after a short time.

Perform the engine oil level check with the dipstick, if it cannot be completed via the multifunction display. See page 256.

In this case we recommend that you have the system checked at a Mercedes-Benz Center.

#### Note:

See malfunction and warning messages on page 234 and page 244 if an engine oil level indicator appears on the multifunction display when the engine is running.

The engine oil level cannot be checked while the engine is running. The "ENGINE OIL LEVEL – NOT WHEN ENGINE ON" message will appear.

#### **Engine oil consumption**

Engine oil consumption checks should only be made after the break-in period. During the break-in period, higher oil consumption may be noticed and is normal. Frequent driving at high engine speeds results in increased consumption.

Engine oil level indicator

113

Inst	ruments
and	controls

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

## Exterior lamp switch

### Exterior lamp switch



- O Off
- Parking lamps (also side marker lamps, taillamps, license plate lamps, instrument panel lamps)
  Canada only: When the engine is running, the low beam is additionally switched on.

#### 114

- Parking lamps plus low beam or high beam headlamps (combination switch pushed forward)
- Ps- Standing lamps, right (turn left one stop)
- **→P** Standing lamps, left (turn left two stops)
- Front fog lamps (pull out one stop) with parking lamps and/or low beam headlamps on. Green indicator lamp in lamp switch comes on.
- Rear fog lamp (pull out to 2nd detent) in addition to fog lamps. Yellow indicator lamp in lamp switch comes on.

#### Standing lamps

When the vehicle is parked on the street the standing lamps (right or left side parking lamps) can be turned on, making the vehicle more visible to passing vehicles.

The standing lamps cannot be operated with the electronic key in steering lock position 2.

#### Notes:

With the electronic key removed and the driver's door open, a warning sounds and the message "SWITCH OFF LIGHTS" in the multifunction indicator appears if the vehicle's exterior lamps (except standing lamps) are not switched off.

Fog lamps will operate with the parking lamps and/or the low beam headlamps on. Fog lamps should only be used in conjunction with low beam headlamps. Consult your State or Province Motor Vehicle Regulations regarding allowable lamp operation.

Fog lamps are automatically switched off when the exterior lamp switch is turned to position .

#### Daytime running lamps (Canada only)

When the engine is running and the selector lever is in a driving position, the low beam headlamps (includes parking lamps, side marker lamps, taillamps and license plate lamps) are automatically switched on.

When shifting from a driving position to position "N" or "P", the low beam switches off (2 seconds delay).

For nighttime driving the exterior lamp switch should be turned to position to permit activation of the high beam headlamps.

#### Night security illumination

When exiting the vehicle after driving with the exterior lamps on, they switch on again for added illumination for approximately 30 seconds after closing the last door. The lamp-on time period can be changed at your Mercedes-Benz Center.

Exterior lamp switch

## Technical data

Index

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 factical fiffics	Car care	data	mucx

Headlamp cleaning system

## Headlamp cleaning system (optional)




116

The switch is located in the center console.

Briefly press symbol side of switch.

The headlamp washer can be activated with the electronic key in steering lock position 2.

#### **Combination switch**



- 1 Low beam (exterior lamp switch position )
- 2 High beam (exterior lamp switch position D)

- 3 High beam flasher (high beam available independent of exterior lamp switch position)
- 4 Turn signals, right
- 5 Turn signals, left

To signal minor directional changes, such as changing lanes on a highway, move combination switch to the point of resistance only and hold it there.

To operate the turn signals continuously, move the combination switch past the point of resistance (up or down). The switch is automatically canceled when the steering wheel is turned to a large enough degree.

### Turn signal failure

If one of the turn signals fails, the turn signal indicator system flashes and sounds at a faster than normal rate.

Combination switch




#### Technical data

Index

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

#### Combination switch



**6** Control for windshield wiper/washer system:

Push briefly for single wipe without adding washer fluid (use only when windshield is wet).

Push past detent and hold to activate wiper and washer.

#### Notes:

The windshield washer reservoir, hoses and nozzles are automatically heated.

See page 259 for refilling windshield washer/headlamp cleaning system.

#### 118

- 7 Windshield wiper
  - 0 Wiper off
  - I Intermittent wiping (optional rain sensor: One initial wipe, pauses between wipes are automatically controlled by a rain sensor monitoring the wetness of the windshield.)

#### Notes:

With switch in this position, one wipe occurs when turning the electronic main key in steering lock from position 0.

#### Optional rain sensor:

Do not leave in intermittent setting when vehicle is taken to an automatic car wash or during windshield cleaning. Wiper will operate in presence of water spray at windshield, and wiper may be damaged as a result.

- II Normal wiper speed
- III Fast wiper speed

#### Windshield wiper smears

If the windshield wiper smears the windshield, even during rain, activate the washer system as often as necessary. The fluid in the washer reservoir should be mixed in the correct ratio, see page 259.

#### **Blocked windshield wiper**

If the windshield wiper becomes blocked (for example, due to snow), switch off the wiper.

For safety reasons before removing ice or snow, remove electronic key from steering lock. Remove blockage.

Activate combination switch again (electronic key in steering lock position 1).

#### Hazard warning flasher switch



The hazard warning flasher can be activated with the switch located in the dashboard.

To activate hazard warning flasher, press switch once. To deactivate, press switch again.

#### Note:

With the hazard warning flasher activated, the combination switch in position for either left or right turn, and the electronic main key in steering lock position 2, only the respective left or right side turn signals will operate.

Hazard warning flasher

119

Inst	ruments
and	controls

### Technical data


Index

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Automatic climate control

120

## **Automatic climate control**



- 1 Air volume control for center air outlets, turn wheel up to open.
- 2 Air volume control for side air outlet.

To open air outlets: Turn wheel to position

- 3 Center air outlet, adjustable
- 4 Side air outlet, adjustable
- **5** Display and controls

The system is always at operational readiness, except when manually switched off.

The automatic climate control only operates with the engine running.

Driving

The temperature selector should be left at the desired temperature setting. The temperature selected is reached as quickly as possible.

The system will not heat or cool any quicker by setting a higher or lower temperature.

The automatic climate control removes considerable moisture from the air during operation in the cooling mode. It is normal for water to drip on the ground through ducts in the underbody.

The desired interior temperature can be selected separately for the left and right side of the passenger compartment.

Automatic climate control



Index

#### Automatic climate control

## Display and controls



Press the desired button to activate, indicator lamp is on while activated.

Automatic mode

Raise temperature

Lower temperature

#### 122

₩ Defrost

Air recirculation

Rear window defroster

Air distribution, manual

Economy mode

. ⊗ ∴ Air volume, manual

REST Residual engine heat utilization

## $Basic\ setting\ \hbox{--}\ automatic\ mode$

Press left and right button for automatic mode.

Simultaneously press both and buttons for temperature setting of 72°F.



Air volume and distribution are controlled automatically.

This setting can be used all year around.

#### **Economy**

The function of this setting corresponds to the automatic mode. However, because the air conditioning compressor will not engage (fuel savings), it is not possible to air condition in this setting.

Press **EC** button to activate.

Press **EC** button once again to return to previous setting.

### Special settings (use only for short duration)

#### **Defogging windows**

Switch off button.

Press left and right AUTO buttons.

Press button repeatedly until air is directed upward.



Turn wheels (2) to position \_\_\_\_\_ to open left and right side air outlets (4). Adjust side air outlets upward.

#### **Defrosting**

Turn wheels (2) to position \_\_\_\_\_ to open left and right side air outlets (4). Adjust side air outlets upward.

Press button. Maximum heated and automatically controlled amount of air is directed to the windshield and side windows.



Press button once again to return to previous setting.

Operation

Instrument Driving cluster display

**Practical hints** 

Car care

**Technical** Index

data

## Automatic climate control

#### Rear window defroster

Turn electronic key in steering lock to position 2.

To select, press the button.

To cancel, press button again.

## Notes:

Heavy accumulation of snow and ice should be removed before activating the defroster.

The rear window defroster consumes a large amount of electrical power. To keep the battery drain to a minimum, turn off the defroster as soon as the window is clear.


The defroster is automatically turned off after a maximum of 12 minutes of operation.

If several power consumers are turned on simultaneously, or the battery is only partially charged, it is possible that the defroster will automatically turn itself off. When this happens, the indicator lamp inside the switch starts blinking.

As soon as the battery has sufficient voltage, the defroster automatically turns itself back on.

## 124

#### Air distribution



Press button for each side repeatedly until the requested symbol is displayed.

Press Auto button to return to automatic mode.

#### Air volume

Press – or + side of rocker switch with until the requested blower speed is attained. A choice of 7 blower speeds is available.

To switch the automatic climate control off, press – side of rocker switch with until symbol OFF is displayed.



The fresh air supply to the vehicle interior is shut off.

While driving, use this setting only temporarily, otherwise the windshield could fog up.

To switch the automatic climate control on again, press AUTO, or +side of \*\*.

#### Air recirculation

This mode can be selected to temporarily reduce the entry of annoying odors or dust into the vehicle's interior.

Outside air is not supplied to the vehicle's interior.

To select, press 🖘 button.

To cancel, press button again.

The system will automatically switch from recirculated air to fresh air

- after approx. 5 minutes at outside temperatures below approx. 40°F (5°C),
- after approx. 30 minutes at outside temperatures above approx. 40°F (5°C),
- after approx. 5 minutes, if button **EC** is pressed.

If the windows should fog up from the inside, switch from recirculated air back to fresh air.

At high outside temperatures, the system automatically engages the recirculated air mode thereby increasing the cooling capacity performance, switching to partially fresh air within 30 minutes.

#### Residual engine heat utilization

With the engine switched off, it is possible to continue heating the interior for a short while.

Air volume and distribution are controlled automatically.

To select:

Turn electronic key in steering lock to position 1 or 0 or remove key.

Press REST button

This function selection will not activate if the battery charge level is insufficient.

To cancel:

Press REST button.

The system will automatically shut off

- if you turn electronic key in steering lock to position 2,
- · after approx. 30 minutes,
- if the battery voltage drops.

Automatic climate control

[nst	ruments
and	controls

## Technical data

and controls	Operation	Dilving	cluster display	Tractical lillies	Cui cui c	data	Index
Automatic climate control		12	26				
ъ.	4 6.14			T 4 41			

Instrument

## Dust filter

Operation

Nearly all dust particles and pollen are filtered out before outside air enters the passenger compartment through the air distribution system.

Driving

Note:

**Instruments** 

Keep the air intake grille in front of windshield free of snow and debris.

## Important!

Practical hinte

This vehicle is equipped with an air conditioner system that uses R-134a (HFC: hydrofluorocarbon) as a refrigerant. Repairs should always be performed by a qualified technician, and refrigerant should be collected in a recovery system for recycling.

Car cara

**Technical** 

Indov

#### Audio and telephone, operation

These instructions are intended to help you become acquainted with your Mercedes-Benz vehicle radio. They contain useful tips and a detailed description of the user functions.

#### Warning!

In order to avoid distraction which could lead to an accident, system settings should be entered with the vehicle at standstill and systems should be operated by the driver only when traffic conditions permit. Always pay full attention to traffic conditions first before operating system controls while driving.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of approximately 50 feet (approximately 14 m) every second.

The right to correct errors and make technical amendments is reserved

#### **Operating safety**

#### Warning!

Any alternations made to electronic components can cause malfunctions.

The radio, cassette deck, CD changer<sup>1</sup> and telephone<sup>1</sup> are interconnected. Therefore, when one of the components is defective or has not been removed/replaced properly this may impair the function of other components.

These malfunctions might seriously impair the operating safety of your vehicle.

We recommend that you have any service work or alternations on electronic components done in an authorized Mercedes-Benz Center.

#### 1 Optional equipment

Dolby and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. The Dolby noise reduction system is manufactured under licence from Dolby Laboratories Licensing Corporation.

Audio system 127

#### Technical data

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 factical innes	Cui cui c	data	muca

Audio system 128

## **Operating and display elements**



- 1 On/off, volume, see page 131
- **2** Telephone mode selector, see page 143
- **3** Seek, see page 133, 137 and 141
- 4 Radio mode selector, see page 133
- **5** Tune, see page 133 and 134 Fast forward/reverse, see page 137
- 6 CD mode selector, see page 140

- 7 Display panel The cassette slot is located behind the display panel. For notes on playing cassettes, see page 135.
- 8 Alpha-numeric keypad for station storage and frequency entry, see page 134 CD/Track access, see page 142 optional telephone, see page 143
- **9** Function button, see page 134 and 142


- 10 Soft keys for
  radio band selection, see page 133
  tone controls, see page 131
  scan, see page 134
  Tape eject, see page 136
  Tape track select, see page 136
  Dolby, see page 138
  CD Random/repeat, see page 142
- 11 Tape mode selector, see page 135

#### **Anti-theft system**

## CODE

If the power supply to the radio has been interrupted, "CODE" will appear on the display when it is next switched on. The radio will

only work after the five-digit code has been entered using the buttons on the right-hand control panel.



The code number is shown on the Radio code card, supplied with the radio.

#### Important!

Never leave the Radio code card in the vehicle. Keep it in a safe place.

Audio system 129

Instruments	Operation	ion Driving Instrum	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 Tactical IIIIts	Cai cai e	data	Illuex

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Audio system			13	30			
Entering the code number			Button and soft	key operation			

Instrument

Switch on the radio. "CODE" will appear on the display. Using the buttons on the alpha-numeric keypad, enter the five digit code. Confirm by pressing the "OK" key.

If an incorrect code has been entered and confirmed, "CODE" will reappear on the display. The correct code must be entered once again.

WAIT

If an incorrect code is entered three times, "WAIT" will appear on the display and the radio will be locked out for about 10 minutes.

Note:

**Instruments** 

The lock out time will only count down if the radio is left switched on.

In these instructions, the alpha-numeric keypad (right side of radio face) and the function buttons (left side of the radio face) are referred to as "buttons" and the four keys under the display are referred to as "soft keys".

**Technical** 

Note:

Do not press directly on the radio display face.

#### **Operation**

### Switching on and off

Press the control knob .

The radio is switched off when the ignition key is turned to position 0 or removed from the ignition. The radio is switched on again when the ignition key is turned to position 1 or 2.

#### Note:

The radio can also be switched on even if the ignition key is not inserted, but will switch itself off automatically after one hour to conserve vehicle battery power.

#### Adjusting the volume

Turn the control knob - turning the knob clockwise will increase the volume, counterclockwise will decrease the volume.

#### **Audio functions**

The AUD key is used to select the BASS, TREBLE and BALANCE functions. Settings for bass and treble are stored separately for the cassette and CD modes. Tone level settings are identified by the vertical bars. The center (flat) setting is shown by one longer bar in the center of the display.

#### Bass



Press the AUD key repeatedly until "BASS" appears in the display.

#### Treble



Press the AUD key repeatedly until "TREBLE" appears in the display.

Press the "+" key to increase decrease the level

or the "-" key to decrease the level.

Audio system

131

Operation Driving

Instrument cluster display

Practical hints

Car care

Technical data

Index

Audio system

Fader<sup>1</sup>



Press the AUD key repeatedly until "FADER" appears on the display. Press the "R" key to move the sound to the rear speakers or the "F" key to

move the sound to the front speakers.

### **Balance**



Press the AUD key repeatedly until "BALANCE" appears in the display.

Press the "L" key to move the

sound to the left speaker or the "R" key to move the sound to the right speaker.

1 not available on all models

## 132

## Centering all audio functions

RESET

Push and hold down the "AUD" key. All audio functions (bass, treble, balance and fader) are set to center or flat positions, and

the volume is adjusted to a pre-set level.

#### Radio mode

### Selecting radio mode

Press BADIO button.

#### Selecting the band

FM5 ST 95.5 MHz AM WB AUD SC

Press the key located below the desired band. The band selected is shown in the top line of the display.

AM4 880 kHz FM WB AUD SC

Frequency ranges: FM87.9 - 107.9 MHz

> AM530 - 1710 kHz

WB approx. 162 MHz

#### Manual tuning

WB1 CH 1 FM AM AUD SC

Press either the  $\triangle$  or  $\nabla$ button. Step-by-step tuning in ascending or descending order of frequency will take place.

The first three tuning steps will take place without muting. The radio will then be muted and high-speed tuning will take place until the button is released. The following tuning intervals will be shown on the display:

FM 200 kHz

AM10 kHz

WB Channels 1-7

#### Seek tuning

Press either the or button. The radio will tune to the next receivable station.

Audio system

133

Operation Driv

Driving Instrument cluster display

Practical hints

Car care

e Technical data

Index

Audio system

## Scan tuning

FM 95.5 MHz AM WB AUD SC Press the SC key. Each strong receivable station on the band selected will be tuned in for 8 seconds. The first scan will tune only the stations with a

high signal strength. The second scan will tune every receivable station. By pressing either the  $\triangle$ ,  $\nabla$ ,  $\triangleright$  or  $\triangleright$  buttons, or the "SC" key the scan mode can be cancelled.

### Station memory

FM ST 95.5 MHz AM WB AUD Ten stations can be stored in the AM and FM bands via the alpha-numeric keypad. The "0" button corresponds to location 10. Weatherband

(WB) channels 1 to 7 can be retrieved via the alphanumeric keypad and are preset at the factory.

## 134

### **Storing stations**

Hold the number button down for approximately 2 seconds. The currently displayed frequency is stored on the selected station button. The storage procedure is confirmed by a short signal tone.

## Retrieving a station from memory

Press the desired station button.

#### Direct frequency input (AM and FM only)

FM ST
--- MHz
AM WB AUD SC

Select the band. Press the button and enter the desired frequency using the alpha-numeric keypad. Frequencies outside of the

frequency ranges (frequencies specified on page 133) will not be accepted. The frequency input mode is cancelled if no button is pressed within 4 seconds.

#### Cassette mode

#### Note:

Vehicles equipped with the COMAND system do not come with a factory installed cassette mechanism. A standard 1/8" stereo phono plug for auxiliary audio input (located in glove box) is provided for connection of a portable battery operated cassette player or any other portable device which uses a headphone output. Please refer to the COMAND operating manual for information concerning the activation of the audio input.

#### **Playing cassettes**

Press the "TAPE" button. When the eject (EJ) key is pressed, the display folds down and the cassette slot becomes visible. Push the cassette into the slot until it engages. The cassette will be pulled in automatically.

#### Note:

Do not press directly on the radio display face.

Return the display panel to its normal position by folding it back up and pressing gently on the display frame to lock in place.

When playing mono recorded tapes (e.g. books) through a stereo system the sound from one track might bleed to the other track, despite setting the balance to the full left or full right speakers.

#### Important!

If the display is in the down position for more than 20 seconds, 2 successive beeps will be heard. This will continue at 5 second intervals until the display is returned to its normal position.

Audio system 135

## Practical hints

## Car care

# e Technical data

Operation Driving

cluster display

Instrument

Practical hints

Car care

e Technical data

Index

Audio system

TAPE NR SIDE 1 TRK EJ AUD SC The radio will switch to cassette mode. Track 1 will be played and "SIDE 1" displayed. Track 1 is the side of the cassette which is facing

upwards. The cassette deck will automatically detect the type of tape and switch the equalization automatically. A cassette symbol in the display indicates that a tape is in the mechanism. This symbol appears in all modes but not in cassette mode.

The cassette will not be ejected when the radio is switched off or another mode is selected.

NR NO TAPE EJ If a cassette is in the mechanism, cassette mode can be selected by using the "TAPE" button. If no cassette has been inserted, the display will show "NO TAPE".

#### \_

136

### Cassette eject

Press the eject (EJ) key. The display will fold down and the cassette will be ejected. Remove the cassette, then fold the display back up manually. The radio will switch back to radio mode automatically.

#### Note:

The cassette will not be ejected when the radio is switched off.

#### Important!

If the display is in the down position for more than 20 seconds, 2 successive beeps will be heard. This will continue at 5 second intervals until the display is returned to its normal position.

#### Track selection

TAPE NR
SIDE 1
TRK EJ AUD SC

Press the track selection (TRK) key. The current track will be displayed as "SIDE 1" or "SIDE 2". The track will be changed automatically at the end of the tape.

#### Track search forwards/backwards

TAPE NR SEEK FWD TRK EJ AUD SC

Press the button. "SEEK FWD" will be shown on the display and the track search will run the tape forwards to the start of the next track.

TAPE NR SEEK RWD TRK EJ AUD SC

Press the button. "SEEK RWD" will be shown on the display and the track search will run the tape backwards to the start of the

track currently playing. Track search can be interrupted by pressing the same button again.

#### Note:

The beginning of a track can only be located if there is a break of at least 4 seconds between tracks.

#### Fast forward/reverse

TAPE NR FORWARD TRK EJ AUD SC Press the  $\triangle$  button. "FORWARD" will appear on the display and fast forward will start.

TAPE NR REWIND TRK EJ AUD SC Press the  $\nabla$  button. "REWIND" will appear on the display and fast reverse will start.

Fast forward/reverse is stopped by pressing the same button again, or it will stop automatically at the beginning or the end of the tape. The track will automatically change at the end or beginning of the tape and play will begin.

Audio system 137

## Car care

Operation

Driving

Instrument cluster display

Practical hints

Car care

are Technical data

Index

Audio system

Scanning

TAPE NR SCAN FWD TRK EJ AUD SC Press the "SC" key. Each track on the cassette will be played for 8 seconds in ascending order.


Note:

The beginning of a track can only be located if there is a break of at least 4 seconds between tracks.

Scan will be interrupted if the  $\triangle$ ,  $\nabla$ ,  $\triangleright$ ,  $\triangleright$ , buttons or the "SC" key is pressed.

138

Dolby NR<sup>1</sup> (noise reduction system)



To enable optimum reproduction of cassettes recorded using the Dolby B system, press the "AUD" key followed by the NR key so the

"NR" in the display is not highlighted. To turn off Dolby B noise reduction, press the "NR" key so the "NR" in the display is highlighted.

1 Dolby and the double-D symbol are trademarks of Dolby Laboratories Licensing Corporation. The Dolby noise reduction system is manufactured under licence from Dolby Laboratories Licensing Corporation.

#### CD mode

#### General notes on CD mode

Should excessive temperatures occur while in CD mode, "TEMP HIGH" will appear in the display and muting will take place. The unit will then switch back to radio mode until the temperature has decreased to a safe operating level.

Should temperatures occur while in CD mode which are too low, "TEMP LOW" will be displayed, but the CD will play. It will be sensitive to skipping if you are driving over rough roads.

Handle CDs carefully to prevent interference during playback.

Avoid fingerprints and dust on CDs. Do not write on the CDs or apply any label to the CDs.

Clean CDs from time to time with a commercially available cleaning cloth. No solvents, anti-static sprays, etc. should be used.

Replace the CD in its container after use. Protect CDs from heat and direct sunlight.

#### Warning!

The CD changer<sup>1</sup> is a Class 1 laser product. There is a danger of invisible laser radiation if the cover is opened or damaged.

Do not remove the cover. The CD changer<sup>1</sup> does not contain any parts which can be serviced by the user. For safety reasons, have any service work which may be necessary performed only by qualified personnel.

1 Optional equipment

Audio system 139


## Practical hints

## Car care

## Technical data

#### 140

## CD changer installed



- 1 CD changer<sup>1</sup>
- 2 CD magazine
- **3** CD tray
- **4** CD

If a CD changer<sup>1</sup> is installed, it can be operated from the front control panel of the radio. A loaded magazine must be installed for CD playing.

1 Optional equipment

## Loading/emptying the CD magazine

Slide the changer door to the right and press the eject button . The magazine will be ejected. Remove the magazine. Pull out the CD tray until its stop is reached and place the CDs in the recess of the tray, label side up. Push the tray into the magazine in the direction shown by the arrow. Insert the loaded magazine into the changer.

#### Important!

Close the door after the magazine has been inserted.

#### **Playing CDs**

Press the "CD" button. The CD most recently played will start at the point where it was last switched off. CDs stored in the magazine can be selected by using the station preset buttons 1-6.

CD1 TRACK 1 RDM RPT AUD SC The magazine slot number of the selected CD will then be displayed after "CD". The number of the track being played will be displayed after "TRACK". CD1 NO CD3 RDM RPT AUD SC If there is no CD in the selected magazine slot, "NO CD" and the corresponding slot number will be displayed

(e.g. "NO CD3"). After the last track on a CD has been played, the next CD will automatically be selected and played.

#### Skipping tracks forwards/backwards

Press the button. The next track on the CD will be played.

Press the button. If the track has been playing for more than 10 seconds, it will revert to the start of that track. If it has been playing for less than ten seconds it will revert to the preceding track. To skip several tracks, the respective button must be pressed until the desired track is reached. If the beginning or end of the CD is reached during the search, the first or last track will be played.

#### Fast forward/reverse

Press the  $\triangle$  button and hold it down for audible fast forward.

Press the  $\nabla$  button and hold it down for audible reverse.

CD1 02:46 RDM RPT AUD SC The search will stop when the button is released. The relative time of the track will be displayed during the search. The search mode will

cancel if the beginning or end of the CD is reached.

#### **Scanning**

Press the SC key. Each track will be played for 8 seconds in ascending order. The search will stop at the track in question if the  $\triangle$ ,  $\nabla$ ,  $\triangleright$ ,  $\triangleright$  buttons or the "SC" key is pressed.

Audio system

141

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Audio system			14	12			

Random play/repeat function

The tracks of the current CD are played in random order when the random feature (RDM) is selected. Press the RDM key to switch on, and press RDM again to switch off.

CD1 TRACK 10 RDM RPT AUD SC When the repeat function (RPT) has been selected, a particular track can be played for as many times as desired. Press the RPT key to switch

on, and press RPT again to switch off.

Note:

Both functions cannot be used simultaneously.

### Direct track selection

Tracks can be selected directly using the buttons on the alpha-numeric keypad. Press the function button, followed by the track number.

### **Telephone operation**

Various functions of the Mercedes-Benz integrated cellular telephone<sup>1</sup> can be performed and displayed via the car radio. Further instructions for operating the car telephone can be found in the operation guide for the cellular telephone<sup>1</sup>.

### Switching the telephone on and off

FM5 ST TEL 95.5 MHz FM WB AUD SC Switching on: Press the button, "TEL" appears in the corner of the display.

Switching off: Press and hold

the **TEL** button until the telephone symbol "TEL" no longer appears in the display, or press the "PWR" button on the phone's keypad.

1 Optional equipment

# Entering telephone number and starting dialing process

S.. ROAM READY SND END Enter the desired telephone number using the alphanumeric keypad. The number can have up to 32 digits, but only 13 of these can be

displayed. The dialing process is started by pressing the SND button. The entered number can be corrected using the "CLR" key.

S.. ROAM 5551212 SND CLR END Press the CLR key briefly - and the last digit will be deleted.

Press the CLR key longer - and

the complete number will be deleted.


### Calling up the phone book

The numbers stored in the telephone memory can be called up via either name or number entries. The memory contents from the portable phone must be downloaded and the telephone menu must be selected in order to call up the phone book. Refer to the "Memory download" section of the cellular telephone operation guide for more information.

Audio system

# Technical data

Index



144

Audio system

Switching between name search and number search

Press ABC key - Name search

Press NUM key - Number search

# Searching and selecting phone book entries by name

Press the ABC key. The current name is shown on the display. The stored entries in alphabetical order can be selected using the or button. By pressing the buttons, the stored entries can be selected according to alphabetical initial letters (e.g. A-Adam, B-Brown, M-Miller).

# Searching and selecting phone book entries by number

Press the NUM key. The current number is shown on the display. The stored entries can be selected in numerical order using the or button. By pressing the or buttons, the stored entries can be selected in increments of 5 (e.g. Entry no. 2, Entry no. 7, etc.).

# Placing a call

S.. ROAM 5551212 SND CLR END

When a number or a name has been selected using the method described above, press the SND key. Index

# Manual repeat dialing (redial)

The last number entered can be re-selected by pressing the SND key once and the call can be placed by pressing the SND key a second time. The last dialed telephone number is shown on the display. Using the A, V, blue or button, the numbers stored in the re-dial memory of the telephone can be selected.

S.. ROAM L2 5551212 SND CLR END The abbreviation L and the number in the memory are shown in the top line of the display.

### Accepting incoming call in telephone mode

With an incoming call, the ringing tone will be heard and the message "CALL" appears in the display. Press the SND key to answer the call.

# Accepting incoming call in tape, CD or radio mode

If the telephone is activated in the background (telephone symbol in the display), then a switch is made automatically to telephone when an incoming call is received. The audio source is muted, the ringing tone is heard and the message "CALL" appears. After the call has been terminated, the previously selected audio source is resumed.

## Terminating call

A current call can be terminated by pressing the END key.

### **Component malfunctions**

The radio, CD changer<sup>1</sup>, and Mercedes-Benz integrated cellular telephone<sup>1</sup> are part of a fiberoptic networked system. Failure of one of the components can lead to malfunctions of the other components. Please contact your authorized Mercedes-Benz Center or call 1-800-FOR-MERCedes for more information in the event of a malfunction.

1 Optional equipment

Audio system 145

instruments	Operation	Driving	
and controls	Operation	Dilving	


**Technical** 

data

Index

Interior equipment

### **Power windows**



Power window switches are located on center console.

- 1 left, front
- 2 left, rear
- 3 right, front
- 4 right, rear

146

Turn electronic key in steering lock to position 1 or 2.

Press switch in to resistance point:

to open

★ to close

Release switch when window is in desired position.

# Warning!

When closing the windows, be sure that there is no danger of anyone being harmed by the closing procedure.

The closing procedure can be immediately reversed by either pressing the switch or pressing button on the remote control, and holding it.

When leaving the vehicle, always remove the electronic key from the steering lock, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment can cause serious personal injury.

# Express opening and closing of door windows

Press switch or past resistance point and release — window opens or closes completely.

To interrupt procedure, briefly press 🗢 or 🖎.

If the upward movement of the window is blocked during the closing procedure, the window will stop during the last few inches before closure and open slightly.

When pressing and holding the switch to close the window, and upward movement of the window is blocked during the last few inches before closure, it will stop but <u>not</u> open slightly.

### Warning!

When leaving the vehicle, always remove the electronic key from the steering lock and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment can cause serious personal injury.

#### Note:

The power windows can also be opened and closed with the infrared remote control while locking the vehicle doors or trunk, see page 32.

# Synchronizing power windows

If the power supply was interrupted (battery disconnected or low), the windows cannot be opened by the Express feature.

To resynchronize the express feature, press side of power window switch until the window is completely closed and hold for additional 2 seconds. Repeat procedure for each window.

The automatic full opening procedure of the windows should now be restored.

Interior equipment

147

Inst	ruments
and	controls

148

# Interior equipment

# Power windows - operated with soft top switch



Soft top switch is located on center console.

In addition to the power window switches, the windows can also be opened or closed with the soft top switch.

# Warning!

When closing the windows, be sure that there is no danger of anyone being harmed by the closing procedure.

When leaving the vehicle, always remove the electronic key from the steering lock, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment can cause serious personal injury.

The soft top handle must be in the locked position to operate the power windows.

Turn electronic key in steering lock to position 1 or 2.

To open:

Lift soft top switch quickly twice and hold.

To close:

Press soft top switch quickly twice and hold.

Release switch when windows are in desired position.

### **Interior lighting**



1 Automatic interior lighting

Press once and the automatic interior lighting is activated.

Interior lamps are switched on, and off (soft fade) delayed, when unlocking or locking the vehicle, or when opening or closing a door. However, there will be no (soft fade) delay when the electronic key is in steering lock position 2.

Press again and interior lamps remain switched off, even when centrally unlocking or opening a door.

- 2 Press to switch interior and reading lamps on or off.
- **3** Press to switch reading lamp on or off.
- 4 Press to switch reading lamp on or off.

### Entrance lamps, exit lamps in doors

The lamps are switched on and off by the door contact switches.

### Note:

To prevent the vehicle battery from being discharged, with doors open all interior lamps go out after approximately 5 minutes.


Interior equipment

Inst	ruments	
and	controls	

# Technical data

Interior equipment


### Sun visors



Swing sun visors down to protect against sun glare.

If sunlight enters through a side window, disengage visor from inner mounting, pivot it to the side, and slide it to the desired position.

# 150



With the visor engaged in its inner mounting, the lamp is switched on by opening the cover.

# Warning!

Do not use the vanity mirror while driving.

The lamp goes out automatically after approximately 5 minutes.

#### Interior

## Warning!

To help avoid personal injury during a collision or sudden maneuver, exercise care when stowing things. Put luggage or cargo in the trunk if possible. Do not pile luggage or cargo higher than the seat backs. Do not place anything on the shelf below the rear window.


Luggage nets cannot secure hard or heavy objects.

Storage compartments, armrest and cup holder

### Warning!

Keep compartment lids closed. This will help to prevent stored objects from being thrown about and injuring vehicle occupants during an accident and sudden maneuvers.

### Glove box



- 1 Unlocking: Turn mechanical key to vertical position and remove.
- 2 Locking: Turn mechanical key to the right and remove.
- 3 Opening: Pull on handle.

The glove box can be locked and unlocked with the mechanical key. See page 25 for instructions on how to remove the mechanical key from the electronic main key (e.g. for valet parking service).

Interior equipment


151

Inst	ruments
and	controls

### Technical data

# Interior equipment

# Storage compartments in center console



152

To open compartment in armrest: Press button (4) and lift lid.

To open compartment under armrest: Press button (5) and lift lid.


To close:

Lower lid until it engages in lock.

To open cover:

Touch top of cover (6) slightly. The cover opens automatically.

## Cup holder in center console



To open cup holder: Briefly press button (7). The cup holder opens automatically.

To store cup holder: Push button (7) down until cup holder engages. Close cover (6).

#### Notes:

The right claw is adjustable to accommodate most container sizes.

An additional second (smaller size) container can be placed in the cup holder.

Spilling liquids (e.g. soda or coffee) could restrict the movement of the claw. Refer to page 306 for cleaning the cup holder.


#### Caution!

Keep cup holder closed while traveling. Place only containers that fit into the cup holder to prevent spills.

Do not fill containers to a height where the contents could spill during vehicle maneuvers, especially hot liquids.

# Interior equipment

# **Ashtray**



# Center console, front

By touching the bottom of the cover lightly, the ashtray opens automatically.

# 154

Prior to removing the ashtray insert, move the gear selector lever to position "N".

# Warning!

Remove front ashtray only with vehicle standing still. With the gear selector lever in position "N", turn off the engine and set the parking brake. Otherwise the vehicle might move as a result of unintended contact with the gear selector lever.


To remove ashtray:

Push sliding knob (1) toward the right to eject the insert.

To install ashtray:

Install insert into ashtray frame and push down to engage.

# Lighter



Turn electronic key in steering lock to position 1 or 2. Push in lighter (1); it will pop out automatically when hot.

# Warning!

Never touch the heating element or sides of the lighter, they are extremely hot, hold at knob only.

When leaving the vehicle always remove the electronic key from the steering lock. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause serious personal injury.


The lighter socket can be used to accommodate electrical accessories up to maximum 85 W.

Interior equipment

# Technical data

Interior equipment

# Cargo tie down rings



# 1 Ring

Carefully secure cargo by applying even load on all four rings with rope of sufficient strength to hold down the cargo.

# 156

# Parcel net in front passenger footwell

A small convenience parcel net is located in the front passenger footwell. It is for small and light items, such as road maps, mail, etc..

# Warning!

Do not place heavy or fragile objects, or objects having sharp edges, in the parcel net.

In an accident, during hard braking or sudden maneuvers, they could be thrown around inside the vehicle, and cause injury to vehicle occupants.

#### Note:

With large objects stored in the parcel net do not slide the seat fully forward, it could damage them.

### Armrest, rear bench

Pull down the armrest by its top.

### Telephone, general

## Warning!

A driver's attention to the road must always be his/her primary focus when driving. For your safety and the safety of others, we recommend that you pull over to a safe location and stop before placing or taking a telephone call. If you choose to use the telephone while driving, please use the hands-free device and only use the telephone when road and traffic conditions permit.

Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of approximately 50 feet (approximately 14 m) every second.

Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and personal injury.

#### Note:

See separate instruction manual for instructions on how to operate the telephone.

# Cellular telephone

The vehicle is prepared for the installation of a cellular telephone. For further information and installation contact your authorized Mercedes-Benz Center.


### Warning!

Some jurisdictions prohibit the driver from using a cellular telephone while driving a vehicle. Whether or not prohibited by law, for safety reasons, the driver should not use the cellular telephone while the vehicle is in motion. Stop the vehicle in a safe location before answering or placing a call.

Telephone 157

Garage door opener

# Garage door opener



- 1 Signal transmitter keys
- 2 Indicator lamp
- 3 Portable remote control transmitter

158

The built-in remote control is capable of operating up to three separately controlled objects.

# Warning!

When programming a garage door opener, the door moves up or down.

When programming or operating the remote control make sure there is no possibility of anyone being harmed by the moving door.

### Notes:

Certain types of garage door openers are incompatible with the integrated opener. If you should experience difficulties with programming the transmitter, contact your authorized Mercedes-Benz Center, or call Mercedes-Benz Client Assistance Center (in the USA only) at 1-800-FOR-MERCedes, or Customer Service (in Canada) at 1-800-387-0100.

For operation in the USA only: This device complies with Part 15, Subpart C, Section 209 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

WARNING: Changes or modification not expressly approved by party responsible for compliance could void the user's authority to operate the equipment.

### Programming or reprogramming the integrated remote control:

- 1. Turn electronic key in steering lock to position 1 or 2.
- 2. Hold the end of the hand-held transmitter of the device you wish to train approximately 2 to 5 inches (5 cm to 12 cm) away from the surface of the integrated remote control located on the inside rear view mirror, keeping the indicator lamp in view.

Driving

- 3. Using both hands, simultaneously push the handheld transmitter button and the desired integrated remote control button. Do not release the buttons until completing step 4.
- 4. The indicator lamp on the integrated remote control will flash, first slowly and then rapidly. When the indicator lamp flashes rapidly, both buttons may be released (the rapid flashing lamp indicates successful programming of the new frequency signal). To program the remaining two buttons, follow steps 1 though 4.

#### Note:

If after repeated attempts, you do not successfully program the integrated remote control device to learn the signal of the hand-held transmitter, the garage door opener could be equipped with the "rolling code feature".

Gara

Instruments

and controls

**Operation** 

159

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Diffying	cluster display	1 factical littles	Car care	data	muex

Garage door opener

# Rolling code programming:

To train a garage door opener (or other rolling code devices) with the rolling code feature, follow these instructions after completing the "Programming" portion of this text. (A second person may make the following training procedures quicker and easier.)

- 1. Locate training button on the garage door opener motor head unit. Exact location and color of the button may vary by garage door opener brand. If there is difficulty locating the transmitting button, reference to garage door opener operator's manual.
- 2. Press "training" button on the garage door opener motor head unit (which activated the "training light").

Note:

Following step 2, there are 30 seconds to initiate step 3.

160

- 3. Firmly press and release the programmed integrated remote control transmit button. Press and release same button a second time to complete the training process. (Some garage door openers may requires you to do this procedure a third time to complete the training.)
- 4. Confirm the garage door operation by pressing the programmed button on the integrated remote control transmitter.

# **Canadian programming:**

During programming, your hand-held transmitter may automatically stop transmitting. Continue to press and hold the integrated remote control transmitter button (note steps 2 through 4 in the "Programming" portion) while you press and re-press ("cycle") your hand-held transmitter every two seconds until the frequency signal has been learned. The indicator lamp will flash slowly and then rapidly after several seconds upon successful training.

### **Operation of remote control:**

- 1. Turn electronic key in steering lock to position 1 or 2.
- 2. Select and press the appropriate button to activate the remote controlled device. The integrated remote control transmitter continues to send the signal as long as the button is pressed - up to 20 seconds.

### Erasing the remote control memory:

- 1. Turn electronic key in steering lock to position 1 or 2.
- 2. Simultaneously holding down the left and right side buttons for approximately 20 seconds, or until the control lamp blinks rapidly, will erase the codes of all three channels.

Car care

Gar

rage door opener	
------------------	--

**Practical hints** 

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Soft top			10	62			

# Soft top

A minimum height clearance of 6  $^{1}/_{2}$  ft. (2 m) is required to lower or raise the soft top.

The raising or lowering procedure can only be started with the luggage cover and trunk lid closed.

The raising or lowering procedure is immediately interrupted by releasing the soft top switch.

Do not operate the soft top while a trunk luggage carrier is installed.

To prevent damage to the soft top, soft top compartment cover, trunk lid or luggage/cargo when lowering the roof:

- load trunk only to the height of the luggage cover,
- do not permit luggage/cargo to raise the closed luggage cover,
- do not load anything on top of the luggage cover,
- do not place anything on the soft top compartment cover,
- do not open the trunk lid while the soft top is being raised or lowered. This is required since the soft top compartment cover moves upward and backward during raising or lowering operations,

• do not operate the luggage cover with the soft top lowered. Doing so will result in damage to the luggage cover or the soft top.

Lowering a wet soft top can result in water reaching the vehicle interior. The soft top should be dry when lowering it into the soft top storage compartment.

Do not lower a frozen soft top until thawed and dry. Doing so may result in damage not covered by the Mercedes-Benz Limited Warranty.

To prevent mildew, the soft top must be dry before lowering it into the storage compartment.

The soft top should not be lowered or raised at outside temperatures below +5°F (-15°C), since the material becomes less pliable with lower temperatures.

#### Notes:

Rear passengers should lean forward while raising or lowering the soft top, to clear the path of the rear window.

To prevent the soft top from being lowered unintentionally while a trunk luggage carrier is installed, keep luggage cover in trunk in the open position with the soft top raised.

### Warning!


Never lock or unlock the soft top while driving. Doing so could cause the driver to lose control of the vehicle.

Driving with an unlocked soft top may cause personal injury to you or your passenger, or personal injury or property damage to others.

Before operating the soft top switch make sure that no persons due to inattention are injured by the moving parts (roll bar, soft top frame and soft top compartment cover).

Hands must never be placed near the roll bar, soft top frame, upper windshield area or soft top storage compartment while the soft top is being raised or lowered. Serious personal injury may occur.

In case of danger release the switch to immediately interrupt the operating procedure.



### Important!

Do not manually move corner flaps (1) of soft top compartment cover. Doing so will result in damage to the soft top folding mechanism that is not covered by the Mercedes-Benz Limited Warranty.

With the soft top lowered do not place anything on the soft top compartment cover (2).

The soft top compartment cover must never be used by any persons as a seat bench. Raising of the roll bar could result in personal injury.

Soft top 163


Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Soft top 164



# **Lowering Soft Top**

- 1. Engage parking brake.
- Close luggage cover and trunk lid.For notes on the luggage cover, see page 250.
- 3. Turn electronic key in steering lock to position 2.
- 4. Press lock button (1) and fold down locking handle (2).
- 5. Turn locking handle  $90^{\circ}$  clockwise to unlock the soft top.



### Important!

Push soft top frame approx. 8 inches (20 cm) upward by the locking handle. Failing to do so will result in damage to the soft top folding mechanism that is not covered by the Mercedes-Benz Limited Warranty.

Turn locking handle counterclockwise to the stop and fold up until it locks in place.

- The indicator lamp in the soft top switch lights up.
- · The side windows lower.



#### Notes:

If indicator lamp blinks slowly, a malfunction has occurred in the system.

If indicator lamp blinks rapidly, the trunk lid and/or the luggage cover may be open, and need to be closed.

- 6. Lift symbol side of the soft top switch and hold:
  - The roll bar lowers (when in the upper position).
  - The soft top compartment cover and rear window section of the soft top unlocks.
  - The rear window section of the soft top raises.
  - The soft top compartment cover opens.
  - The soft top lowers into its storage compartment.
  - The soft top compartment cover closes and locks.
  - The indicator lamp in the soft top switch goes out – the lowering procedure is completed – a signal sounds.

If the soft top switch is held or is released and lifted again within approximately 2 seconds, the side windows will close. If the roll bar was previously in the upper position, it will return to that position.

The side windows can also be opened/closed later on. Lift/press soft top switch twice and hold, see page 148.

However, the side windows and the roll bar can also be activated using their respective switches, see page 146 and page 53.

Soft top 165

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 Tactical IIIIts	Car care	data	HIGGA

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Soft top			10	66			
Wa	rning!			4. Press symbo	ol side of soft top s	witch and hold:	

To prevent possible accidents, drive the vehicle only with the soft top either completely closed and locked, or fully lowered into its storage compartment.

#### Note:

For safety reasons, the soft top cannot be lowered while driving.

# **Raising Soft Top**

- 1. Engage parking brake.
- 2. Close luggage cover and trunk lid. For notes on the luggage cover, see page 250.
- 3. Turn electronic key in steering lock to position 2.

- - The indicator lamp in the soft top switch lights up.

### Notes:

If indicator lamp blinks slowly, a malfunction has occurred in the system.

If indicator lamp blinks rapidly, the trunk lid and/or the luggage cover may be open, and need to be closed.

- · The side windows lower.
- The roll bar lowers (when in the upper position).
- The soft top compartment cover unlocks and opens.
- The soft top is raised from its storage compartment to the closing position.
- The soft top storage compartment closes and the rear window section of the soft top lowers - a signal sounds.




- 5. Press lock button (1) and fold down locking handle (2).
- 6. Turn locking handle 90° clockwise and pull soft top frame carefully down until it meets the windshield header attachment points.

Turn locking handle counterclockwise to the stop to lock the soft top.

Fold locking handle up until it locks in place.

The indicator lamp in the soft top switch goes out – the lowering procedure is completed.



If the soft top switch is held or is released and pressed again within approximately 2 seconds, the side windows will close. If the roll bar was previously in the upright position, it will return to that position.

The side windows can also be closed/opened later on. Press/lift soft top switch twice and hold, see page 148.

However, the side windows and the roll bar can also be activated using their respective switches, see page 146 and page 53.

Soft top 167

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 factical fiffits	Car care	data	Hucz

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Soft top			10	68			

## Note:

For safety reasons, the soft top cannot be raised while driving.

# Warning!

The soft top is not fully closed and locked:

- if the indicator lamp in the soft top switch does not got out (electronic key in steering lock position 2).
- if the indicator lamp blinks, and a signal sounds for 10 seconds when starting to drive.

Stop the vehicle and before continuing to drive, close and lock the soft top.

If the soft top is not locked, it may fold back or forward when driving.

During soft top operation, do not place your hands near the roll bar, soft top frame, upper windshield area or soft top storage compartment. Serious personal injury may occur.

To prevent possible accidents, drive the vehicle only with the soft top either completely closed and locked, or fully lowered into its storage compartment.

If the indicator lamp in the soft top switch blinks slowly while activating the switch,

- the battery voltage may be insufficient start engine and let it run while activating switch,
- the system may be overheated (for example after lowering or raising the soft top approx. 5 consecutive times) - after approx. 10 minutes the soft top switch may be activated again.

If indicator lamp in the soft top switch blinks rapidly while activating the switch,

- the trunk lid and/or the luggage cover may be open, and need to be closed.
- the soft top is still locked during the opening procedure and needs to be unlocked,
- the opening/closing procedure is interrupted.

In this case the soft top needs to be synchronized. Turn electronic key in steering lock back to position 0, and then to position 2. Activate soft top switch again. The soft top should now be operational again.

If the indicator lamp continues to blink, raise the soft top manually, see page 291.

Have the system checked at your authorized Mercedes-Benz Center as soon as possible.

#### Notes:

If the roll bar was raised automatically, the process of raising or lowering the soft top will take somewhat longer, as the roll bar must first be lowered.

Whenever possible, park vehicle in the shade as continuous exposure to sun rays can prematurely deteriorate the soft top material.

The soft top may become moldy and receive permanent creases if it is kept in the storage compartment for an extended period.

Therefore, we recommend raising and airing it thoroughly with the side windows open (do not expose it to the sun) at regular intervals during the wet and cold seasons.

To prevent damage, the soft top must be dry and clean before lowering it into the storage compartment. There is the possibility of sharp-edged dirt particles damaging the soft top or scratching the rear window.

Soft top 169

Inst	ruments
and	controls

# **Practical hints**

# Car care

### **Technical** data

Wind screen

# Wind screen (optional)




The wind screen is most effective when all four side windows are fully raised.

# 170

### Installation

- 1. Remove wind screen from its storage bag, located in the trunk, secured with hook and loop fasteners, and unfold.
- 2. Pull folded end sections in direction of arrow (1) and unfold in direction of arrow (2).



# Important!

The open end of the hooks must point toward the vehicle's front.

3. Insert end section in right opening (3) on quarter panel first. Then push left end section toward vehicle center (arrow 4) until it meets the left opening. Insert end section in left opening (5).

Push down on wind screen (6) until it locks in place.


# Warning!

Check for secure locking by pulling up on the wind screen.

Wind screen 171

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Driving	cluster display	r ractical illits	Cai Cai e	data	muex

Wind screen 172



### Removal

Push left and right side buttons and remove wind screen upward.


# Warning!

To prevent personal injury, remove wind screen if rear seats are to be occupied by passengers.

### Note:

Do not insert foreign objects in openings for the wind screen.

# Storing



Pull end sections in direction of arrow (1) and fold in direction of arrow (2).

Place wind screen in its storage bag, and close the bag.

Place bag in trunk, and secure it with the provided hook and loop fasteners.


When the wind screen is not in use, it should be stored in the closed storage bag, to prevent possible damage to the wind screen or luggage/cargo.

Wind screen 173

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 factical illits	Cai cai e	data	Illuex

Wind screen

# Roller Blind (horizontal)



### 174

# To open blind:

- 1. Pull out blind on tab (arrow 1) towards vehicles rear. Insert guide rod of blind in right rear seat belt outlet (arrow 2).
- 2. Insert other end of rod in left rear seat belt outlet as shown with arrow (3).


# Important!

Do not place anything on the roller blind.

### To retract blind:

• Hold blind at tab, disengage and guide retraction.

# Roller Blind (vertical)



# To open blind:

- 1. Fold driver and front passenger seat backrests forward.
- 2. Pull out on tab, located below rear bench, towards vehicle's front, then pull up and engage blind at wind screen.

### To retract blind:

- 1. Fold driver and front passenger seat backrests forward.
- 2. Hold blind at tab, disengage and guide its retraction.

Wind screen 175

Instruments	Operation	Driving	Instrument	Practical hints	Con cono	Technical	Indov
and controls	Operation	Diffillg	cluster display	Practical illins	Car care	data	Index

# Driving

Control and operation of radio transmitters 17	78
The first 1 000 miles	
(1 500 km)17	79
Maintenance17	79
Catalytic converter18	30
Emission control 18	
Tele Aid18	32
Steering lock	2
Starting and turning off	
the engine19	4
Automatic transmission	
Parking brake20	

Driving instructions	205
Drive sensibly - save fuel	205
Drinking and driving	205
Pedals	205
Power assistance	206
Brakes	206
Driving off	207
Parking	207
Tires	208
Snow chains	210
Winter driving instructions	211
Deep water	212
Passenger compartment	213
Traveling abroad	213

Cruise control	214
Brake assist system	
(BAS)	216
Antilock brake system	
(ABS)	218
Electronic stability program	
(ESP)	220
What you should know	
at the gas station	224
Check regularly and	
before a long trip	226

Contents - Driving

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	operation	Dirving	cluster display	Tractical mines	Cur cure	data	mucx

178

Control and operation of radio transmitters

# Control and operation of radio transmitters

COMAND, radio and telephone

# Warning!

Please do not forget that your primary responsibility is to drive the vehicle. Only operate the COMAND (Cockpit Management and Data System), radio or telephone<sup>1</sup> if road and traffic conditions permit.

Bear in mind that at a speed of just 30 mph (approximately 50 km/h), your vehicle is covering a distance of approximately 50 feet (approximately 14 m) every second.

1 Observe all legal requirements.

# Telephones and two-way radio

# Warning!

Never operate radio transmitters equipped with a built-in or attached antenna (i.e. without being connected to an external antenna) from inside the vehicle while the engine is running. Doing so could lead to a malfunction of the vehicle's electronic system, possibly resulting in an accident and personal injury.

Radio transmitters, such as a portable telephone or a citizens band unit should only be used inside the vehicle if they are connected to an antenna that is installed on the outside of the vehicle.

Refer to the radio transmitter operation instructions regarding use of an external antenna.

#### The first 1 000 miles (1 500 km)

The more cautiously you treat your vehicle during the break-in period, the more satisfied you will be with its performance later on. Therefore, drive your vehicle during the first 1 000 miles (1 500 km) at moderate vehicle and engine speeds.

During this period, avoid heavy loads (full throttle driving) and excessive engine speeds.

Avoid accelerating by kickdown. It is not recommended to brake the vehicle by manually shifting to a lower gear. We recommend that you select positions "3", "2" or "1" only at moderate speeds (for hill driving).

After 1 000 miles (1 500 km) speeds may be gradually increased to the permissible maximum.

#### Maintenance

Approximately 30 days or 2 000 miles ( 2000 km) prior to the next recommended service, the remaining distance or days are displayed in the multifunction indicator. See Flexible service system (FSS) on page 109.

We strongly recommend that you have your vehicle serviced by your authorized Mercedes-Benz Center, in accordance with the Service Booklet at the times called for by the FSS.

Failure to have the vehicle maintained in accordance with the Service Booklet at the designated times/mileage may result in vehicle damage not covered by the Mercedes-Benz Limited Warranty.

Check regularly and before a long trip, see page 226.

The first 1 000 miles

# Technical data

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	-------------------------------	-----------------	----------	-------------------	-------

Catalytic converter

# Catalytic converter

Your Mercedes-Benz is equipped with monolithic type catalytic converters, an important element in conjunction with the oxygen sensors to achieve substantial control of the pollutants in the exhaust emissions. Keep your vehicle in proper operating condition by following our recommended maintenance instructions as outlined in your Service Booklet.

180

#### Caution!

To prevent damage to the catalytic converters, use only premium unleaded gasoline in this vehicle.

Any noticeable irregularities in engine operation should be repaired promptly. Otherwise, excessive unburned fuel may reach the catalytic converter causing it to overheat, which could start a fire.

# Warning!

As with any vehicle, do not idle, park or operate this vehicle in areas where combustible materials such as grass, hay or leaves can come into contact with the hot exhaust system, as these materials could be ignited and cause a vehicle fire.

#### **Emission control**

Certain systems of the engine serve to keep the toxic components of the exhaust gases within permissible limits required by law.

These systems, of course, will function properly only when maintained strictly according to factory specifications. Any adjustments on the engine should, therefore, be carried out only by qualified Mercedes-Benz authorized center technicians. Engine adjustments should not be altered in any way. Moreover, the specified service jobs must be carried out regularly according to Mercedes-Benz servicing requirements. For details refer to the Service Booklet

# Warning!

Inhalation of exhaust gas is hazardous to your health. All exhaust gas contains carbon monoxide, and inhaling it can cause unconsciousness and lead to death.

Do not run the engine in confined areas (such as a garage) which are not properly ventilated. If you think that exhaust gas fumes are entering the vehicle while driving, have the cause determined and corrected immediately. If you must drive under these conditions, drive only with at least one window fully open.

Emission control 181

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dirving	cluster display	Tractical mints	Car care	data	mucx

182

Tele Aid

# Tele Aid

# Important!

The initial activation of the Tele Aid system may only be performed by completing the subscriber agreement and placing an acquaintance call using the "SOS" button. Failure to complete either of these steps will result in a system that is not activated. If the system is not activated the indicator lamp in the "SOS" button stays on after turning electronic key in starter switch to position 2 and the message "TELE AID – NOT ACTIVATED" will be shown in the multifunction display for approx. 10 seconds.

If you have any questions regarding activation, please call the Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada).

# (Telematic Alarm Identification on Demand)

The Tele Aid system consists of three types of response; automatic and manual emergency, roadside assistance and information.

The Tele Aid system is operational providing that the vehicle's battery is charged, properly connected, not damaged and cellular and GPS coverage is available.

The speaker volume of a Tele Aid call can be adjusted when using the volume control on the multifunction steering wheel, for raising press button + and for lowering press button -.

To activate, press the "SOS" button, the Roadside Assistance button or the Information button depending on the type of response required.

Shortly after the completion of your Acquaintance Call, you will receive a user ID and password via first call mail. By visiting www.mbusa.com and selecting "Tele Aid" (USA only), you will have access to account information, remote door unlock, Info Services\* profile and more.

# System self-check

Initially, after turning the electronic key in starter switch to position 2, malfunctions are detected and indicated (the indicator lamps in the "SOS" button, the Roadside Assistance button and the Information button stay on longer than 10 seconds or do not come on). The message "TELE AID – VISIT WORKSHOP" appears for approx. 10 seconds in the multifunction display.

<sup>\*</sup> Optional - available only with COMAND

# Important!

Always make sure that the indicator lamps in the "SOS" button, in the "Roadside Assistance" button and in the "Information" button do not remain illuminated constantly in red and the message "TELE AID - VISIT WORKSHOP" is not displayed in the multifunction display after the system self check.

If a malfunction is indicated as outlined above, have the system checked at the nearest Mercedes-Benz Center as soon as possible.

# **Emergency calls**

An emergency call is initiated automatically:

- following an accident in which the Emergency Tensioning Retractors (ETR's) or airbags deploy,
- if the antitheft alarm or the tow away alarm stays on for more than 20 seconds, see pages 42 and 44.

An emergency call can also be initiated manually by opening the cover next to the inside rear view mirror labeled "SOS", then pressing the button (for longer than 2 seconds) located under the cover. See below for instructions on initiating an emergency call manually.

Once the emergency call is in progress, the indicator lamp in the "SOS" button will begin to flash. The message "EMERGENCY CALL – CONNECTING CALL" appears in the multifunction display. When the connection is established, the message "EMERGENCY CALL – CALL CONNECTED" appears in the multifunction display. All information relevant to the emergency, such as the location of the vehicle (determined by the GPS satellite location system), vehicle model, identification number and color are generated.

A voice connection between the Response Center and the occupants of the vehicle will be established automatically soon after the emergency call has been initiated. When a voice connection is established the audio system mutes and the message "TELE AID – EMERGENCY CALL ACTIVE" appears in the multifunction display. The Response Center will attempt to determine more precisely the nature of the accident provided they can speak to an occupant of the vehicle.

Tele Aid 183

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Tele Aid			18	84			

Instrument

The Tele Aid system is available if:

- it has been activated and is operational. Activation requires a subscription for monitoring services and cellular air time,
- the relevant cellular phone network and GPS signals are available and pass the information on to the response center.

#### Note:

Instruments

Location of the vehicle on a map is possible if the vehicle is able to receive signals from the GPS satellite network and pass the information on to the response center.

# Warning!

If the indicator lamp in the "SOS" button is illuminated continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate an emergency call (e.g. the relevant cellular phone network is not available). The message "EMERGENCY CALL – CALL FAILED" appears in the multifunction display for approx. 10 seconds.

Tachnical

Should this occur, assistance must be summoned by other means.

# Initiating an emergency call manually



Briefly press on cover (1) – the cover will open.

Press the SOS button (2) briefly (for longer than 2 seconds). The indicator lamp in the SOS button (2) will flash until the emergency call is concluded. Wait for a voice connection to the Response Center.

Close the cover (1) after the emergency call is concluded.

# Warning!

If you feel at any way in jeopardy when in the vehicle (e.g. smoke or fire in the vehicle, vehicle in a dangerous road location), please do not wait for voice contact after you have pressed the emergency button. Carefully leave the vehicle and move to a safe location. The Response Center will automatically contact local emergency officials with the vehicle's approximate location if they receive an automatic "SOS" signal and cannot make voice contact with the vehicle occupants.

Tele Aid 185

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 factical fiffics	Car care	data	Hucz

Driving

Instrument cluster display

Practical hints

Car care

Technical data

Index

Tele Aid

186

# Roadside Assistance button **S**

Operation

Located below the center armrest cover is the Roadside Assistance button . Pressing and holding the button (for longer than 2 seconds) will initiate a call to a Mercedes-Benz Roadside Assistance dispatcher. The button will flash while the call is in progress. The message "ROADSIDE ASSISTANCE – CONNECTING CALL" will appear in the multifunction display. When the connection is established, the message "ROADSIDE ASSISTANCE – CALL CONNECTED" appears in the multifunction display. The Tele Aid system will transmit data generating the vehicle identification number, model, color and location (subject to availability of cellular and GPS signals).

A voice connection between the Roadside Assistance dispatcher and the occupants of the vehicle will be established. When a voice connection is established the audio system mutes and the message "TELE AID – ROADSIDE ASSISTANCE CALL ACTIVE" appears in the multifunction display. The nature of the need for assistance can then be described. The Mercedes-Benz Roadside assistance dispatcher will either dispatch a qualified Mercedes-Benz technician or arrange to tow your vehicle to the nearest Mercedes-Benz Center. For

services such as labor and/or towing charges may apply. Refer to the Roadside Assistance manual for more information.

These programs are only available in the USA:

- Sign and Drive services: Services such as jump start, a few gallons of fuel or the replacement of a flat tire with the vehicle spare tire are obtainable,
- Remote Vehicle Diagnostics: This function permits the Mercedes-Benz Roadside Assistance dispatcher to download malfunction codes and actual vehicle data.

#### Notes:

The indicator lamp in the Roadside Assistance button remains illuminated in red for approx. 10 seconds during the system self-check after turning electronic key in starter switch to position 2 (together with the "SOS" button and the Information button.

See system self-check on page 182 when the indicator lamp does not light up in red or stays on longer than approximately 10 seconds.

If the indicator lamp in the Roadside Assistance button is illuminated continuously and there was no voice connection to the Response Center established, then the Tele Aid system could not initiate an Roadside Assistance call (e.g. the relevant cellular phone network is not available). The message "ROADSIDE ASSISTANCE – CALL FAILED" appears in the multifunction display.

Roadside Assistance calls can be terminated using the button on the multifunction steering wheel.

### Information button •—

A voice connection between the Client Assistance Center representative and the occupants of the vehicle will be established. When a voice connection is established the audio system mutes and the message "TELE AID – INFO CALL ACTIVE" appears in the multifunction display. Information regarding the operation of your vehicle, the nearest Mercedes-Benz Center or Mercedes-Benz USA products and services is available to you.

For more details concerning Tele Aid, please visit www.mbusa.com and use your ID and password, sent to you separately, to learn more (USA only).

#### Notes:

See system self-check on page 182 when the indicator lamp does not light up in red or stays on longer than approximately 10 seconds.

If the indicator lamp in the Information button is illuminated continuously and there was no voice connection to the Response Center established, then the

Tele Aid 187

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 factical lillies	Car care	data	HIGGA

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Tele Aid			18	88			

Instrument

Tele Aid system could not initiate an Information call (e.g. the relevant cellular phone network is not available). The message "INFO – CALL FAILED" appears in the multifunction display.

Information calls can be terminated using the button on the multifunction steering wheel.

# Important!

Instruments

If the indicator lamps do not start flashing after pressing one of the buttons or remain illuminated (in red) at any time, the Tele Aid system has detected a fault or the service is not currently active, and may not initiate a call. Visit your Mercedes-Benz Center and have the system checked or contact the Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada) as soon as possible.

Upgrade Signals

Tele Aid system processes calls using the following priority.

Tachnical

- Automatic emergency First priority
- Manual emergency Second priority
- Roadside assistance Third priority
- Information Fourth priority

Should a higher priority call be initiated while you are connected, an upgrade (alternating) tone will be heard, and the appropriate indicator lamp will flash. If certain information such as vehicle identification number or client information is not available, the operator may need to retransmit. During this time you will hear a chirp and voice contact will be interrupted. Voice contact will resume once the retransmission is completed. Once a call is concluded, a chirp will be heard and the appropriate indicator lamp will stop flashing. The COMAND system operation will resume (only vehicles with COMAND).

### Important!

If the indicator lamp continues to flash or the system does not reset, contact the Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada), or Mercedes-Benz Client Assistance at 1-800-FOR-MERCedes (1-800-367-6372) in the USA or Customer Service at 1-800-387-0100 in Canada.

#### Notes:

The indicator lamp in the respective button flashes until the call is concluded. Calls can only be terminated by a Response Center or Client Assistance Center representative except Roadside Assistance and Information calls, which can also be terminated by pressing button on the multifunction steering wheel.

When a Tele Aid call has been initiated, the audio system or the COMAND system audio (only vehicles with COMAND) is muted and the selected mode (radio, tape or CD) pauses. The optional cellular phone (if installed) switches off. If you must use this phone, the vehicle must be parked. Disconnect the coiled cord and place the call. The navigation system (if engaged) will continue to run. The display in the instrument cluster is available for use and spoken commands are only available by pressing the RPT button on the COMAND unit. A pop-up window will appear in the COMAND display to indicate that a Tele Aid call is in progress.

Tele Aid 189

and controls	Operation	Driving	cluster display	Practical nints	Car care	data	ingex
Tele Aid							
Rer	note door unlock			Notes:			

Instrument

Instruments

In the case you have your vehicle locked unintentionally (e.g. key inside vehicle), and the reserve key is not handy, contact the Mercedes-Benz Response Center at 1-800-756-9018 (in the USA) or 1-888-923-8367 (in Canada). You will be asked to provide your password which you provided when you completed the subscriber agreement.

Then return to your vehicle and press trunk lock for minimum of 20 seconds until the "SOS" button is flashing. The message "EMERGENCY CALL - CALL CONNECTED" appears in the multifunction display.

As an alternative, you may unlock the vehicle via Internet using the ID and password sent to you shortly after the completion of your Acquaintance Call.

The Response Center will then unlock your vehicle with the remote door unlocking feature.

#### motes:

The remote door unlock feature is available if the relevant cellular phone network is available.

The SOS button will flash and the message "EMERGENCY CALL - CALL CONNECTED" will appear in the multifunction display to indicate receipt of the door unlock command.

**Technical** 

Once the vehicle is unlocked, a Response Center specialist will attempt to establish voice contact with the vehicle occupants.

If the trunk lock was pressed for more than 20 seconds before door unlock authorization was received by the Response Center, you must wait 15 minutes before pressing trunk lock again.

### Stolen vehicle tracking services

In the event your vehicle was stolen, report the incident to the police who will issue a numbered incident report. Pass this number on to the Mercedes-Benz Response Center.

The Response Center will then attempt to covertly contact the vehicle's Tele Aid system. Once the vehicle is located, the Response Center will contact the local Law Enforcement and you. The vehicle's location will only be provided to Law Enforcement.

**Info Services** (optional, except Canada) (only vehicles with COMAND)

Info Services categories include news, sports, stocks, weather and calendar reminders. Choices can be selected via www.mbusa.com or by calling 1-800-FOR-MERcedes.

To request Info Services press the SVC button on the COMAND system, then select "SEND NEW REQUEST FOR INFO SERVICE". "NEW INFO SERVICE REQUEST TRANSMITTED" will appear in the COMAND display and call status messages will appear in the multifunction display.

Once information is available, the message "NEW INFO RECEIVED - READ LATER WHEN STOPPED?" will appear. Select "Yes". With the vehicle stopped in a safe location press SVC, then select "View Info Service of mm.dd.yyyy hh.mm". Messages will be retained for 30 minutes once the ignition is switched off.

### Important!

Tele Aid utilizes the cellular network for communication and the GPS (Global Positioning System) satellites for vehicle location. If either of these signals are unavailable, the Tele Aid system may not function and if this occurs, assistance must be summoned by other means.

# Warning!

If the indicator lamp in the "SOS" button does not illuminate during or remains illuminated after the system self-check or if the message "TELE AID – VISIT WORKSHOP" appears in the multifunction display, have the system checked at the nearest Mercedes-Benz Center as soon as possible.


Tele Aid 191

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 factical fiffics	Car care	data	HIGGA

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Steering lock

# **Steering lock**



O The electronic key can be withdrawn in this position only. The steering is locked when the electronic key is removed from the steering lock. If necessary, move steering wheel slightly to allow the locking mechanism to engage. The electronic key can only be removed with the selector lever in position "P". After removing the electronic key or with the electronic key in steering lock position 0, the selector lever is locked in position "P".

192

- Steering is unlocked.
- (If necessary, move steering wheel slightly to allow the electronic key to be turned clockwise to position 1.) Most electrical consumers can be operated. For detailed information see respective subjects.
- **2** Driving position.
- **3** Starting position.

See page 194 for starting and turning off the engine.

# Warning!

When leaving the vehicle always remove the electronic key from the steering lock, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Unsupervised use of vehicle equipment may cause serious personal injury.

### Important!

If the electronic key is left in the steering lock position 0 for an extended period of time, it can no longer be turned in the lock. In this case, remove electronic key from steering lock and reinsert.

#### Caution!

To prevent accelerated battery discharge and a possible dead battery, always remove the electronic key from the steering lock. **Do not** leave the electronic key in steering lock position 0.

#### Notes:

A warning sounds when the driver's door is opened while the electronic key is in steering lock position 1 or 0.

With the engine at idle speed, the charging rate of the alternator (output) is limited.

It is therefore recommended that you turn off unnecessary electrical consumers while driving in stopand-go traffic. This precaution helps to avoid draining of the battery.

Unnecessary strain on the battery and charging system may be minimized by turning off the following power consumers, for example: Heated seats, rear window defroster. In addition, the automatic climate air volume control should be set to the lowest position.

The steering lock can only be unlocked with the vehicle battery properly charged and connected.

Steering lock 193

# Practical hints

# Car care

# Technical data

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index

Starting and turning off the engine

# Starting and turning off the engine

# Before starting

Ensure that parking brake is engaged and that selector lever is in position "P" or "N". Turn electronic key in steering lock to position 2.

# **Starting**

Do not depress accelerator.

Briefly turn electronic key in steering lock clockwise to the stop and release. The starter will engage until the engine is running.

If engine will not run, and the starting procedure stops, turn electronic key completely to the left and repeat starting the engine.

After several unsuccessful attempts, have the system checked at the nearest authorized Mercedes-Benz Center.

# 194

# Important!

Due to the installed starter non-repeat feature, the electronic key must be turned completely to the left before attempting to start the engine again.

In areas where temperatures frequently drop below -4°F (-20°C) we recommend that an engine block heater be installed. Your authorized Mercedes-Benz Center will advise you on this subject.

# **Turning off**

Turn the electronic key in the steering lock to position 0 to stop the engine.

The electronic key can only be removed with the selector lever in position "P".

#### **Automatic transmission**



The automatic transmission selects individual gears automatically, dependent upon

- Selector lever position
- · Program mode selector
- · Accelerator position
- · Vehicle speed

The gear shifting process is continuously adapted, dependent on the driving style, the driving situation and the road characteristics.

# Important!

When parking the vehicle or before working on the vehicle with the engine running, firmly depress the parking brake pedal and shift the selector lever into "P".

**Automatic transmission** 

Inst	ruments
and	controls

# e Technical

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index

Automatic transmission

# Driving

The selector lever is automatically locked while in position "P". To move the selector lever out of position "P", the service brake pedal must be firmly depressed before the shift lock will release.

Shift selector lever to the desired position only when the engine is idling normally and the service brake is applied. Do not release the brake until ready to drive. The vehicle may otherwise start creeping when the selector lever is in drive or reverse position.

# Warning!

It is dangerous to shift the selector lever out of "P" or "N" if the engine speed is higher than idle speed. If your foot is not firmly on the brake pedal, the vehicle could accelerate quickly forward or in reverse. You could lose control of the vehicle and hit someone or something. Only shift into gear when the engine is idling normally and when your right foot is firmly on the brake pedal.

# 196

# Important!

After selecting any driving position from "N" or "P", wait a moment to allow the gear to fully engage before accelerating, especially when the engine is cold.

# **Accelerator position**

Partial throttle = early upshifting = normal acceleration
Full throttle = later upshifting = rapid acceleration
Kickdown (depressing the accelerator beyond full
throttle) = downshifting to a lower gear = maximum
acceleration. Once the desired speed is attained, ease up
on the accelerator - the transmission shifts up again.

# **Stopping**

For brief stops, e.g. at traffic lights, leave the transmission in gear and hold vehicle with the service brake.

For longer stops with the engine idling, shift into "N" or "P" and hold the vehicle with the service brake.

When stopping the vehicle on an uphill gradient, do not hold it with the accelerator, use the brake. This avoids unnecessary transmission heat build up.

# Maneuvering

To maneuver in tight areas, e.g. when pulling into a parking space, control the vehicle speed by gradually releasing the brakes. Accelerate gently and never abruptly step on the accelerator.

To rock a vehicle out of soft ground (mud or snow), alternately shift from forward to reverse, while applying slight partial throttle.

Rocking a vehicle free in this manner may cause the ABS or traction system malfunction indicator lamp to come on. Turn off and restart the engine to clear the malfunction indication.

# Warning!

Getting out of your vehicle with the selector lever not fully engaged in position "P" is dangerous. Also, when parked on an incline, position "P" alone may not prevent your vehicle from moving, possibly hitting people or objects.

Always set the parking brake in addition to shifting to position "P", see page 204 for parking brake.

When parked on an incline, also turn front wheel against curb.

# Warning!

When leaving the vehicle, always remove the electronic key from the steering lock, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could move the gear selector lever from position "P", which could result in an accident or serious personal injury.

**Automatic transmission** 

197

Inst	rument
and	control

# Technical data

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care data

**Automatic transmission** 

# **Selector lever position**



The current selector lever position is indicated in the gear range indicator display. The automatic gear shifting process can be adapted to specific operating conditions using the selector lever.

198

# P Park position

The park position is to be used when parking the vehicle. Engage only with the vehicle stopped. The park position is not intended to serve as a brake when the vehicle is parked. Rather, the driver should always use the parking brake in addition to placing the selector lever in park to secure the vehicle.

Index

### Note:

The electronic key can only be removed from the steering lock with the selector lever in position "P". With the electronic key removed, the selector lever is locked in position "P".

With a malfunction in the vehicle's electrical system the selector lever could remain locked in position "P". To unlock the selector lever manually, see page 279.

# R Reverse gear

Shift to reverse gear only with the vehicle stopped.

Dependent on the program mode selector switch position "S" or "W" the maximum speed in the reverse gear is different. However, it is not possible to change the program mode while in reverse.

#### N Neutral

No power is transmitted from the engine to the drive axle. When the brakes are released, the vehicle can be moved freely (pushed or towed). Do not engage "N" while driving except to coast when the vehicle is in danger of skidding (e.g. on icy roads, see winter driving instructions on page 211).

### Important!

Coasting the vehicle, or driving for any other reason with selector lever in "N" can result in transmission damage that is not covered by the Mercedes-Benz Limited Warranty.

The transmission automatically upshifts through 5th gear. Position "D" provides optimum driving characteristics under all normal operating conditions.

#### Gear selection for special circumstances

The transmission gear ranges for special circumstances can be selected by pressing the selector lever to the right or the left with the selector lever in position "D".

The gear range currently selected is indicated in the instrument cluster display.

Briefly press selector lever in the direction: The transmission downshifts, one gear at a time, in the order "4", "3", "2", "1".

Press and hold selector lever in the direction: The selector lever position display will switch to the gear range currently selected by the automatic transmission.

The transmission will only shift down one gear if the gear range currently selected has already shifted to its highest possible gear.

Briefly press selector lever in the direction:
The transmission will shift from the current gear range to the next higher gear range. If the transmission is already in gear range "D", an additional upshift of one gear is possible.

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 factical fiffics	Car care	data	HIUCA

# Automatic transmission

Press and hold selector lever in the + direction: The transmission will shift from the current gear directly to gear range "D".

# Warning!

On slippery road surfaces, never downshift in order to obtain braking action. This could result in drive wheel slip and reduced vehicle control. Your vehicle's ABS will not prevent this type of loss of control.

# Important!

With transmission in gear range "D", "4" or "3", upshifting from 1st to 2nd to 3rd gear is delayed depending on vehicle speed and engine temperature. This allows the catalytic converter to heat up more quickly to operating temperatures.

200

During the brief warm-up period this delayed upshift and increased engine noise might be perceived as a malfunction. However, neither the engine nor transmission are negatively affected by this mode of operation.

The delayed upshift is effective with vehicle speeds below 31 mph (50 km/h) at partial throttle and engine temperatures below 95°F (35°C).

To avoid overrevving the engine when the selector lever is moved to a lower gear range, the transmission will not shift to a lower gear, if the engine's revolutions per minute limit would be exceeded. In this case there will be no downshift, even when the vehicle speed reaches the engine's RPM limit of that gear, e.g. by applying the service brakes.

To prevent the engine from laboring at low RPM when driving uphill gradients or with your vehicle heavily loaded, the automatic transmission will downshift when necessary to maintain engine RPM within the best torque range.

#### Gear ranges:

- 4 Upshift through 4th gear only. Suitable for performance driving.
- Upshift through 3rd gear only. Suitable for moderately steep hills. Since the transmission does not shift higher than 3rd gear, this gear selection will allow use of the engine's braking power downhill.
- 2 Upshift through 2nd gear only. For driving in mountainous regions or under extreme operating conditions. This gear selection will allow use of the engine's braking power when descending steep grades.
- Use this position, which makes maximum use of the engine's braking effect, while descending very steep or lengthy downgrades and only at speeds below 40 mph (60 km/h).

**Automatic transmission** 

### Automatic transmission

# 202

# Program mode selector switch



The transmission is provided with a selector switch (1) for Standard "S" and Winter/Wet (snow and ice) "W" program modes.

### S Standard mode

Press switch on symbol "S". Use this mode for all regular driving.

The vehicle starts out in 1st gear.

# Accelerator Operation:

Fast on = depressing the accelerator pedal quickly (not into kickdown position) while driving continuously, rather than depressing the accelerator pedal in the usual manner, will cause the automatic transmission to shift down into a lower gear. This gear shifting process is dependent on the current vehicle speed.

Fast off = there will be no upshift when releasing the accelerator pedal quickly, e.g. using the engine's braking power during performance driving.

# W Winter/Wet (snow and ice) mode

Press switch on symbol "W". The vehicle starts out in 2nd gear, except with selector lever in 1st gear, or with accelerator pedal in kick-down position.

The "W" mode helps to improve traction and driving stability of the vehicle.

The gear shifting process occurs at lower vehicle and engine speeds than in the "S" program mode.

#### Caution!

Never change the program mode when the selector lever is out of position "P". It could result in a change of driving characteristics for which you may not be prepared.

# Important!

Always be certain of the program mode selected since the vehicle driving characteristics change with the selection of the program mode.

Dependent on the program mode selector switch position "S" or "W" and the gear selector lever in position "R", the ratio of power transmission changes.

# **Emergency operation (Limp home mode)**

If vehicle acceleration worsens or the transmission no longer shifts, the transmission is most likely operating in Limp home mode which engages when there is a malfunction of the transmission. This condition may be accompanied by the "CHECK ENGINE" malfunction indicator lamp in the instrument cluster coming on.

In this mode only the 2nd gear or reverse gear can be activated.

To engage 2nd gear or reverse:

- 1. Stop the vehicle.
- 2. Move selector lever to position "P".
- 3. Turn off the engine.
- 4. Wait approx. 10 seconds.
- 5. Restart the engine.
- 6. Move selector lever to position "D" (for 2nd gear), or move selector lever to position "R" (for reverse gear).

Have the transmission checked at your authorized Mercedes-Benz Center as soon as possible.

**Automatic transmission** 

203

Inst	ruments
and	controls


# Technical data

Index

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Parking brake

# Parking brake



204

To engage, firmly depress parking brake pedal. When the electronic key is in steering lock position 2, the brake warning lamp in the instrument cluster should come on brightly.

To release the parking brake, pull handle on instrument panel. The brake warning lamp in the instrument cluster should go out.

A warning sounds, if you start to drive without having released the parking brake.

Also see brake warning lamp on page 229.

# Warning!

When leaving the vehicle always remove the electronic key from the steering lock, and lock the vehicle. Do not leave children unattended in the vehicle, or with access to an unlocked vehicle. Children could release the parking brake, which could result in an accident or serious injury.

# **Driving instructions**

# **Drive sensibly - save fuel**

Fuel consumption, to a great extent, depends on driving habits and operating conditions.

To save fuel you should:

- keep tires at the recommended inflation pressures,
- · remove unnecessary loads.
- allow engine to warm up under low load use,
- avoid frequent acceleration and deceleration,
- have all maintenance work performed at regular intervals by an authorized Mercedes-Benz Center.

Fuel consumption is also increased by driving in cold weather, in stop-and-go traffic, on short trips and in hilly country.

### Drinking and driving

# Warning!

Drinking or taking drugs and driving can be a very dangerous combination. Even a small amount of alcohol or drugs can affect your reflexes, perceptions and judgement.

The possibility of a serious or even fatal accident is sharply increased when you drink or take drugs and drive.

Please don't drink or take drugs and drive or allow anyone to drive after drinking or taking drugs.

#### **Pedals**

# Warning!

Keep driver's foot area clear at all times. Objects stored in this area may impair pedal movement.

**Driving instructions** 

#### Power assistance

# Warning!

When the engine is not running, the brake and steering systems are without power assistance. Under these circumstances, a much greater effort is necessary to stop or steer the vehicle.

#### **Brakes**

# Warning!

After driving in heavy rain for some time without applying the brakes or through water deep enough to wet brake components, the first braking action may be somewhat reduced and increased pedal pressure may be necessary to obtain expected braking effect. Be sure to maintain a safe distance from vehicles in front.

Resting your foot on the brake pedal will cause excessive and premature wear of the brake pads.

It can also result in the brakes overheating thereby significantly reducing their effectiveness. It may not be possible to stop the vehicle in sufficient time to avoid an accident.

206

The condition of the parking brake system is checked each time the vehicle is in the shop for the required maintenance service.

If the parking brake is released and the brake warning lamp in the instrument cluster stays on, the brake fluid level in the reservoir is too low.

Brake pad wear or a leak in the system may be the reason for low brake fluid in the reservoir.

Have the brake system inspected at an authorized Mercedes-Benz Center immediately.

All checks and service work on the brake system should be carried out by an authorized Mercedes-Benz Center.

Install only brake pads and brake fluid recommended by Mercedes-Benz.

# Warning!

If other than recommended brake pads are installed, or other than recommended brake fluid is used, the braking properties of the vehicle can be degraded to an extent that safe braking is substantially impaired. This could result in an accident.

#### Caution!

When driving down long and steep grades, relieve the load on the brakes by shifting into a lower gear to use the engine's braking power. This helps prevent overheating of the brakes and reduces brake pad wear.

After hard braking, it is advisable to drive on for some time, rather than immediately parking, so the air stream will cool down the brakes faster.

# **Driving off**

Apply the service brakes to test them briefly after driving off. Perform this procedure only when the road is clear of other traffic.

Warm up the engine smoothly. Do not place full load on the engine until the operating temperature has been reached.

When starting off on a slippery surface, do not allow one drive wheel to spin for an extended period with the ESP switched off. Doing so may cause serious damage to the drive train which is not covered by the Mercedes-Benz Limited Warranty.

### **Parking**

# Warning!

To reduce the risk of personal injury as a result of vehicle movement, <u>before</u> turning off the engine and leaving the vehicle, always:

- 1. Keep right foot on the service brake pedal.
- 2. Firmly depress parking brake pedal.
- 3. Move the selector lever to position "P".
- 4. Slowly release the service brake pedal.
- 5. Turn front wheels towards the road curb.
- 6. Turn the electronic key to steering lock position 0 and remove.
- 7. Take the electronic key and lock vehicle when leaving.

# Important!

It is advisable to set the parking brake whenever parking or leaving the vehicle. In addition, move selector lever to position "P".

When parking on hills, always set the parking brake.

**Driving instructions** 

207

Inst	ruments
and	controls

# re Technical data

**Driving instructions** 

208

#### Tires


# Warning!

If you feel a sudden significant vibration or ride disturbance, or you suspect that possible damage to your vehicle has occurred, you should turn on the hazard warning flashers, carefully slow down, and drive with caution to an area which is a safe distance from the roadway.

Inspect the tires and under the vehicle for possible damage. If the vehicle or tires appear unsafe, have it towed to the nearest Mercedes-Benz Center or tire dealer for repairs.

Tread wear indicators (TWI) are required by law. These indicators are located in six places on the tread circumference and become visible at a tread depth of approximately  $^1/_{16}$  in (1.5 mm), at which point the tire is considered worn and should be replaced.

The tread wear indicator appears as a solid band across the tread.



# Warning!

Do not allow your tires to wear down too far. As tread depth approaches  $^1/_{16}$  in (1.5 mm), the adhesion properties on a wet road are sharply reduced.

Depending upon the weather and/or road surface (conditions), the tire traction varies widely.

Specified tire pressures must be maintained. This applies particularly if the tires are subjected to high loads (e.g. high speeds, heavy loads, high ambient temperatures).

# Warning!

Do not drive with a flat tire. A flat tire affects the ability to steer or brake the vehicle. You may lose control of the vehicle. Continued driving with a flat tire or driving at high speed with a flat tire will cause excessive heat build-up and possibly a fire.

# Aquaplaning

Depending on the depth of the water layer on the road, aquaplaning may occur, even at low speeds and with new tires. Reduce vehicle speed, avoid track grooves in the road and apply brakes cautiously in the rain.

#### Tire traction

The safe speed on a wet, snow covered or icy road is always lower than on a dry road.

You should pay particular attention to the condition of the road whenever the outside temperatures are close to the freezing point.

# Warning!

If ice has formed on the road, tire traction will be substantially reduced. Under such weather conditions, drive, steer and brake with extreme caution.

We recommend M+S rated radial-ply tires for the winter season for all four wheels to insure normal balanced handling characteristics. On packed snow, they can reduce your stopping distance as compared with summer tires. Stopping distance, however, is still considerably greater than when the road is not snow or ice covered.

**Driving instructions** 

209

# Technical data

Index

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index

**Driving instructions** 

# Tire speed rating

# CLK 320:

Your vehicle is factory equipped with "H"-rated tires, which have a speed rating of 130 mph (210 km/h).

# CLK 430:

Your vehicle is factory equipped with "W"-rated tires, which are permissible for speeds up to 168 mph (270 km/h).

An electronic speed limiter prevents your vehicle from exceeding a speed of 130 mph (210 km/h).

Despite the tire rating, local speed limits should be obeyed. Use prudent driving speeds appropriate to prevailing conditions.

# Warning!

Even when permitted by law, never operate a vehicle at speeds greater than the maximum speed rating of the tires.

Exceeding the maximum speed for which tires are rated can lead to sudden tire failure causing loss of vehicle control and resulting in personal injury and possible death.

# 210

### Snow chains

Use only snow chains that are tested and recommended by Mercedes-Benz. Your authorized Mercedes-Benz Center will be glad to advise you on this subject.

Chains should only be used on the rear wheels. Follow the manufacturer's mounting instructions.

Snow chains should only be driven on snow covered roads at speeds not to exceed 30 mph (50 km/h). Remove chains as soon as possible when driving on roads without snow.

When driving with snow chains, press the ESP control switch to OFF, refer to page 222.

# Important!

Use of snow chains is not permissible with tire sizes 225/45 R17 and 245/40 R17.

# Winter driving instructions

The most important rule for slippery or icy roads is to drive sensibly and to avoid abrupt acceleration, braking and steering maneuvers. Do not use the cruise control system under such conditions.

When the vehicle is in danger of skidding, move selector lever to position "N". Try to keep the vehicle under control by corrective steering action.

Road salts and chemicals can adversely affect braking efficiency. Increased pedal force may become necessary to produce the normal brake effect. We therefore recommend depressing the brake pedal periodically when traveling at length on salt-strewn roads. This can bring road salt impaired braking efficiency back to normal. A prerequisite is, however, that this be done without endangering other drivers on the road.

If the vehicle is parked after being driven on salt treated roads, the braking efficiency should be tested as soon as possible after driving is resumed while observing the safety rules in the previous paragraph.

# Warning!

If the vehicle becomes stuck in snow, make sure that snow is kept clear of the exhaust pipe and from around the vehicle with engine running. Otherwise, deadly carbon monoxide (CO) gases may enter vehicle interior resulting in unconsciousness and death.

To assure sufficient fresh air ventilation, open a window slightly on the side of the vehicle not facing the wind.

**Driving instructions** 

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index

**Driving instructions** 

# Winter driving

Have your vehicle winterized at your authorized Mercedes-Benz Center before the onset of winter.

- Change the engine oil if the engine contains an oil which is not approved for winter operation. For viscosity (SAE/CCMC class) and filling quantity, see page 317.
- Check engine coolant anticorrosion/antifreeze concentration.
- Additive for the windshield washer and headlamp cleaning system: Add MB Concentrate "S" to a premixed windshield washer solvent/antifreeze which is formulated for below freezing temperatures see page 259.
- Test battery: Battery capacity drops with decreasing ambient temperature. A well charged battery helps to ensure that the engine can be started, even at low ambient temperatures.
- Tires: We recommend M+S rated radial-ply tires on all four wheels for the winter season. Observe permissible maximum speed for M+S rated radial-ply tires and the legal speed limit.

212

In winter operation, the maximum effectiveness of the antilock brake system (ABS) or of the electronic stability program (ESP) can only be achieved with M+S rated radial-ply tires and/or snow chains recommended by Mercedes-Benz. Snow chains maximize performance.

For driving instructions with snow chains, see page 210.

# Deep water

### Caution!

Do not drive through flooded areas or water of unknown depth.

If you must drive through deep water, drive slowly to prevent water from entering the engine compartment or passenger compartment, being ingested by the air intake, possibly causing damage to electrical components or wiring, to engine or transmission that is not covered by the Mercedes-Benz Limited Warranty.

### Block heater (Canada only)

The engine is equipped with a block heater.

The electrical cable may be installed at your authorized Mercedes-Benz Center.

# Passenger compartment

# Warning!

Always fasten items being carried as securely as possible.

In an accident, during hard braking or sudden maneuvers, loose items will be thrown around inside the vehicle, and cause injury to vehicle occupants unless the items are securely fastened in the vehicle.

The trunk is the preferred place to carry objects.

Driving

### Traveling abroad

Abroad, there is a widely-spread Mercedes-Benz service network at your disposal. If you plan to travel into areas which are not listed in the index of your Mercedes-Benz Center directory, you should request pertinent information from your authorized Mercedes-Benz Center.

**Driving instructions** 




Operation

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

**Driving systems** 

#### Cruise control



The cruise control allows you to drive in a more relaxed manner, for example over long distances, as it automatically maintains the set speed by actively regulating the throttle setting.

Any given speed above approximately 25 mph (40 km/h) can be maintained with the cruise control by operating the lever.

#### 214

- 1 Accelerate and set: Lift lever briefly to set speed. Hold lever up to accelerate.
- 2 Decelerate and set: Depress lever briefly to set speed. Hold lever down to decelerate.

Normally the vehicle is accelerated to the desired speed with the accelerator.

Speed is set by briefly pushing the lever to position 1 or 2. The accelerator can then be released.

The speed can be increased (e.g. for passing) by using the accelerator. After the accelerator is released, the previously set speed will be resumed automatically.

If a set speed is to be increased or decreased slightly, e. g. to adapt to the traffic flow, hold lever in position 1 or 2 until the desired speed is reached, or briefly tip the lever in the appropriate direction for increases or decreases in 0.6 mph (1 km/h) increments. When the lever is released, the newly set speed remains.

# 3 Canceling

To cancel the cruise control, briefly push lever to position 3.

When you step on the brake pedal or the vehicle speed drops below approx. 25 mph (40 km/h), for example when driving upgrade, the cruise control will be canceled.

If the cruise control cancels by itself and remains inoperative until the engine is restarted, have the system checked at your authorized Mercedes-Benz Center as soon as possible.

#### 4 Resume

If the lever is briefly pushed to position 4 when driving at a speed exceeding approx. 25 mph (40 km/h), the vehicle resumes the speed which was set prior to the cancellation of the cruise control. The last memorized speed is canceled when the electronic key in the steering lock is turned to position 1 or 0.

# Important!

Moving gear selector lever to position "N" switches the cruise control off.

# Warning!

Only use the cruise control if the traffic and weather conditions make it advisable to travel at a steady speed.

- The use of cruise control can be dangerous on winding roads or in heavy traffic because conditions do not allow safe driving at a steady speed.
- The use of cruise control can be dangerous on slippery roads. Rapid changes in tire adhesion can result in wheel spin and loss of control.

The "Resume" function should only be operated if the driver is fully aware of the previously set speed and wishes to resume this particular preset speed.

**Driving systems** 

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 factical fiffits	Car care	data	Hucz

Driving systems

Notes:

If the engine does not brake the vehicle sufficiently while driving on a downgrade, the speed you set on the cruise control may be exceeded. In this case the automatic transmission shifts down (max. to 3rd gear) to maintain the set cruise control speed by using the engine's braking power.

As soon as the grade eases, the automatic transmission shifts up again dependent on the selector lever position.

Nevertheless, in some cases you may have to step on the brake pedal to slow down. In this case the cruise control is switched off.

Use the lever to resume the previously set speed.

216

Brake assist system (BAS)

Warning!

BAS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded. The BAS cannot prevent accidents, including those resulting from excessive speed in turns, following another vehicle too closely, or aquaplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of a BAS equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

The BAS is designed to maximize the vehicle's braking capability during emergency braking maneuvers by having maximum power boost applied to the brakes more quickly in emergency braking conditions than might otherwise be afforded solely by the driver's braking style. This can help reduce braking distances over what ordinary driving and braking style might do. The BAS complements the antilock brake system (ABS).

Applying the brakes very quickly results in maximum BAS assistance.

To receive the benefit of the system you must apply continuous full braking power during the stopping sequence. Do not reduce brake pedal pressure.

Once the brake pedal is released, the BAS is deactivated.

The malfunction indicator lamp for the electronic stability program (ESP) is combined with the BAS malfunction indicator lamp.

The BAS/ESP malfunction indicator lamp in the instrument cluster comes on with the electronic key in steering lock position 2 and should go out with the engine running.

If the BAS/ESP malfunction indicator lamp comes on permanently while the engine is running, a malfunction has been detected in either system. As a result, it is possible that now only partial engine output will be available. If the BAS malfunctions, the brake system functions in the usual manner, but without BAS.

If the charging voltage falls below 10 volts, the malfunction indicator lamp comes on and the BAS is switched off. When the voltage is above this value again, the malfunction indicator lamp should go out and the BAS is operational.

With the ABS malfunctioning, the BAS is also switched off. Both malfunction indicator lamps come on with the engine running.

If the BAS warning message is displayed, have the BAS or ESP checked at your authorized Mercedes-Benz Center as soon as possible.

**Driving systems** 

217

Instruments	Operation	Driving	Instrument
and controls	Operation	Dilving	cluster display

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dirving	cluster display	1 factical lillits	Cai care	data	muex

Driving systems

# Antilock brake system (ABS)

# Warning!

Do not pump the brake pedal, rather use firm, steady brake pedal pressure. Pumping the brake pedal defeats the purpose for ABS and significantly reduces braking effectiveness.

# Important!

The ABS improves steering control of the vehicle during hard braking maneuvers.

The ABS prevents the wheels from locking up above a vehicle speed of approximately 5 mph (8 km/h) independent of road surface conditions.

218

At the instant one of the wheels is about to lock up, a slight pulsation can be felt in the brake pedal, indicating that the ABS is in the regulating mode. Keep firm and steady pressure on the brake pedal while experiencing the pulsation.

Continuous steady brake pedal pressure results in applying the advantages of the ABS, namely braking power and ability to steer the vehicle.

In the case of an emergency brake maneuver keep continuous full pressure on the brake pedal. In this manner only can the ABS be most effective.

On slippery road surfaces, the ABS will respond even with light brake pedal pressure because of the increased likelihood of locking wheels. The pulsating brake pedal can be an indication of hazardous road conditions and functions as a reminder to take extra care while driving.

#### ABS control

The ABS malfunction indicator lamp in the instrument cluster comes on with the electronic key in steering lock position 2 and should go out with the engine running.

When the ABS malfunction indicator lamp in the instrument cluster comes on while the engine is running, it indicates that the ABS has detected a malfunction and has switched off. In this case, the brake system functions in the usual manner, but without antilock assistance.

For ABS malfunction indicator lamp, see page 231.

With the ABS malfunctioning, the BAS and ESP are also switched off. Both malfunction indicator lamps come on with the engine running.

If the charging voltage falls below 10 volts, the malfunction indicator lamp comes on and the ABS is switched off. When the voltage is above this value again, the malfunction indicator lamp should go out and the ABS is operational.

If the ABS malfunction indicator lamp stays illuminated, have the system checked at your authorized Mercedes-Benz Center as soon as possible.

# Warning!

ABS cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase braking or steering efficiency beyond that afforded by the condition of the vehicle brakes and tires or the traction afforded. The ABS cannot prevent accidents, including those resulting from excessive speed in turns, following another vehicle too closely, or aquaplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ABS equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

#### Note:

To alert following vehicles to slippery road conditions you discover, operate your hazard warning flashers as appropriate.

**Driving systems** 

219

Inst	ruments
and	controls

Instruments and controls

Operation

Operation

Operation

Driving

Instrument cluster display

Practical hints

Car care

Technical data

Index

Driving systems

# Electronic stability program (ESP)

# Warning!

ESP cannot prevent the natural laws of physics from acting on the vehicle, nor can it increase the traction afforded. The ESP cannot prevent accidents, including those resulting from excessive speed in turns, or aquaplaning. Only a safe, attentive, and skillful driver can prevent accidents. The capabilities of an ESP equipped vehicle must never be exploited in a reckless or dangerous manner which could jeopardize the user's safety or the safety of others.

The ESP enhances directional control and reduces driving wheel spin of the vehicle under various driving conditions.

Over/understeering of the vehicle is counteracted by applying brakes to the appropriate wheel to create a countervailing vehicle movement. Engine torque is also limited. The ESP warning lamp, located in the speedometer dial, starts to flash when ESP is in operation.

# 220

# Important!

If the ESP warning lamp flashes:

- During take-off apply as little throttle as possible.
- While driving ease up on the accelerator.
- Adapt your speed and driving to the prevailing road conditions.
- Do not switch off the ESP.

#### Caution!

If the vehicle is towed with the front axle raised (see towing the vehicle on page 276), the engine must be shut off (electronic key in steering lock position 0 or 1). Otherwise, the ESP will immediately be engaged and will apply the rear wheel brakes.

#### Notes:

The malfunction indicator lamp specific for the ESP is combined with that of the BAS.

The yellow BAS/ESP malfunction indicator lamp in the instrument cluster and the yellow ESP warning lamp in the speedometer dial come on with the electronic key in steering lock position 2. They should go out with the engine running.

If the BAS/ESP malfunction indicator lamp comes on continuously with the engine running, a malfunction has been detected in either system. Only partial engine output will be available.

If the BAS malfunctions, the brake system functions in the usual manner, but without BAS.

If the ESP warning message is displayed, have the BAS or ESP checked at your authorized Mercedes-Benz Center as soon as possible.

For ESP warning message, see page 245.

With the ABS malfunctioning, the ESP is also switched off.

Driving the vehicle with varied size tires will cause the wheels to rotate at different speeds, therefore the ESP may activate (yellow ESP warning lamp in speedometer dial comes on). For this reason, all wheels, including the spare wheel, must have the same tire outside diameter.

When testing the parking brake on a brake test dynamometer, the engine must be shut off. Otherwise, the ESP will immediately be engaged and will apply the rear wheel brakes.

In winter operation, the maximum effectiveness of the ESP is only achieved with Mercedes-Benz recommended M+S rated radial-ply tires and/or snow chains.

## **Synchronizing ESP**

If the power supply was interrupted (battery disconnected or empty), the BAS/ESP malfunction indicator lamp may be illuminated with the engine running.

Turn steering wheel completely to the left and then to the right. The BAS/ESP malfunction indicator lamp should go out.

**Driving systems** 

221

Inst	ruments
and	controls

Index

Operation

Driving

Instrument cluster display

**Practical hints** 

Car care

Technical data

Index

Driving systems

# **ESP** control switch



ESP control switch located on center console.

To switch ESP off, press upper half of the switch.

ESP warning lamp \_\_\_\_\_, located in speedometer dial, comes on.

To switch ESP on again, press lower half of the switch.

ESP warning lamp , located in speedometer dial, goes out.

222

To improve the vehicle's traction when driving with snow chains, or starting off in deep snow, sand or gravel, switch off ESP by pressing the upper half of the ESP switch. The ESP warning lamp \_\_\_\_\_\_\_, located in the speedometer dial, is continuously illuminated.

# Warning!

When the ESP warning lamp is illuminated continuously, the ESP is switched off.

Adapt your speed and driving to the prevailing road conditions.

With the ESP system switched off, the engine torque reduction feature is cancelled. Therefore, the enhanced vehicle stability offered by ESP is unavailable.

Adapt your speed and driving to the prevailing road conditions.

A portion of the ESP system remains active, even with the switch in the OFF position.

If one drive wheel loses traction and begins to spin, the brake is applied until the wheel regains sufficient traction. The traction control engages at vehicle speeds up to approximately 24 mph (40 km/h), and switches off at 50 mph (80 km/h).

#### Note:

Avoid spinning of one drive wheel. This may cause serious damage to the drive train which is not covered by the Mercedes-Benz Limited Warranty.

## Warning!

ESP should not be switched off during normal driving other than in circumstances described above. Disabling of the system will reduce vehicle stability in standard driving maneuvers.

The ESP warning lamp, located in the speedometer dial, starts to flash at any vehicle speed as soon as the tires lose traction and the wheels begin to spin.

To return to the enhanced vehicle stability offered by ESP: press lower half of the switch (the ESP warning lamp in the speedometer dial goes out).

# Important!

If the ESP warning lamp flashes:


- during take-off, apply as little throttle as possible,
- while driving, ease up on the accelerator.

Driving systems 223

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

What you should know at the gas station

# What you should know at the gas station



# Fuel supply

# Warning!

Gasoline is highly flammable and poisonous. It burns violently and can cause serious injury. Whenever you are around gasoline, avoid inhaling fumes and skin contact, extinguish all smoking materials. Never allow sparks, flame or smoking materials near gasoline! 224

Open flap by pushing near front (arrow). Turn fuel cap to the left and hold on to it until possible pressure in tank has been released, then remove cap. Failure to remove slowly could result in personal injury.

Manual release of fuel filler flap, see page 298.

# **Fuel**

To prevent fuel vapors from escaping into open air, fully insert filler nozzle unit. Only fill fuel tank until the filler nozzle unit cuts out – do not top up or overfill.

# Warning!

Overfilling of fuel tank may result in creating pressure in the system which could cause a gas discharge such as the gas spraying back out upon removing the filler nozzle which could cause personal injury.

Leaving the engine running and the fuel cap open can cause the "CHECK ENGINE" lamp to illuminate.

Fuel tank capacity approx. 16.4 US gal (62.0 l). This includes approx. 2.1 US gal (8.0 l) reserve. Use premium unleaded gasoline: Posted Octane Index 91 (Average of 96 RON/86 MON).

## · Engine oil

Engine oil level check, see page 112 and page 256.

Fill quantity between upper and lower dipstick marking level: 2.1 US qt (2.0 l).

Recommended engine oils, see Approved Service Products sheet.

#### Coolant

For normal replenishing, use water (potable water quality).

For further information (e.g. anticorrosion/antifreeze), see page 317.

# · Spark plugs

Approved spark plugs, see page 315.

# · Tire pressure

For tire pressure, refer to tire pressure label inside the fuel filler flap. See page 271 for further details.

#### · Air conditioner

R-134a refrigerant and special PAG lubricant, see page 317.


#### • Bulbs

High and low beams: H7 (55 W), low beam: Xenon (optional) fog lamps: H1 (55 W), turn signal lamps, front 1156 NA (26.9/5 W/32/4 cp), parking and standing lamps, front: H 6W (6 W), side marker lamps, front: 5 W/4 cp, turn signal lamps, rear: 21 W/24 cp, stop, tail, parking and side marker lamps: 21/4 W, tail and parking lamp: 5 W/4 cp, rear fog lamp, driver's side: 21 W/32 cp, backup lamps: 21 W/32 cp, license plate lamps: 5 W/4 cp.

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Check regularly and before a long trip

# Check regularly and before a long trip



226

- 1 Engine oil level See "Engine oil level, checking" on page 112 and page 256.
- **2 Coolant level** See "Coolant level" on page 257.
- **3 Brake fluid** See "Brake fluid" on page 319.
- 4 Windshield washer system
  Headlamp cleaning system
  For refilling reservoir see page 259.

Opening hood, see page 254.

**Vehicle lighting:** Check function and cleanliness. For replacement of light bulbs, see "Exterior lamps" on page 280.

Exterior lamp switch, see page 114.

# **Instrument cluster display**

Malfunction and
indicator lamps in the
instrument cluster228
On-board diagnostic system
Check engine malfunction
indicator lamp228
Brake warning lamp229
Supplemental restraint
system (SRS)
indicator lamp230
Fuel reserve and fuel cap
placement warning230
Electronic stability program
(ESP) – warning lamp231
BAS/ESP malfunction
indicator lamp231
ABS malfunction
indicator lamp231

Telescoping steering column -	-
indicator lamp	232
Seat belt warning lamp	232
Malfunction and indicator	
lamps in the	
center console	233
AIRBAG OFF	
indicator lamp	233
Roll bar warning lamp	233
Malfunction and	
warning messages in the	
multifunction display	234
DISPLAY DEFECTIVE	
(engine control unit)	235
DISPLAY DEFECTIVE	
(several systems)	235
BATTERY/ALTERNATOR	
ABS-SYSTEM	
BRAKE ASSIST	

BRAKE LINING WEAR	238
BRAKE FLUID	238
PARKING BRAKE	239
ENGINE FAN	239
COOLANT	
(coolant level)	240
COOLANT TEMP.	
(coolant temperature)	241
LIGHTING SYSTEM	242
LIGHT SENSOR	243
STEER. WHEEL ADJUST	243
ENGINE OIL LEVEL	244
ELEC. STABIL. PROG.	
(Electronic stability	
program)	
REMOVE KEY	245
WASHER FLUID	246
TELE AID	247

Contents – Instrument cluster display

Index

228

Malfunction and indicator lamps

# Malfunction and indicator lamps in the instrument cluster

General information:

If a bulb in the instrument cluster fails to light up during the bulb self-check when turning the electronic key in steering lock to position 2, have it checked and replaced if necessary.

# On-board diagnostic system Check engine malfunction indicator lamp



Engine malfunction indicator lamp. If the "CHECK ENGINE" malfunction indicator lamp comes on when the engine is running,

it indicates a malfunction of the fuel management system, emission control system, systems which impact emissions, or the fuel cap is not closed tight (check the fuel cap). If the "CHECK ENGINE" lamp is illuminated continuously and the vehicle is driving normally, you may still drive the vehicle, however, in all cases, we recommend that you have the system checked at your authorized Mercedes-Benz Center as soon as possible.

If the "CHECK ENGINE" lamp comes on continuously and/or the vehicle is not driving normally (e.g. malfunction of the fuel management system or running

out of fuel), serious damage can occur to the emission system. Please contact your authorized Mercedes-Benz Center immediately.

The Sequential Multiport Fuel Injection (SFI) control module monitors emission control components that either provide input signals to or receive output signals from the control module. Malfunctions resulting from interruptions or failure of any of these components are indicated by the "CHECK ENGINE" malfunction indicator lamp in the instrument cluster and are simultaneously stored in the SFI control module.

If the "CHECK ENGINE" malfunction indicator lamp comes on, have the system checked at your authorized Mercedes-Benz Center as soon as possible.

With some exceptions, the control module switches off the "CHECK ENGINE" malfunction indicator lamp if the condition, causing the lamp to come on, no longer exists during three consecutive cycles. See also page 230 for fuel cap placement warning.

An on-board diagnostic connector is located in the passenger compartment near to the parking brake pedal, allowing the accurate identification of system malfunctions through the readout of diagnostic trouble codes.

# Brake warning lamp



**Except Canada** 



Canada only

When the brake warning lamp and message appear while the engine is running, this means:

• there is insufficient brake fluid in the reservoir (engine running and parking brake released), or

Driving

• the parking brake is set (engine running).

# Warning!

Driving with the brake warning lamp illuminated can result in an accident. Have your brake system checked immediately if the brake warning lamp stays on. Don't add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

#### Note:

If you find that the minimum mark on the brake fluid reservoir is reached, have the brake system checked for brake pad thickness and leaks.

Instruments

and controls

Malfunction and	indicator	lamps
-----------------	-----------	-------

Operation

**Practical hints** 

Operation

Driving

Instrument cluster display

**Practical hints** 

Car care

Technical data

Index

Malfunction and indicator lamps

230

# Supplemental restraint system (SRS) indicator lamp



The operational readiness of the airbag system is verified by the indicator lamp "SRS" in the instrument cluster when

turning the electronic key in steering lock to position 1 or 2. If no malfunction is detected, the lamp will go out after approximately 4 seconds; after the lamp goes out, the system continues to monitor the components and circuitry of the airbag system and will indicate a malfunction by coming on again.

# Warning!

In the event a malfunction of the "SRS" is indicated as outlined above, the "SRS" may not be operational. For your safety, we strongly recommend that you visit an authorized Mercedes-Benz Center immediately to have the system checked; otherwise the "SRS" may not be activated when needed in an accident, which could result in serious or fatal injury, or it might deploy unexpectedly and unnecessarily which could also result in injury.

See page 66 for notes on airbags, see page 65 for belt tensioners and page 74 for infant and child seat restraint.

# Fuel reserve and fuel cap placement warning



When the warning lamp (1) comes on after starting the engine, or if it comes on while driving, it indicates that the fuel level is down to the reserve quantity of approximately 2.1 gal (8 liters).

The warning lamp blinks when the fuel cap is not closed, or a fuel system leak has been detected. Retighten cap and see if lamp goes out after restart and next OBD selfcheck.

If the warning lamp continues to blink after closing the fuel cap correctly, have the fuel system checked at your authorized Mercedes-Benz Center as soon as possible.

Leaving the engine running and the fuel cap open can also cause the "CHECK ENGINE" lamp to illuminate, see page 228.

# Electronic stability program (ESP) — warning lamp



The yellow ESP warning lamp in the speedometer dial comes on with the electronic key in steering lock position 2.

It should go out with engine running.

See page 220 if the warning lamp lights up or flashes when the vehicle is moving.

## BAS/ESP malfunction indicator lamp



The malfunction indicator lamp for the ESP is combined with that of the BAS.

The yellow BAS/ESP malfunction indicator lamp in the instrument cluster comes on with the electronic key in steering lock position 2. It should go out with the engine running.

If the BAS/ESP malfunction indicator lamp remains illuminated with the engine running, see page 216 for notes on the brake assist (BAS) and page 220 for notes on the electronic stability program (ESP).

# ABS malfunction indicator lamp



The ABS malfunction indicator lamp in the instrument cluster comes on with the electronic key in steering lock position 2 and

should go out with the engine running.

When the ABS malfunction indicator lamp symbol and warning in the instrument cluster remains illuminated while the engine is running, it indicates that the ABS has detected a malfunction and has switched off. In this case, the brake system functions in the usual manner, but without antilock assistance.

With the ABS malfunctioning, the BAS and ESP are also switched off. Both malfunction indicator lamps come on with the engine running.

If the charging voltage falls below 10 volts, the malfunction indicator lamp comes on and the ABS is switched off. When the voltage is above this value again, the malfunction indicator lamp should go out and the ABS is operational.

Have the system checked at your authorized Mercedes-Benz Center as soon as possible.

See page 218 for notes on the antilock brake system (ABS).

Malfunction and indicator lamps

[nst	ruments
and	controls

**Instruments** Instrument **Technical** Operation **Driving Practical hints** Car care Index cluster display and controls data Malfunction and indicator lamps 232

# Telescoping steering column - indicator lamp



The indicator lamp in the instrument cluster comes on with the electronic key in steering lock position 2 and should go out with the engine running.

If the indicator lamp does not go out after starting the engine, the adjustable steering column is not properly locked.

For locking the adjustable telescoping steering column, see page 76.

# Seat belt warning lamp



With the electronic key in steering lock position 2, the seat belt warning lamp comes on and a warning sounds for approx.

6 seconds if the driver's seat belt is not fastened.

# Malfunction and indicator lamps in the center console

# AIRBAG OFF indicator lamp

The ABBAG indicator lamp will light up for approx. 6 seconds when you turn the electronic key in steering lock to position 1 or 2.

The ABBAG indicator lamp stays lit as long as a BabySmart<sup>TM</sup> compatible child seat is properly installed on the front passenger seat. It indicates that the front passenger airbag is switched off.

See page 64 for BabySmart<sup>TM</sup> deactivation system.

 $BabySmart^{TM}$  is a trademark of Siemens Automotive Corp.

# Roll bar warning lamp

The roll bar warning lamp is located in the roll bar switch in the center console. Roll bar switch see page 52.

With the electronic key in steering lock position 2, the roll bar warning lamp comes on and should go out with the engine running.

With the engine running and the roll bar lowered, the warning lamp in the roll bar switch will blink for approx. 15 seconds. The blinking is reminding you to raise the roll bar if the rear passenger seats are occupied.

# Warning!

If the warning lamp does not go out after starting the engine, or if it comes on while driving, then the roll bar system is not operating properly and may not activate in an accident. In this case, raise the roll bar manually (see page 53) before continuing to drive.

#### Note:

Have the roll bar system checked at your authorized Mercedes-Benz Center as soon as possible.

Malfunction and indicator lamps

233

Inst	ruments
and	controls

# Technical

Index

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Malfunction a	and warning messa	iges	23	34			

9

# Malfunction and warning messages in the multifunction display

Malfunction and warning messages for the following systems will be displayed immediately in the multifunction display.

These messages can be cleared from the instrument cluster by:

- using the **(B)** button on the instrument cluster, or
- pressing button 💪 , 💎 , 🗊 or 🗊 on the multifunction steering wheel.

They are then stored in the malfunction message memory. See page 104.

# 234

## Notes:

Certain malfunction and warning messages are accompanied by an audible signal.

Malfunction and warning messages in red are always accompanied by an audible signal.

Temporary messages such as "SWITCH OFF LIGHTS" will not be stored in the malfunction message memory.

# Warning!

All messages contain important information which should be taken note of and, where malfunction indicated, addressed as soon as possible at an authorized Mercedes-Benz Center.

Failure to repair condition noted may cause damage not covered by the Mercedes-Benz Limited Warranty, or result in property damage or personal injury.

# **DISPLAY DEFECTIVE (engine control unit)**



Line 1	Line 2
DISPLAY DEFECTIVE	VISIT WORKSHOP!

This message is displayed to indicate that the information being relayed by the engine control unit is no longer complete. The coolant temperature gauge, tachometer, or the cruise control may have failed.

# **DISPLAY DEFECTIVE (several systems)**



Line 1	Line 2
DISPLAY DEFECTIVE	VISIT WORKSHOP!

The displays for several systems have failed. Some systems themselves may also have failed.

Instruments

and controls

**Driving** 

Instrument cluster display

**Practical hints** 

235

Car care

**Technical** data

Index

Operation

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index

Malfunction and warning messages

# BATTERY/ALTERNATOR



Line 1	Line 2
BATTERY/ALTERNATOR	VISIT WORKSHOP!
OVERVOLTAGE	VISIT WORKSHOP!
UNDERVOLTAGE	CONSUMER DEFECTIVE!

236

This message indicates a malfunction which must be repaired immediately.

It may indicate that the poly-V-belt has broken. Should this condition occur, the poly-V-belt must be replaced before continuing to operate the vehicle. Otherwise, the engine will overheat due to an inoperative water pump which may result in damage to the engine.

Do not continue to drive the vehicle with this message displayed.

Doing so could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

#### ABS-SYSTEM



Line 1	Line 2
ABS-SYSTEM	VISIT WORKSHOP!

A malfunction has been detected in the system. The brake system functions in the usual manner, but without antilock assistance.

With the ABS malfunctioning, the BAS and ESP are also switched off.

Have the system checked at your authorized Mercedes-Benz Center as soon as possible.

#### BRAKE ASSIST

# BRAKE ASSIST BAS VISIT WORKSHOP!

Line 1	Line 2
BRAKE ASSIST	VISIT WORKSHOP!
DISPLAY DEFECTIVE	VISIT WORKSHOP!

A malfunction has been detected in the system. The brake system functions in the usual manner, but without BAS.

Malfunction and warning messages

237

Inst	ruments
and	controls

# Technical data

238

Malfunction and warning messages

# **BRAKE LINING WEAR**



Line 1	Line 2
BRAKE LINING WEAR	VISIT WORKSHOP!

When this message appears during braking, it indicates that the brake pads are worn down.

Have the brake system checked at your authorized Mercedes-Benz Center as soon as possible.

# BRAKE FLUID



Line 1 Line 2

BRAKE FLUID VISIT WORKSHOP!

# Warning!

Driving with this message displayed can result in an accident. Have your brake system checked immediately. Don't add brake fluid before checking the brake system. Overfilling the brake fluid reservoir can result in spilling brake fluid on hot engine parts and the brake fluid catching fire. You can be seriously burned.

# PARKING BRAKE



Line 1	Line 2
PARKING BRAKE	RELEASE BRAKE!

Parking brake, see page 204.

#### ENGINE FAN



Line 1	Line 2
ENGINE FAN	VISIT WORKSHOP! <sup>1</sup>

1 The cooling fan for the coolant is faulty. Observe coolant temperature gauge while driving, see page 86.

Operation

Driving

Instrument cluster display

Practical hints


Car care

care Technical data

Index

Malfunction and warning messages

# COOLANT (coolant level)



Line 1	Line 2
COOLANT	CHECK LEVEL!

When this message appears while driving, the coolant level has dropped below the required level. If no leaks are noticeable and the engine temperature does not increase, continue to drive to the nearest service station and have coolant added to the coolant system.

240

The low engine coolant level warning should not be ignored. Extended driving with the symbol displayed may cause serious engine damage not covered by the Mercedes-Benz Limited Warranty.

In cases of major or frequent minor coolant loss, have the cooling system checked at your authorized Mercedes-Benz Center as soon as possible.

#### Notes:

Do not drive without coolant in the cooling system. The engine will overheat causing major engine damage.


Monitor the coolant temperature gauge while driving.

See page 257 for instructions on adding coolant.

# Warning!

Do not spill antifreeze on hot engine parts. Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts. You can be seriously burned.

# **COOLANT TEMP.** (coolant temperature)



Line 1	Line 2
COOLANT TEMP.	VISIT WORKSHOP! <sup>1</sup>

Observe coolant temperature gauge, see page 86.
 Check coolant level, see page 257.

This may indicate that the poly-V-belt has broken. Should this condition occur, the poly-V-belt must be replaced before continuing to operate the vehicle. Otherwise, the engine will overheat due to an inoperative water pump which may result in damage to the engine. Do not continue to drive the vehicle with this message displayed. Doing so could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

During severe operating conditions and stop-and-go city traffic, the coolant temperature may rise close to the red marking.

The engine should not be operated with the coolant temperature in the red zone. Doing so may cause serious engine damage which is not covered by the Mercedes-Benz Limited Warranty.

# Warning!

Driving when your engine is badly overheated can cause some fluids which may have leaked into the engine compartment to catch fire. You could be seriously burned.


Steam from an overheated engine can cause serious burns and can occur just by opening the engine hood. Stay away from the engine if you see or hear steam coming from it.

Turn off the engine, get out of the vehicle and do not stand near the vehicle until it cools down.

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	Fractical lillits	Car care	data	muex

Malfunction and warning messages

# LIGHTING SYSTEM



Line 1	Line 2
LAMP DEFECTIVE	CHECK LAMPS!
DISPLAY DEFECTIVE	VISIT WORKSHOP!

242

When the message appears after starting the engine, or if it comes on while driving, this indicates a failure in the parking lamp, taillamp, stop lamp, or low beam headlamp. See page 280 for instructions on replacing bulbs.

If an exterior lamp fails, the message will appear only when that lamp is switched on.

If a brake lamp fails, the message will appear when applying the brake and stays on until the engine is turned off.

#### Note:

If additional lighting is installed (e.g. auxiliary headlamps etc.) be certain to connect into the fuse before the failure indicator monitoring unit order to avoid damaging the system.

#### LIGHT SENSOR



With the electronic key removed and the driver's door open, a warning sounds and the message "SWITCH OFF LIGHTS!" appears in the multifunction indicator if the vehicle's exterior lamps (except standing lamps) are not switched off.

## STEER. WHEEL ADJUST.



Line 1	Line 2
	STEER. WHEEL ADJUST.

For locking the adjustable telescoping steering column, see page 76.

Malfunction and warning messages

243

Instruments	Operation	Driving	Instrument
and controls	Operation	Dilving	cluster display

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 ractical mints	Cur cure	data	Index

Malfunction and warning messages

# ENGINE OIL LEVEL



Line 1	Line 2
ENGINE OIL LEVEL	CHECK LEVEL! <sup>1</sup>
ENGINE OIL LEVEL	STOP, ENGINE OFF! <sup>2</sup>
ENGINE OIL LEVEL	REDUCE OIL LEVEL! <sup>3</sup>
ENGINE OIL LEVEL	VISIT WORKSHOP! <sup>4</sup>
ENGINE OIL SENSOR	VISIT WORKSHOP! <sup>5</sup>
ENGINE OIL	VISIT WORKSHOP!6

- 1 The engine oil level must be checked immediately. See Engine oil level indicator on page 112
- 2 There is no oil in the engine. There is a danger of engine damage.

# 244

- 3 There is a risk of damaging the engine or catalytic converter. The engine oil level must be checked immediately. See Engine oil level indicator on page 112.
- 4 The engine oil level has dropped to a critical level. Check the engine oil level immediately. See Engine oil level indicator on page 112 and check the engine for visible leakage (loss of oil).
- 5 The measuring system is malfunctioning.
- 6 It may be that there is water in the engine oil. Have the engine oil checked.

When the "ENGINE OIL LEVEL - CHECK LEVEL" message appears while the engine is running and at operating temperature, the engine oil level has dropped to approximately the minimum mark on the dipstick.

When this occurs, the warning will first come on intermittently and then stay on if the oil level drops further.

If no oil leaks are noted, continue to drive to the nearest service station where the engine oil should be topped to the "full" mark on the dipstick with an approved oil.

The engine oil level warnings should not be ignored. Extended driving with the symbol displayed could result in serious engine damage that is not covered by the Mercedes-Benz Limited Warranty.

# ELEC. STABIL. PROG. (Electronic stability program)

# ELEC. STABIL. PROG.

# **ESP**

# VISIT WORKSHOP!

P54.30-2125-21

Line 1	Line 2
DISPLAY DEFECTIVE	VISIT WORKSHOP!
ELEC. STABIL. PROG.	VISIT WORKSHOP! <sup>1, 2, 3</sup>

- 1 A malfunction has been detected in the system. Pressing the accelerator pedal will require greater effort. Only partial engine output will be available.
- 2 This message may be displayed if the power supply was interrupted (battery disconnected or empty).
- 3 Synchronize ESP. See page 221

#### REMOVE KEY



Line 1	Line 2
	REMOVE KEY!

This message plus an audible alarm indicate that the electronic key is in steering lock position 0 or 1, and the driver's door is open.

Malfunction and warning messages

245

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	-------------------------------	-----------------	----------	-------------------	-------

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index

Malfunction and warning messages

# WASHER FLUID



Line 1	Line 2
WASHER FLUID	CHECK LEVEL!

246

When this message appears while the engine is running, the level of the reservoir has dropped to approx. <sup>1</sup>/<sub>3</sub> of the total volume. The reservoir should be refilled with the prescribed mixture of MB Windshield Washer Concentrate "S" and water or the Concentrate and commercially available premixed windshield washer solvent/antifreeze, depending on ambient temperature, at the next opportunity. The reservoir for the windshield and headlamp washer systems is located in the engine compartment.

See windshield washer system on page 259 for instructions on adding washer fluid.

#### TELE AID



Line 1	Line 2
TELE AID	VISIT WORKSHOP! <sup>1</sup>

1 When this message appears, a malfunction has been detected in the Tele Aid system. In some cases it may not be possible to initiate an Emergency, Roadside Assistance or Information call.

See page 182 for notes on the Tele Aid.

If a malfunction is indicated as outlined above, have the system checked at the nearest Mercedes-Benz Center as soon as possible.

Malfunction and warning messages

`	1	7	
,	4	. /	

Instruments	Operation	Driving	Instrument	Instrument cluster display  Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display			data	

# **Practical hints**

First aid kit	250
Shelf below rear window	250
Stowing things in	
the vehicle	250
Luggage cover	250
Fuses	252
Hood	254
Checking engine oil level	256
Automatic transmission	
fluid level	257
Coolant level	257
Adding coolant	258
Windshield washer / headlamp	
cleaning system	259

259
260
261
262
262
263
264
266
271
272
274
276
280
281
283

Adjusting headlamp aim	.285
Changing batteries in	
the electronic main key	.288
Synchronizing	
remote control	.290
Raising soft top manually	. 291
Antenna	.298
Manual release for	
fuel filler flap	.298
Frunk lamp	.299
Replacing wiper	
blade insert	.299

**Driving** 

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

First aid kit 250

#### First aid kit

The first aid kit is stored in the left trunk well.

#### Shelf below rear window

### Warning!

The shelf below the rear window should not be used to carry objects. This will avoid such objects from being thrown about and injuring vehicle occupants during an accident or sudden maneuver.

The trunk is the preferred place to carry objects.

#### Stowing things in the vehicle

#### Warning!

To help avoid personal injury during a collision or sudden maneuver, exercise care when stowing things. Put luggage or cargo in the trunk if possible. Do not pile luggage or cargo higher than the seat backs. Do not place anything on the shelf below the rear window.

#### Luggage cover



- 1 Handle
- 2 Holder

To close compartment:

Pull out on handle (1) to the stop and guide luggage cover into left and right holders (2).



#### To open compartment:

Press button (arrow). Unhook luggage cover from holders (2) and guide luggage cover with handle (1) into storage compartment until handle (1) locks in place.

#### Important!

To prevent damage to soft top or luggage/cargo when lowering the roof:

- load trunk only to the height of the luggage cover,
- do not permit luggage/cargo to raise the closed luggage cover,
- do not load anything on top of the luggage cover,
- do not operate the luggage cover with the soft top lowered. Doing so will result in damage to the luggage cover or the soft top.

#### Note:

Opening and closing of the soft top can only be done with the luggage cover and trunk lid closed.

Luggage cover 251

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 Tactical IIIIts	Car care	data	HIGGA

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Fuses 252

#### **Fuses**

Before replacing a blown fuse, determine the cause of the short circuit.


Spare fuses are supplied inside the main fuse box (1). Observe amperage and color of fuse.  $\$ 

A special fuse puller is supplied with the vehicle tools.

Always use a new fuse for replacement. Never attempt to repair or bridge a blown fuse.

A fuse chart can be found inside the corresponding fuse box cover.

### Fuse box in engine compartment




1 Main fuse box in engine compartment

To gain access to the main fuse box (1), press clamp (arrow), lift the fuse box cover up and remove it.


To close the main fuse box, engage back end of cover and let front end snap into place.

#### Auxiliary fuse box below the trunk floor



**2** Auxiliary fuse box below the trunk floor. To gain access, lift trunk floor.

#### Auxiliary fuse box in the dashboard



**3** Auxiliary fuse box to left of exterior lamp switch. To gain access, open door, pry off cover (3) and remove.

care

**Technical** 

data

Index

Fuses 253

instruments	Operation	Driving	instrument	Practical hints	Car
and controls	Operation	Dilving	cluster display	Fractical lillits	Car

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dirving	cluster display	1 ractical mints	Cui cui c	data	mucx

Engine compartment

#### Hood

#### Warning!

To help prevent personal injury, stay clear of moving parts when the hood is open and the engine is running. Be sure the hood is properly closed before driving. When closing hood, use extreme caution not to catch hands or fingers.


The radiator fan may continue to run for approximately 30 seconds or even restart after the engine has been turned off. Stay clear from fan blades.

254

The engine is equipped with a transistorized ignition system. Because of the high voltage it is dangerous to touch any components (ignition coils, spark plug sockets, diagnostic socket) of the ignition system

- with the engine running,
- · while starting the engine,
- if ignition is "on" and the engine is turned manually.

If you see flames, steam or smoke coming from the engine compartment, or if the coolant temperature gauge indicates that the engine is overheated, do not open the hood. Move away from vehicle and do not open the hood until the engine has cooled. If necessary, call a fire department.




#### To open:

To unlock the hood, pull release lever (1) under the driver's side of the instrument panel. At the same time a handle will extend out of the radiator grill (it may be necessary to lift the hood up slightly).

#### Caution!

To avoid damage to the windshield wiper or hood, open the hood only with wiper in the parked position.



Pull handle (2) to its stop out of radiator grill and open hood (do not pull up on handle).

#### To close:

Lower hood and let it drop into lock from a height of approx. 1 ft. (30 cm), assisting with hands placed flat on edges of hood (3).

To avoid hood damage, please make sure that hood is fully closed. If not, repeat closing procedure. Do not push down on hood to attempt to fully close it.

# Technical data

Instruments operation and controls Operation Driving Operation Driving Operation Driving Operation Driving Operation Driving Operation Operation Driving Operation

**Engine compartment** 

#### Checking engine oil level (CLK 320 shown)



- 1 Oil dipstick
- 2 Oil filler cap

To check the engine oil level, park vehicle on level ground, with engine at normal operational temperature.

Check engine oil level approximately 5 minutes after stopping the engine, allowing for the oil to return to the oil pan.

256

Wipe oil dipstick clean prior to checking the engine oil level. Fully insert dipstick in tube, and remove after three seconds to obtain accurate reading.



Oil level must be between the lower (min) and upper (max) mark of the dipstick.

Fill quantity between upper and lower dipstick marking level is approximately 2.1 US qt (2.0 l).

<u>Do not overfill the engine.</u> Excessive oil must be drained or siphoned. It could cause damage to engine and catalytic converter not covered by the Mercedes-Benz Limited Warranty.

See malfunction and warning messages on page 234 if an engine oil level display appears on the multifunction display when the engine is running.

Note:

See page 112 for engine oil level indicator.


#### Automatic transmission fluid level

The transmission has a permanent fill of automatic transmission fluid.

Regular automatic transmission fluid level checks and changes are not required. For this reason the dipstick is omitted.

If you notice fluid leaks or gear shifting malfunctions, have your authorized Mercedes-Benz Center check the transmission fluid level.

#### **Coolant level**



To check the coolant level, the vehicle must be parked on level ground and the engine stopped.

Check coolant level only when coolant is cold.

The coolant level should reach the black top part of the reservoir.

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index

258

Engine compartment

### Adding coolant

If coolant has to be added, a 50/50 mixture of water and MB anticorrosion/antifreeze should be added.

The drain plugs for the cooling system are located on the right side of the engine block and at the bottom of the radiator.

Anticorrosion/antifreeze mixture, see page 322.


### Warning!

In order to avoid possible serious burns or injury:

- Use extreme caution when opening the hood if there are any signs of steam or coolant leaking from the cooling system, or if the coolant temperature gauge indicates that the coolant is overheated.
- Do not remove pressure cap on coolant reservoir if engine temperature is above 194°F (90°C). Allow engine to cool down before removing cap. The coolant reservoir contains hot fluid and is under pressure.

- Using a rag, slowly open cap approximately 1/2 turn to relieve excess pressure. If opened immediately, scalding hot fluid and steam will be blown out under pressure.
- Do not spill antifreeze on hot engine parts.
   Antifreeze contains ethylene glycol which may burn if it comes into contact with hot engine parts.

#### Windshield washer/headlamp cleaning system



1 Windshield washer/headlamp cleaning system fluid reservoir

Capacity approx. 7.4 US qt (7.0 l).

The reservoir should be refilled with MB Windshield washer concentrate and water (or commercially available premixed windshield washer solvent/antifreeze, depending on ambient temperatures).

#### Warning!

Washer solvent/antifreeze is highly flammable. Do not spill washer solvent/antifreeze on hot engine parts, because it may burn. You can be seriously burned.

## Windshield and headlamp washer fluid mixing ratio

For temperatures above freezing:

MB Windshield Washer Concentrate "S" and water.

1 part "S" to 100 parts water (40 ml "S" to 1 gallon water).

For temperature below freezing:


MB Windshield Washer Concentrate "S" and commercially available premixed windshield washer solvent/antifreeze.

1 part "S" to 100 parts solvent (40 ml "S" to 1 gallon solvent).

### Car care

# Technical data

#### Spare wheel, vehicle tools, storage compartment



- 1 Trunk floor
- 2 Handle
- 3 Luggage bowl
- 4 Vehicle tools

260

Lift trunk floor and engage handle in grip molding of luggage cover.

To remove spare tire:

Turn luggage bowl counterclockwise and remove.


To store spare tire:

Place spare tire in wheel well and secure it with luggage bowl. Turn luggage bowl clockwise to its stop.

Note:

Always lower trunk floor before closing trunk lid.

#### Vehicle jack



- 1 Jack arm
- 2 Jack base

See illustration for proper storage of jack.

Before storing the jack on the felt in the spare wheel well, the jack arm must be lowered almost to the base of the jack.

#### Warning!

The jack is designed exclusively for jacking up the vehicle at the jack tubes built into either side of the vehicle. To help avoid personal injury, use the jack only to lift the vehicle during a wheel change. Never get beneath the vehicle while it is supported by the jack. Keep hands and feet away from the area under the lifted vehicle. Always firmly set parking brake and block wheels before raising vehicle with jack.

Do not disengage parking brake while the vehicle is raised. Be certain that the jack is always vertical when in use, especially on hills. Always try to use the jack on level surface. Be sure that the jack arm is fully inserted in the jack tube. Always lower the vehicle onto sufficient capacity jackstands before working under the vehicle.

Index

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
/D: XA/1 1			0.4	· · · · · · · · · · · · · · · · · · ·			

Tires, Wheels

#### Wheels

Replace rims or tires with the same designation, manufacturer and type as shown on the original part. See your authorized Mercedes-Benz Center for further information.

See your authorized Mercedes-Benz Center for information on tested and recommended rims and tires for summer and winter operation. They can also offer advice concerning tire service and purchase.

#### Tire replacement

Front tires should be replaced in sets. Rims and tires must be of the correct size and type. For dimensions, see "Technical Data" (page 314).

We recommend that you break in new tires for approx. 60 miles (100 km) at moderate speed.

262

It is imperative that the wheel mounting bolts be fastened to a tightening torque of 80 ft.lb. (110 Nm) whenever wheels are mounted.

For rim and tire specifications, refer to "Technical Data" (page 314).

#### Warning!

Worn, old tires can cause accidents. If the tire tread is badly worn, or if the tires have sustained damage, replace them.

When replacing rims, use only genuine Mercedes-Benz wheel bolts specified for the particular rim type. Failure to do so can result in the bolts loosening and possibly an accident.

#### **Rotating wheels**

CLK 430:

Wheel rotation applies only when winter tires are mounted on all four wheels.

The wheels can be rotated according to the degree of tire wear while retaining the same direction of travel.

Rotating, however, should be carried out as recommended by the tire manufacturer, before the characteristic tire wear pattern (shoulder wear on front wheels and tread center wear on rear wheels) becomes visible, as otherwise the driving properties deteriorate.

#### Important!

Unidirectional tires must always be mounted with arrow on tire sidewall pointing in direction of vehicle forward movement.

#### Notes:

Thoroughly clean the inner side of the wheels any time vou rotate the wheels or wash the vehicle underside.

The use of retread tires is not recommended. Retread. tires may adversely affect the handling characteristics and safety of the vehicle.

Dented or bent rims can cause tire pressure loss and damage to the tire beads. For this reason, check rims for damage at regular intervals. The rim flanges must be checked for wear before a tire is mounted. Remove burrs, if any.

Check and ensure proper tire inflation pressure after rotating the wheels. For tire inflation pressure see inside of fuel filler flap and also page 271.

Tires, Wheels 263

Operation

## Practical hints

Car care

**Technical** data

Index

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Tires, Wheels			20	64			

### Spare wheel

Inctmimonto

### Spare wheel CLK 320

### Important!

The spare wheel rim is mounted with a full size tire of the same type as on the vehicle, and is fully functional. However, that spare wheel rim is weight optimized and has a limited service life of 12 000 miles (20 000 km) use before a standard wheel rim must replace it.

In the case of a flat tire, you may temporarily use the spare wheel.

Do not operate vehicle with more than one spare wheel mounted.

Unidirectional tires must always be mounted with arrow on tire sidewall pointing in direction of vehicle forward movement.

If the arrow on tire side wall does not point in direction of vehicle forward movement when using the spare wheel, observe the following restriction:

• Drive to the nearest tire repair facility as soon as possible.

For rim and tire specifications, refer to "Technical Data" (page 314).

#### Warning!

The spare wheel rim is for temporary use only. Use for over a total of 12 000 miles (20 000 km) (aggregate of all uses) may cause wheel rim failure leading to an accident and possible injuries.

#### Spare wheel CLK 430

#### Important!

The spare wheel rim size is  $7^{1}/_{2}$  J x 17 H 2.

The spare wheel rim is mounted with a full size tire of the same type as on the vehicle's front axle, and is fully functional. However, that spare wheel rim is weight optimized and has a limited service life of 12 000 miles (20 000 km) use before a standard wheel rim must replace it.

If the arrow on tire side wall does not point in direction of vehicle forward movement when using the spare wheel, observe the following restriction:

Drive to the nearest tire repair facility as soon as possible.

In the case of a rear axle flat tire, you may temporarily use the spare wheel, when observing the following restrictions:

- Do not exceed vehicle speed of 50 mph (80 km/h)
- Drive to the nearest tire repair facility to have the flat tire repaired or replaced as appropriate.

Do not operate vehicle with more than one spare wheel mounted.

Unidirectional tires must always be mounted with arrow on tire sidewall pointing in direction of vehicle forward movement.

For rim and tire specifications, refer to "Technical Data" (page 314).

#### Warning!

The spare wheel rim is for temporary use only. Use for over a total of 12 000 miles (20 000 km) (aggregate of all uses) may cause wheel rim failure leading to an accident and possible injuries.

The dimensions of the spare wheel are different from those of the road wheels for the rear axle. As a result, the vehicle handling characteristics change when driving with a spare wheel mounted on the rear axle.

The spare wheel should only be used temporarily, and replaced with a regular road wheel as quick as possible.

Tires, Wheels 265

Inst	ruments
and	controls

# Instrument cluster display

### Car care

## e Technical

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

266

Tires, Wheels

### Warning!

Changing wheels

The jack is designed exclusively for jacking up the vehicle at the jack tubes built into either side of the vehicle. To help avoid personal injury, use the jack only to lift the vehicle during a wheel change. Never get beneath the vehicle while it is supported by the jack. Keep hands and feet away from the area under the lifted vehicle. Always firmly set parking brake and block wheels before raising vehicle with jack.


Do not disengage parking brake while the vehicle is raised. Be certain that the jack is always vertical when in use, especially on hills. Always try to use the jack on level surface. Be sure that the jack arm is fully inserted in the jack tube. Always lower the vehicle onto sufficient capacity jackstands before working under the vehicle.

Move vehicle to a level area which is a safe distance from the roadway.


#### Warning!

Before working on the vehicle, e.g. when changing wheels, the roll bar should be raised with the switch, and the electronic key be removed from the steering lock, to prevent possible injury.

- Set parking brake and turn on hazard warning flasher.
- 2. Move selector lever to position "P" and turn off engine.
- 3. Prevent vehicle from rolling away by blocking wheels with wheel chocks (not supplied with vehicle) or sizable wood block or stone. When changing a wheel on a hill, place chocks on the downhill side blocking both wheels of the other axle. On a level road, place one chock in front of and one behind the wheel that is diagonally opposite to the wheel being changed.




4. Using the wrench, loosen but do not yet remove the wheel bolts.




5. Remove the protective cover from the jack support tube opening by inserting the screwdriver (supplied in the tool kit) in the opening and prying it out.


The tube openings are located directly behind the front wheel housings and in front of the rear wheel housings.



- 6. Insert jack arm fully into the tube hole up to the stop. Place jack on firm ground. Position the jack so that it is always vertical (plumb-line) as seen from the side (see arrow), even if the vehicle is parked on an incline.
- 7. Jack up the vehicle until the wheel is clear of the ground. Never start engine while vehicle is raised.




- 8. Unscrew upper-most wheel bolt and install alignment bolt (1) supplied in the tool kit. Remove the remaining bolts. Keep bolt threads protected from dirt and sand.
- 9. Remove wheel. Grip wheel from the sides. Keep hands from beneath the wheels.



10. Clean contact surfaces of wheel and wheel hub. Install wheel on wheel hub. Insert wheel bolts and tighten them slightly.

To avoid paint damage, place wheel flat against hub and hold it there while installing first wheel bolt.

Unscrew the alignment bolt (1) to install the last wheel bolt.



- 11. Lower vehicle. Remove jack and insert jack tube cover.
- 12. Using the wrench, tighten the five bolts evenly, following the sequence illustrated, until all bolts are tight.Observe a tightening torque of 80 ft.lb. (110 Nm).
- 13. Ensure proper tire pressure.

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 lactical lillits	Cai caie	data	Hitex

and controls	Operation	Dilving	cluster display	•	ractical illitis	car care	data	muex
Tires, Whee	ls		:	270				
	Warning!				Warning!			
Always replace wheel bolts that are damaged or				The spare whe	el rim is for temp	orary use only. Use	e	

Instrument

rusted.

Never apply oil or grease to wheel bolts.

Operation

**Instruments** 

Damaged wheel hub threads should be repaired immediately.

Driving

Incorrect mounting bolts or improperly tightened mounting bolts can cause the wheel to come off. This could cause an accident. Be sure to use the correct mounting bolts.

The spare wheel rim is for temporary use only. Use for over a total of 12 000 miles (20 000 km) (aggregate of all uses) may cause wheel rim failure leading to an accident and possible injuries.

**Technical** 

#### Notes:

Before storing the jack, the jack arm must be lowered almost to the base of the jack.

For proper storage of vehicle jack see page 261.

#### Tire inflation pressure

A table (see fuel filler flap) lists the tire inflation pressures specified for Mercedes-Benz recommended tires as well as for the varying operating conditions.

#### Important!

Tire pressure changes by approx. 1.5 psi (0.1 bar) per 18°F (10°C) of air temperature change. Keep this in mind when checking tire pressure inside a garage – especially in the winter.

#### Example:

If garage temperature = approx. +68°F (+20°C) and ambient temperature = approx. +32°F (0°C) then the adjusted air pressure = specified air pressure +3 psi (+0.2 bar).

Tire pressures listed for light loads are minimum values offering high driving comfort. Increased inflation pressures for heavy loads produce favorable handling characteristics with lighter loads and are perfectly permissible. The ride of the vehicle, however, will become somewhat harder.

Tire temperature and pressure increase with the vehicle speed. Tire pressure should therefore only be checked and corrected on cold tires. Correct tire pressure in warm tires only if pressure has dropped below the pressure listed in the table and the respective operating conditions are taken into consideration.

An underinflated tire due to a slow leak (e.g. due to a nail in the tire) may cause damage such as tread separation, bulging etc.. Regular tire pressure checks (including the spare tire) at intervals of no more than 14 days are therefore essential.

Instruments	Operation	n Dnizzin a	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Driving	cluster display	r ractical illitis	Cai care	data	muex

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Battery			27	72			

Battery

If a tire constantly loses air, it should be inspected for damage.

The spare tire should be checked periodically for condition and inflation. Spare tire will age and become worn over time even if never used, and thus should be inspected and replaced when necessary.

### Warning!

Do not overinflate tires. Overinflating tires can result in sudden deflation (blowout) because they are more likely to become punctured or damaged by road debris, potholes etc.. Follow recommended inflation pressures.

Do not overload the tires by exceeding the specified vehicle capacity weight (as indicated by the label on the driver's door latch post). Overloading the tires can overheat them, possibly causing a blowout.

#### - / -

#### **Battery**

#### Warning!

Failure to follow these instructions can result in severe injury or death.

Never lean over batteries while connecting, you might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking etc..

#### Important!

Battery replacement information:

The maintenance-free battery is located in the trunk under the trunk floor.

The service life of the battery is dependent on its condition of charge. The battery should always be kept sufficiently charged, in order to last an optimum length of time.

Therefore, we strongly recommend that you have the battery charge checked frequently, and corrected if necessary, especially if you use the vehicle less than approximately 200 miles (300 km) per month, mostly for short distance trips, or if it is not used for long periods of time.

Only charge a battery with a battery charger after the battery has been disconnected from the vehicle's electrical circuit.

Always disconnect the battery negative lead first and connect last.

When removing and connecting the battery, always make sure that all electrical consumers are off and the electronic key is in steering lock position 0. The battery and its filler caps must always be securely installed when the vehicle is in operation. During removal and installation always protect the disconnected battery positive (+) terminal with the cover attached to the battery.

While the engine is running the battery terminal clamps must not be loosened or detached, otherwise the generator and other electronic components would be damaged.

#### Notes:

After reconnecting the battery also set the clock (see page 106) resynchronize the front seats (see page 49), front seat head restraints (see page 49), the express feature of the power windows (see page 147), and the electronic stability program (ESP) (see page 221).

If the soft top is in a half open position, it also has to be synchronized. To do so, raise and lock soft top manually (see page 291).

#### **Battery recycling**

Batteries contain material that can harm the environment with improper disposal.

Large 12 Volt storage batteries contain lead.

Recycling of batteries is the preferred method of disposal.

Many states require sellers of batteries to accept old batteries for recycling.

Battery 273

Inst	ruments
and	controls

### **Practical hints**

### Car care

#### Technical data

Index

Instruments and controls

Operation Driving Instrument cluster display

Practical hints Car care Technical data Index

Jump starting

### Jump starting

### Warning!

Failure to follow these directions will cause damage to the electronic components, and can lead to a battery explosion and severe injury or death.

Never lean over batteries while connecting or jump starting, you might get injured.

Battery fluid contains sulfuric acid. Do not allow this fluid to come in contact with eyes, skin or clothing. In case it does, immediately flush affected area with water, and seek medical help if necessary.

A battery will also produce hydrogen gas, which is flammable and very explosive. Keep flames or sparks away from battery, avoid improper connection of jumper cables, smoking etc..

Read all instructions before proceeding.

### 274

#### Important!

A discharged battery can freeze at approx. +14°F (-10°C). In that case, it must be thawed out before jumper cables are used. Attempting to jump start a frozen battery can result in it exploding, causing personal injury.

Jumper cable specifications:

- Minimum cable cross-section of 25 mm<sup>2</sup> or approx.
   2 AWG
- Maximum length of 11.5 ft. (3.5 m).

If the battery is discharged, the engine should be started with jumper cables and the (12 V) battery of another vehicle.

Only use 12 V battery to jump start your vehicle. Jump starting with more powerful battery could damage the vehicle's electrical systems, which will not be covered by the Mercedes-Benz Limited Warranty.

The battery is located in the trunk under the trunk floor.

#### Proceed as follows:

- 1. Position the vehicle with the charged battery so that the jumper cables will reach, but never let the vehicles touch. Make sure the jumper cables do not have loose or missing insulation.
- 2. On both vehicles:
  - Turn off engine and all lights and accessories, except hazard warning flashers or work lights.
  - Apply parking brake and shift selector lever to position "P".

#### Important!

- 3. Clamp one end of the first jumper cable to the positive (+) under hood terminal of the discharged battery and the other end to the positive (+) terminal of the charged battery. Make sure the cable clamps do not touch any other metal parts.
- 4. Clamp one end of the second jumper cable to the grounded negative (-) terminal of the charged battery and the final connection to the negative (-) terminal (2) of the discharged battery.

#### Important!

- 5. Start engine of the vehicle with the charged battery and run at high idle. Make sure the cables are not on or near pulleys, fans, or other parts that move when the engine is started. Allow the discharged battery to charge for a few minutes. Start engine of the disabled vehicle in the usual manner.
- 6. After the engine has started, remove jumper cables by exactly reversing the above installation sequence, starting with the last connection made first. When removing each clamp, make sure that it does not touch any other metal while the other end is still attached.

#### Notes:

If engine does not run after several unsuccessful starting attempts, have it checked at the nearest authorized Mercedes-Benz Center.

Excessive unburned fuel may damage the catalytic converter.

Jump starting 275

Inst	rument
and	control

### Car care

#### Technical data

and controls	Operation	Dilving	cluster display	i racticai illiits	Car care	data	muex
Towing			27	76			
_							

Instrument

### Towing the vehicle

Operation

**Instruments** 

Prior to towing the vehicle with all wheels on the ground, make certain that the electronic key is in steering lock position 2.

Driving

If the electronic key is left in the steering lock position 0 for an extended period of time, it can no longer be turned in the lock. In this case, the steering is locked. To unlock, remove electronic key from steering lock and reinsert.

#### Important!

Drogtical hinte


When towing the vehicle, please, note the following:

**Technical** 

Indox

With the automatic central locking activated and the electronic key in steering lock position 2, the vehicle doors lock if the left front wheel as well as the right rear wheel are turning at vehicle speeds of approx. 9 mph (15 km/h) or more.

To prevent the vehicle door locks from locking, deactivate the automatic central locking, see page 37.



The rear towing eye is located at the right, below the bumper. The front towing eye is located on the passenger side behind a cover in the bumper panel.


#### CLK 320:

Cover removal:

Insert finger in recess of cover and pull cover out.

Cover installation:

Engage cover at bottom and press in top securely.



#### CLK 430:

Cover removal:

Hold left and right end of grille and pull out.

Cover installation:

Engage left and right end of grille and press in securely.

Towing 277

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 Tactical lillits	Car care	data	HIGGA

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Towing			27	78			

We recommend that the vehicle be transported using flat bed equipment. This method is preferable to other types of towing.

The vehicle may be towed with all wheels on the ground and the selector lever in position "N" for distances up to 30 miles (50 km) and at a speed not to exceed 30 mph (50 km/h). The electronic key must be in steering lock position 2.

To be certain to avoid a possibility of damage to the transmission, however, we recommend the drive shaft be disconnected at the rear axle drive flange for any towing beyond a short tow to a nearby garage.

Do not tow with sling-type equipment. Towing with sling-type equipment over bumpy roads will damage radiator and supports.

Use wheel lift, dolly, or flat bed equipment, with electronic key in steering lock turned to position 0.

#### Warning!

With the engine not running, there is no power assistance for the braking and steering systems. In this case, it is important to keep in mind that a considerably higher degree of effort is necessary to brake and steer the vehicle.

#### Note:

To signal turns while being towed with hazard warning flasher in use, turn electronic key in steering lock to position 2 and activate combination switch for left or right turn signal in usual manner – only the selected turn signal will operate.

Upon canceling the turn signal, the hazard warning flasher will operate again.

#### Caution!

If the vehicle is towed with the front axle raised, the engine must be shut off (electronic key in steering lock position 0 or 1). Otherwise, the ESP will immediately be engaged and will apply the rear wheel brakes. Switch off the tow-away alarm (see page 44) as well as the ESP (see page 222).

#### Transmission selector lever, manually unlocking



In the case of power failure the transmission selector lever can be manually unlocked, e.g. to tow the vehicle.

To do so, insert a pin (1), e.g. ball point pen, into the covered opening below the position "D" of the shift pattern. While pushing the pin down, move selector lever from position "P".

After removal of the pin from the opening, the cover will not close fully. Only after moving the selector lever to positions "D+" and "D-" does the cover return to its closed position.

Towing 279

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilying	cluster display	1 ractical illines	Car care	data	HIGGA

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Exterior lamps			28	30			

Exterior lamps

### Exterior lamps

### Headlamp adjustment

Correct headlamp adjustment is extremely important. Check and readjust headlamps at regular intervals and when a bulb has been replaced.

For adjusting headlamp aim see page 285.

#### Replacing bulbs

#### Warning!

Bulbs and bulb holders can be very hot. Allow the lamp to cool down before changing a bulb.

Halogen lamps contain pressurized gas. A bulb can explode if you:

- touch or move it when hot,
- drop the bulb,
- scratch the bulb.

Wear eye and hand protection.

#### Notes:

To prevent a possible electrical short circuit, switch off lamp prior to replacing a bulb.


When replacing bulbs, install only 12 volt bulbs with the specified watt rating.

When replacing halogen bulbs do not touch glass portion of bulb with bare hands. Use plain paper or a clean cloth.

#### Warning!


Because of high voltage in Xenon lamps, it is dangerous to replace the bulb or repair the lamp and its components. We recommend that you have such work done by a qualified technician.

#### Headlamp assembly (Halogen)



- 1 Headlamp vertical adjustment screw
- **2** Cover for low beam headlamp
- **3** Cover for high beam headlamp, parking and standing lamp

#### Headlamp assembly (Xenon)



- 4 Bulb socket for turn signal lamp
- **5** Electrical connector for low beam headlamp bulb
- 6 Electrical connector for high beam headlamp bulb
- 7 Bulb socket for parking and standing lamp

**Exterior lamps** 

281

Inst	ruments
and	control

#### Technical data


Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index		
Exterior lan	nps		28	32					
	Bulbs for low or hig H7 (55 W)	h beam		<b>Turn signal lamp</b> 1156 NA (26.9/5 W/32/4 cp bulb)					
(	Open hood.			Open hood.					
(	Rotate cover (2 or 3) of electrical connected and remove bulb.			Twist bulb socket (4) counterclockwise and pull out. Push bulb into socket, turn counterclockwise and remove.					
:	Insert new bulb (seat socket), mount clamp electrical connector o	ing ring. Reinstall		Insert new bulb in socket, push in and twist clockwise. Reinstall bulb socket. Reinstall lamp assembly until properly seated.					
]	Reinstall cover (2 or 3	3).							
	Xenon (optional)			Parking and standing lamp H 6W (6 W bulb)					
]	Bulb for low beam			Open hood.					
	Warning!			Rotate cover (3) counterclockwise and remove.					
	December of high well	taga in Vanan lam	na it ia	Twist hulb socket (7) counterclockwise and null out					

Because of high voltage in Xenon lamps, it is dangerous to replace the bulb or repair the lamp and its components. We recommend that you have such work done by a qualified technician. Twist bulb socket (7) counterclockwise and pull out. Push bulb into socket, turn counterclockwise and remove.

Insert new bulb in socket, push in and twist clockwise. Reinstall bulb socket. Reinstall lamp assembly until properly seated.

Reinstall cover (3).

#### Taillamp assemblies



Open trunk lid.

Swing cover aside (bulbs 1, 2 and 3).

- 1 Turn signal lamp (21 W/24 cp bulb)
- 2 Stop, tail, parking, and side marker lamp (21/4 W bulb)
- 3 Tail and parking lamp (5 W/4 cp bulb)



- 4 Driver's side: Rear fog lamp (21 W/32 cp bulb)
- 5 Backup lamp (21 W/32 cp bulb)

Twist bulb socket counterclockwise and pull out. Push bulb into socket, turn counterclockwise and remove.

Insert new bulb in socket, push in and twist clockwise. Reinstall bulb socket. Close cover (bulbs 1, 2 and 3).

**Exterior lamps** 

283


Inst	ruments
and	controls

### Car care

#### Technical data

### Exterior lamps

#### **Side marker lamp, front** (5 W/4 cp bulb)



#### 284

Carefully slide lamp towards front (arrow), and remove back and first.

Twist bulb socket counterclockwise and pull out. Push bulb socket, turn counterclockwise and remove.

Insert new bulb in socket, push in and twist clockwise. Reinstall bulb socket, push in and twist clockwise.

To reinstall lamp, set front end of lamp in bumper and let back end snap into place.

#### High mounted stop lamp, Additional turn signals on the exterior mirror

The high mounted stop lamp (3rd brake lamp), and the additional turn signals on the exterior mirrors are equipped with LEDs.

Have the system checked at an authorized Mercedes-Benz Center if a fault or defect occurs.

#### Adjusting headlamp aim

Correct headlamp adjustment is extremely important. To check and readjust a headlamp, follow steps 1 through 5.

#### Please note:

- Low beam adjustments simultaneously aim the high beam.
- Vehicle should have a normal trunk load.
- 1. Park vehicle on level surface approximately 25 ft. (7.6 m) from a vertical test screen or wall. The centerline of the vehicle must be at a 90° angle to the test screen.


285 Exterior lamps

## **Practical hints**

### Car care


**Technical** data

Exterior lamps 286



# 2. (Low beams on):


Using a carpenter's level, align and mark a vertical centerline (8) on the test screen using the vertex of the angle formed in each beam image. As a check, the distance between centerlines should be  $49^{-1}/_{4}$  inches (1250 mm). If the distance does not check, have the system verified at an authorized Mercedes-Benz Center.



#### 3. (Low beams off):

Measure the vertical height from the floor to reference point (10) on high beam lens. Subtract approx. 2 inches (53 mm) from measurement, and mark a horizontal centerline (9) on the test screen at the resulting height from the floor. It must be at a 90° angle to the vertical centerline.

# 4. Open hood.



# 5. Vertical headlamp aim (low beams on):

Turn adjusting screw (1) (counterclockwise to adjust headlamp downward, clockwise upward) until the headlamps illuminate the test screen as shown. The vertex of the angle formed in each beam image should align with the vertical and horizontal centerlines (8 and 9).

The left and right headlamps must be adjusted individually.

#### Note:

If it is not possible to obtain a proper headlamp adjustment, have the system checked at your authorized Mercedes-Benz Center.

Exterior lamps 287

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	Practical nints	Cai caie	data	Index

Electronic main key

288

# Changing batteries in the electronic main key



- 1 Transmit buttons
- 2 Lamp for battery check and function control

# **Checking batteries**

If one of the transmit buttons (1) is pressed, the battery check lamp (2) lights up briefly – indicating that the batteries are in order.

Change batteries if the battery check lamp (2) does not light up briefly.



# **Changing batteries**


Move locking tab (3) in direction of right arrow and remove mechanical key (4, left arrow).



Insert mechanical key (4) in side opening (5) to open latch. Press briefly (do not use mechanical key as lever) to release battery compartment.

Remove mechanical key from side opening.

Carefully remove battery compartment in direction of arrow (6).



Change batteries (7), inserting new ones under contact spring (8) with plus (+) side facing up.

Return battery compartment into housing until locked in place and slide mechanical key back into electronic main key.

# Car care

# Technical data

	•	_			
Electronic main key		290			
Important!		Synchronizing rem	ote control		
Ratteries contain ma	aterials that can harm the	The remote control n	nay have to be r	resynchronized if	

**Practical hints** 

**Instrument** 

cluster display

Batteries contain materials that can harm the environment if disposed of improperly. Recycling of batteries is the preferred method of disposal. For disposal, please follow manufacturer's recommendation on battery package.

Driving

Replacement Battery: Lithium, type CR 2025 or equivalent.

Operation

**Instruments** 

and controls

The remote control may have to be resynchronized, if the vehicle cannot be locked or unlocked.

Car care

**Technical** 

data

Index

To synchronize insert electronic key in steering lock.

The remote control should once again be operational.

# Raising soft top manually

In case of malfunction, the power soft top can also be raised manually. This procedure should be performed with great care by two persons.

We recommend to take off your watch or other jewelry to prevent personal injury.

A combination open-end/hex-socket wrench in the vehicle tool kit is required for this job.

- 1. Engage parking brake.
- 2. Lower windows and open doors.
- 3. Lower roll bar with roll bar switch.

Note:

If the roll bar cannot be lowered, carefully guide the soft top across the roll bar. Lift the rear window over the roll bar.

4. For safety reasons, remove electronic key from steering lock.

### Important!

Ensure that the trunk lid is closed while raising the soft top manually. Otherwise there is the possibility of contact between the trunk lid and the soft top compartment cover.

# Warning!

Do not place your hands near the roll bar, soft top frame, upper windshield area or soft top storage compartment or between the soft top rods while the soft top is being raised and locked.

Serious personal injury may occur.

# are Technical data

# **Emergency operation of soft top**



5. Unlock soft top storage compartment:


Open trunk lid with mechanical key and lift protection cover.

Using screwdriver (supplied in vehicle tool kit), turn screw two turns counterclockwise to the stop.


Close trunk lid.

# Important!

Do not place mechanical key inside trunk, since trunk is locked again when closing the lid.




6. Place open-end wrench (1) (supplied in vehicle tool kit) on bolt between backrest and soft top compartment cover. Turn wrench (1) in direction of arrow to its stop and remove.



7. Open soft top compartment cover (2) and place in upright position.

Place hands from below on upper section of soft top (3) and pull hard to move soft top (4) out of its storage compartment.




8. Move soft top toward windshield header (arrow).

# Warning!


Do not place your hands in areas marked X. Serious personal injury may occur.

**Emergency operation of soft top** 




- 9. Do not place soft top frame (5) onto windshield header.
- 10. Place rear window section of soft top (6) in its vertical position.
- 11. Close soft top compartment cover (2) by placing hands near edges (arrows). The soft top compartment cover must lock in the first notch of compartment cover catch.

294



12. Lock soft top storage compartment:

Place open-end wrench (1) on bolt between backrest and soft top compartment cover. Turn wrench (1) in direction of arrow to its stop and remove.



- 13. Lower rear window section of soft top (6).
- 14. Open trunk lid with mechanical key and carefully guide luggage cover into its storage compartment.



15. Insert hex-socket wrench (7) to lock the soft top bow.

Press soft top bow down onto soft top compartment cover.

Insert and turn wrench in direction of arrow (8) to lock soft top bow.

# **Emergency operation of soft top**




- 16. Using screwdriver (supplied in vehicle tool kit), turn screw clockwise to the stop.
- 17. Close trunk lid.

# Important!

Do not place mechanical key inside trunk, since trunk is locked again when closing the lid.



18. Press lock button (9) and fold down locking handle (10).



19. Turn locking handle 90° clockwise and pull soft top frame carefully down until it meets the windshield header attachment points.

Turn locking handle counterclockwise to the stop to lock the soft top.

Fold locking handle up until lock button engages.

#### Note:

Have the soft top operation checked at your authorized Mercedes-Benz Center as soon as possible.

**Emergency operation of soft top** 


# Car care

# Technical data

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Manual release for fuel filler flap

#### Antenna



The non-retractable antenna should be removed before entering an automatic car wash, to avoid damage to the antenna mast or vehicle paint finish.

Do not use tools (e.g. pliers) for the antenna mast removal.

To remove:

Unscrew antenna counterclockwise (1).

To install:

Carefully position antenna mast on threaded socket and turn clockwise (2) until hand tight.

# 298


# Manual release for fuel filler flap



The manual release knob is located behind the right side trunk panel.

In case the central locking system does not release the fuel filler flap, pull the manual release knob while simultaneously opening the fuel filler flap.

### Trunk lamp



If the trunk is to remain open for a long period of time, the trunk lamp can be switched off by pulling out the plunger in the switch (arrow). This prevents the vehicle battery from being discharged.

When the trunk lid is closed, the switch will reset and turn on the lamp next time the lid is opened.

### Replacing wiper blade insert

For safety reasons, remove electronic key from steering lock before replacing the wiper blade, otherwise the motor can suddenly turn on and cause injury.

#### Notes:


Do not open engine hood with wiper arm folded forward.

Do not allow the wiper arm to contact the windshield glass without a wiper blade inserted. The glass may be scratched or broken.

Make certain that the wiper blade is properly installed. An improperly installed wiper blade may cause windshield damage.

Trunk lamp 299

Replacing wiper blade insert




#### Removal:

Fold wiper arm forward. Press safety tab down (1), push wiper blade downward (2) and remove.

Place wiper blade on firm support. Press down both tabs and slide (direction of arrow) the wiper blade insert out of the retainer claws.

# **3**00



#### Installation:

Slide (direction of arrow) wiper blade insert into retainer claws until tabs are engaged.

Insert wiper blade between tabs (3) on the wiper arm, and slide into end of wiper arm. Press safety tab upward until it locks in place.

# Vehicle care

Cleaning and care	
of the vehicle	302
Power washer	303
Paintwork, painted body	
components	303
Engine cleaning	304
Tar stains	304
Vehicle washing	304
Ornamental moldings	
Headlamps, taillamps,	
turn signal lenses	305
Window cleaning	
Plastic and rubber parts	

Wiper blade	305
Light alloy wheels	305
Instrument cluster	306
Steering wheel and	
gear selector lever	306
Cup holder	306
Seat belts	306
Headliner	306
Upholstery	307
Hard plastic trim items	307
Plastic and rubber parts	307
Wind screen	307
Rubber weatherstrip	307
Soft top	308

Contents - Vehicle care

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

Cleaning and care of the vehicle

# Cleaning and care of the vehicle

# Warning!

Many cleaning products can be hazardous. Some are poisonous, others are flammable. Always follow the instructions on the particular container. Always open your vehicle's doors or windows when cleaning the inside.

Never use fluids or solvents that are not designed for cleaning your vehicle.

In operation, your vehicle is subjected to varying external influences which, if gone unchecked, can attack the paintwork as well as the underbody and cause lasting damage.

Such damage is caused not only by extreme and varying climatic conditions, but also by air polution, road salt, tar, gravel and stone chipping. Grease and oil, fuel, coolant, brake fluid, bird droppings, insects, tree resins etc. should be removed immediately to avoid paint damage. Frequent washing reduces and/or eliminates the aggressiveness and potency of the above adverse influences.

302

More frequent washings are necessary to deal with unfavorable conditions; for example, near the ocean, in industrial areas (smoke, exhaust emissions), or during winter operation.

You should check your vehicle from time to time for stone chipping or other damage. Any damage should be repaired as soon as possible to prevent the start of corrosion.

In doing so, do not neglect the underside of the vehicle. A prerequisite for a thorough check is a washing of the underbody followed by a thorough inspection. Damaged areas need to be reundercoated.

Your vehicle has been treated at the factory with a wax-base rustproofing in the body cavities which will last for the lifetime of the vehicle. Post-production treatment is neither necessary nor recommended by Mercedes-Benz because of the possibility of incompatibility between materials used in the production process and others applied later.

We have selected car-care products and compiled recommendations which are specially matched to our vehicles and which always reflect the latest technology. You can obtain Mercedes-Benz approved car-care products at your authorized Mercedes-Benz Center.

Scratches, corrosive deposits, corrosion or damage due to negligent or incorrect care cannot always be removed or repaired with the car-care products recommended here. In such cases it is best to seek aid at your authorized Mercedes-Benz Center.

The following topics deal with the cleaning and care of your vehicle and give important "how-to" information as well as references to Mercedes-Benz approved car-care products.

Additional information can be found in the booklet titled "Vehicle Care Guide".

#### Power washer

When using a power washer for cleaning the vehicle always observe manufacturer's operating instructions.

#### Caution!

Never use a round nozzle to power wash tires. The intense jet of water can result in damage to the tire.

Always replace a damaged tire.

Always keep the jet of water moving across the surface. Do not aim directly at soft top, electrical parts, electrical connectors, seals, or other rubber parts.

# Paintwork, painted body components

Mercedes-Benz approved Paint Care should be applied when water drops on the paint surface do not "bead up", normally in 3 to 5 months, depending on climate and washing detergent used.

Mercedes-Benz approved Paint Cleaner should be applied if paint surface shows signs of dirt embedding (i.e. loss of gloss).

Do not apply any of these products or wax if your vehicle is parked in the sun or if the hood is still hot.

Use the appropriate MB-Touch-Up Stick for quick and provisional repairs of minor paint damage (i.e. chips from stones, vehicle doors etc.).

# Technical data

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Cleaning and care of the vehicle		30	04				

# **Engine cleaning**

Prior to cleaning the engine compartment make sure to protect electrical components and connectors from the intrusion of water and cleaning agents.

Corrosion protection, such as MB Anticorrosion Wax should be applied to the engine compartment after every engine cleaning. Before applying, all control linkage bushings and joints should be lubricated. The poly-V-belt and all pulleys should be protected from any wax.

#### Tar stains

Quickly remove tar stains before they dry and become more difficult to remove. A tar remover is recommended.

# Vehicle washing

Do not use hot water or wash your vehicle in direct sunlight. Use only a mild car wash detergent, such as Mercedes-Benz approved Car Shampoo.

Thoroughly spray the vehicle with a diffused jet of water. Direct only a very weak spray towards the ventilation intake. Use plenty of water and rinse the sponge and chamois frequently.

Rinse with clear water and thoroughly wipe dry with a chamois. Do not allow cleaning agents to dry on the finish.

In the winter, thoroughly remove all traces of road salt as soon as possible.

When washing the underbody, do not forget to clean the inner sides of the wheels.

# **Ornamental moldings**

For regular cleaning and care of very dirty chromeplated parts, use a chrome cleaner.

# Headlamps, taillamps, turn signal lenses

Use a mild car wash detergent, such as Mercedes-Benz approved Car Shampoo, with plenty of water.

To prevent scratches, never apply strong force and use only a soft, non-scratchy cloth when cleaning the lenses. Do not attempt to wipe dirty lenses with a dry cloth or sponge.

# Window cleaning

Use a window cleaning solution on all glass surfaces. An automotive glass cleaner is recommended.

#### Note:

For safety reasons, switch off wiper and remove electronic key from steering lock before cleaning the windshield, otherwise the wiper motor can suddenly turn on and cause injury.

# Plastic and rubber parts

Do not use oil or wax on these parts.

#### Wiper blade

Clean the wiper blade rubber with a clean cloth and detergent solution.

#### Note:

For safety reasons, remove electronic key from steering lock before cleaning the wiper blade, otherwise the wiper motor can suddenly turn on and cause injury.

# Light alloy wheels

Mercedes-Benz approved Wheel Care should be used for regular cleaning of the light alloy wheels.

If possible, clean wheels once a week with Mercedes-Benz approved Wheel Care, using a soft bristle brush and a strong spray of water.

Follow instructions on container.

#### Note:

Use only acid-free cleaning materials. The acid could lead to corrosion.

Cleaning and care of the vehicle

and controls	Operation	Driving	cluster display	Practical hints	Car care	data	Index
Cleaning and care of the vehicle		30	06				

# Instrument cluster

Use a gentle dishwashing detergent or mild detergent for delicate fabrics as a washing solution. Wipe with a cloth moistened in lukewarm solution. Do not use scouring agents.

# Steering wheel and gear selector lever

Wipe with a damp cloth and dry thoroughly or clean with Mercedes-Benz approved Leather Care.

# Cup holder

Use a gentle dishwashing detergent or mild detergent for delicate fabrics as a washing solution. Wipe with a cloth moistened in lukewarm solution. Do not use scouring agents.

# Seat belts

The webbing must not be treated with chemical cleaning agents. Use only clear, lukewarm water and soap. Do not dry the webbing at temperatures above 176°F (80°C) or in direct sunlight.

# Warning!

Do not bleach or dye seat belts as this may severely weaken them. In a crash they may not be able to provide adequate protection.

#### Headliner

Clean with soft bristle brush, or use a dry-shampoo cleaner in case of excessive dirt.

# Upholstery

Using aftermarket seat covers or wearing clothing that have the tendency to give off coloring (e.g. when wet etc.) may cause the upholstery to become permanently discolored. By lining the seats with a proper intermediate cover, contact-discoloration will be prevented.

Leather Upholstery

Wipe leather upholstery with a damp cloth and dry thoroughly or clean with Mercedes-Benz approved Leather Care. Exercise particular care when cleaning perforated leather as its underside should not become wet.

MB Tex Upholstery

Pour Mercedes-Benz approved Interior Care onto soft lint-free cloth and apply with light pressure.

#### Hard plastic trim items

Pour Mercedes-Benz approved Interior Care onto soft lint-free cloth and apply with light pressure.

# Plastic and rubber parts

Do not use oil or wax on these parts.

#### Wind screen

Use only water or mild detergent to clean the wind screen.

# Rubber weatherstrip

The door and windshield header rubber weatherstrip material should be cared for at regular intervals with a silicon-based car care product.

Cleaning and care of the vehicle

- 2	n	7
J	v	,

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Cleaning and	care of the vehicl	e	3(	08			

Cleaning and care of the venic

# Soft top

Clean soft top with soft top raised and locked. Lower the soft top into the storage compartment only if the soft top is completely dry. If the soft top is kept in the storage compartment for a lengthy period, raise it and air out with the windows open about every 4 months.

Dry cleaning:

Brush top (always from front to rear) with a soft-bristled brush.

Wet cleaning:

Brush the dry top. Wash with a mild detergent and an ample supply of lukewarm water by wiping with a soft-bristled brush or sponge from front to rear. Then rinse thoroughly with clear water.

If only parts of the top have been washed, wet the entire top and allow it to air-dry before lowering it into the storage compartment.

Do not use sharp-edged instruments for the removal of ice and snow.

#### N

Notes:

When you run the vehicle through an automatic car wash, never use hot-wax for conservation.

Depending on the operation mode of the car wash, there is the possibility of water drops entering the vehicle's interior.

Never use a power washer to clean the soft top, as you may damage the soft top material.

Remove bird droppings immediately. The organic acid damages the material and causes the soft top to leak.

In general, regular spraying or cleansing with clear water is sufficient to keep the top clean.

Wash the top only when heavily soiled.

Light colored soft tops should be cleaned frequently to prevent spots and dirt from setting in, which could stain and discolor the soft top material permanently.

#### Caution!

Never use any gasoline, thinner, tar and stain removers, glass cleaner, or similar organic solvents to clean the soft top or wind screen. They will cause damage which is not covered by the Mercedes-Benz Limited Warranty.

#### Technical data Engine oil additives ......319 Air conditioner Spare parts service ...... 310 refrigerant ......319 Warranty coverage ......310 Brake fluid ......319 Identification labels ...... 311 Premium unleaded Layout of poly-V-belt drive ...... 312 gasoline ...... 320 Technical data ......313 Fuel requirements ......320 Fuels, coolants, lubricants etc. -Gasoline additives .......321 capacities .......317

Contents - Technical data

**Practical hints** 

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Technical data

# Spare parts service

All authorized Mercedes-Benz Centers maintain a stock of original spare parts required for maintenance and repair work. In addition, strategically located parts distribution centers provide quick and reliable parts service.

More than 300 000 different spare parts, for Mercedes-Benz models, are available.

Mercedes-Benz original spare parts are subjected to stringent quality inspections. Each part has been specifically developed, manufactured or selected for and adapted to Mercedes-Benz vehicles.

Therefore, Mercedes-Benz original spare parts should be installed.

# Important!

The use of non-genuine parts and accessories not authorized by Mercedes-Benz could damage the vehicle which damage is not covered by the Mercedes-Benz Limited Warranty or compromise its durability or safety.

# 310

# Warranty coverage

Your vehicle is covered under the terms of the "warranties" printed in the Service and Warranty Information booklet and your authorized Mercedes-Benz Center will exchange or repair any defective parts originally installed on the vehicle in accordance with the terms of the following warranties:


- 1. New vehicle limited warranty
- 2. Emission system warranty
- 3. Emission performance warranty
- 4. California, Massachusetts, and Vermont emission control systems warranty

Replacement parts and accessories are covered by the Mercedes-Benz Spare Parts and Accessories warranties, copies of which are available at any Mercedes-Benz Center.

# Loss of Service and Warranty Information Booklet

Should you lose your Service and Warranty Information booklet, have your authorized Mercedes-Benz Center arrange for a replacement. It will be mailed to you.

#### **Identification labels**



1 Certification label



**2** Vehicle Identification Number (VIN)

When ordering spare parts, please specify vehicle identification and engine numbers.

Technical data 311

Instruments and controls Operation Driving Instrument cluster display Practical hints Car care Index

312


Technical data



#### CLK 320 shown

- **3** VIN, visible (lower edge of windshield)
- 4 Engine number
- **5** Body number and paintwork number
- 6 Emission control label
- 7 Information label, California version Vacuum line routing for emission control system

# Layout of poly-V-belt drive



- 1 Automatic belt tensioner
- 2 Crankshaft
- 3 Air conditioner compressor
- 4 Coolant pump
- 5 Generator (alternator)
- 6 Idler pulley
- **7** Power steering pump

#### Technical data

Model	CLK 320 (208 465) <sup>1</sup>	CLK <b>430</b> (208 470) <sup>1</sup>
Engine	112	113
Mode of operation	4-stroke engine, gasoline injection	4-stroke engine, gasoline injection
No. of cylinders	6	8
Bore	3.54 in (89.90 mm)	3.54 in (89.90 mm)
Stroke	3.31 in (84.00 mm)	3.31 in (84.00 mm)
Total piston displacement	195.2 cu.in. (3199 cm³)	260.3 cu.in. (4265 cm <sup>3</sup> )
Compression ratio	10:1	10:1
Output acc. to SAE J 1349	215 hp/5700 rpm (160 kW/5700 rpm)	275 hp/5750 rpm (205 kW/5750 rpm)
Maximum torque acc. to SAE J 1349	232 ft.lb/3000 rpm (315 Nm/3000 rpm)	295 ft.lb/3200 rpm (400 Nm/3200 rpm)
Maximum engine speed	6000 rpm	6000 rpm
Firing order	1-4-3-6-2-5	1-5-4-2-6-3-7-8
Poly-V-belt	2390 mm	2390 mm

<sup>1</sup> The quoted data apply only to the standard vehicle. See an authorized Mercedes-Benz Center for the corresponding data of all special bodies and special equipment.

Technical data 313

Instruments	Operation	Driving	Instrument
and controls			cluster display

**Practical hints** 

and controls	Operation	Driving	cluster display	Practical hints	Car care	data
Technical data	a		<b>3</b> 1	14		
Riı	ms - Tires					
Mo	odel	CLK 320		Model	CLK 4	30
	Rims (light alloy) Wheel offset All season tires: Radial-ply tires 205/55 R 16 Winter tires: Radial-ply tires 205/55 R 16  Spare wheel		mm)	Rims front axle (AMG light alloy)		x 17 H 2
			5 91 H	Wheel offset: Rims rear axle		n (37 mm)
			6 91 H M+S	(AMG light alloy) Wheel offset:		x 17 H 2 n (30 mm)
Spa				Radial-ply tires: summer tires, fro summer tires, rea	nt axle 225/4 ar axle 245/4	5 R 17 91 W <sup>1</sup> 0 R 17 91 W <sup>2, 3</sup>
	m (light alloy) neel offset:	7 J x 16 H 2 1.46 in (37 r	mm)	Spare wheel		
	All season tire: Radial-ply tire		205/55 R 16 91 H			x 17 H 2 n (37 mm)
				Summer tire: Radial-ply tire	225/4	5 R 17 91 W¹
				1 Also permissible 2	25/45 ZR 17	
				2 Also permissible 2	45/40 ZR 17 <sup>3</sup>	
				3 Must not be used v	vith snow chains.	

Instrument

**Practical hints** 

Car care

Driving

Instruments

Operation

Technical

Index

# **Electrical system**

Model	CLK 320	CLK 430
Generator (alternator)	14 V/115 A	14 V/150 A
Starter motor	12V/1.7 kW	12V/1.7 kW
Battery	12V/100 Ah	12V/100 Ah
Spark plugs	Bosch F 8 DPER Beru 14 FGH 8 DPUR X 2 NGK PFR 5 R-11	Bosch F 8 DPER Beru 14 FGH 8 DPUR X 2 NGK PFR 5 R-11
Electrode gap	0.039 in (1.0 mm)	0.039 in (1.0 mm)
Tightening torque	15 - 22 ft.lb (20 - 30 Nm)	15 - 22 ft.lb (20 - 30 Nm)

# Weights (see certification tag)

Trunk load max. 220 lb (100 kg)

Technical data 315

**Driving** 

Operation

and controls	Operation	Driving	cluster display	Practical nints	Car care	data	
Technical d	ata		3	16			
]	Main dimensions						
]	Model	CLK :	320	CLK 430			
(	Overall vehicle length	180.2 in (4	4577 mm) 179.8	3 in (4567 mm)			
(	Overall vehicle width	67.8 in (	1722 mm) 67.	8 in (1722 mm)			
(	Overall height	54.3 in (	1380 mm) 54.	3 in (1380 mm)			
,	Wheel base	105.9 in (2	2690 mm) 105.9	9 in (2690 mm)			

59.3 in (1505 mm)

58.0 in (1474 mm)

**Practical hints** 

59.3 in (1505 mm)

58.6 in (1488 mm)

Car care

Instrument

**Instruments** 

Operation

Track, front

Track, rear

Driving

Technical

Index

# Fuels, coolants, lubricants etc. - capacities

Vehicle components and their respective lubricants must match. Therefore use only brands tested and recommended by us. Please refer to the Factory Approved Service Products pamphlet, or inquire at your Mercedes-Benz Center.

Fuels, coolants, lubricants etc.	Model	Capacity
Engine with oil filter (recommended engine oils)		8.5 US qt (8.0 l)
Automatic transmission (automatic transmission fluid)	CLK 320 CLK 430	8.5 US qt (8.0 l) 9.6 US qt (9.1 l)
Rear axle (Hypoid gear oil SAE 90, 85 W 90)		1.4 US qt (1.3 l)
Power steering (MB Power steering fluid)		approx. 1.1 US qt (1.0 l)
Front wheel hubs (high temperature roller bearing grease)		approx. 2.1 oz (60 g) each
Brake system (MB Brake fluid (DOT 4))		approx. 0.5 US qt (0.5 l)
Cooling system (MB Anticorrosion/antifreeze)	CLK 320 CLK 430	approx. 9.5 US qt (9.0 l) approx. 11.7 US qt (11.1 l)

Fuels, coolants, lubricants etc. - capacities

31	7

Instruments	Operation	Driving	Instrument	Practical hints	Car care	Technical	Index
and controls	Operation	Dilving	cluster display	1 factical lillits	Car care	data	Hucx

Fuels,	coolants, lubricants etc capacities	318	
	Fuels, coolants, lubricants etc.	Model	Capacity
	Windshield washer system (MB Windshield washer concentrate "S" ¹)		approx. 7.4 US qt (7.0 l)
	Fuel tank including a reserve of (Premium unleaded gasoline: Posted Octane 91 (Avg. of 96 RON/86 MON))		approx. 16.4 US gal (62.0 l) approx. 2.1 US gal (8.0 l)
	Air conditioner system (R-134a refrigerant and special PAC lubricant <i>(Never R-12)</i> )		

**Practical hints** 

Car care

Instrument

cluster display

Driving

Instruments

and controls

Operation

Technical

data

Index

<sup>1</sup> Use MB Windshield Washer Concentrate "S" and water for temperatures above freezing or MB Windshield Washer Concentrate "S" and commercially available premixed windshield washer solvent/antifreeze for temperatures below freezing. Follow suggested mixing ratios, see page 259.

### **Engine oils**

Engine oils are specifically tested for their suitability in our engines. Therefore, use only engine oils recommended by Mercedes-Benz. Information on recommended brands is available at your authorized Mercedes-Benz Center.

Please follow Service Booklet recommendations for scheduled oil changes. Failure to do so could result in engine damage not covered by the Mercedes-Benz Limited Warranty.

# **Engine oil additives**

Do not blend oil additives with engine oil. They may be harmful to the engine operation.

Damage or malfunctions resulting from blending oil additives are not covered by the Mercedes-Benz Limited Warranty.

### Air conditioner refrigerant

R-134a (HFC) refrigerant and special PAG lubricating oil is used in the air conditioner system.

Never use R-12 (CFC) or mineral-based lubricating oil, otherwise damage to the system will occur.

#### Brake fluid

During vehicle operation, the boiling point of the brake fluid is continuously reduced through the absorption of moisture from the atmosphere. Under extremely hard operating conditions, this moisture content can lead to the formation of bubbles in the system thus reducing the system's efficiency.

The brake fluid must therefore be replaced every two years, preferably in the spring.

It is recommended to use only brake fluid approved by Mercedes-Benz. Your authorized Mercedes-Benz Center will provide you with additional information.

Fuels, coolants, lubricants etc.

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Fuels coolant	s lubricants atc		3,	20			

iants, fubricants et

# Premium unleaded gasoline

#### Caution!

To maintain the engine's durability and performance, premium unleaded gasoline must be used. If premium unleaded is not available and low octane fuel is used, follow these precautions:

- have the fuel tank filled only partially with unleaded regular and fill up with premium unleaded as soon as possible,
- avoid full throttle driving and abrupt acceleration,
- do not exceed an engine speed of 3000 rpm, if the vehicle is loaded with a light load such as two persons and no luggage,
- do not exceed 2/3 of maximum accelerator pedal position, if the vehicle is fully loaded or operating in mountainous terrain.

# **Fuel requirements**

Use only Premium unleaded meeting ASTM standard D 439:

The octane number (posted at the pump) must be 91 min. It is an average of both the Research (R) octane number and the Motor (M) octane number: [(R+M)/2]. This is also known as ANTI-KNOCK INDEX.

Unleaded gasoline containing oxygenates such as Ethanol, IPA, IBA and TBA can be used provided the ratio of any one of these oxygenates to gasoline does not exceed 10%, MTBE not to exceed 15%.

The ratio of Methanol to gasoline must not exceed 3% plus additional cosolvents.

Using mixtures of Ethanol and Methanol is not allowed. Gasohol, which contains 10% Ethanol and 90% unleaded gasoline, can be used.

These blends must also meet all other fuel requirements such as resistance to spark knock, boiling range, vapor pressure etc..

#### Gasoline additives

A major concern among engine manufacturers is carbon build up caused by gasoline. Mercedes-Benz recommends the use of only quality gasoline containing additives that prevent the build up of carbon deposits.

After an extended period of using fuels without such additives, carbon deposits can build up especially on the intake valves and in the combustion area, leading to engine performance problems such as:

- warm-up hesitation,
- unstable idle,
- · knocking/pinging,
- misfire,
- power loss.

Do not blend other specific fuel additives with fuel. They only result in unnecessary cost, and may be harmful to the engine operation.

Damage or malfunctions resulting from poor fuel quality or from blending specific fuel additives are not covered by the Mercedes-Benz Limited Warranty.

#### **Coolants**

The engine coolant is a mixture of water and anticorrosion/antifreeze, which provides:

- corrosion protection,
- · freeze protection,
- boiling protection (by increasing the boiling point).

The cooling system was filled at the factory with a coolant providing freeze protection to approximately -22°F (-30°C) and corrosion protection.

If the antifreeze mixture is effective to -22°F (-30°C), the boiling point of the coolant in the pressurized cooling system is reached at approximately 266°F (130°C).

The coolant solution must be used year round to provide the necessary corrosion protection and increase in the boil-over protection. You should have it replaced every 3 years.

To provide the important corrosion protection, the solution must be at least 45% anticorrosion/antifreeze (equals a freeze protection to approx. - 22°F [-30°C]). If you use a solution that is more than 55% anticorrosion/antifreeze (freeze protection to approx. - 49°F [-45°C]),

Fuels, coolants, lubricants etc.

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Fuels, coolar	nts, lubricants etc.		32	22			
h	ne engine temperatu eat transfer capabili	ty of the solution. T	Therefore, do not	the hot southern	of the winter season regions), you sho		1

use more than this amount of anticorrosion/antifreeze.

If the coolant level is low, water and MB anticorrosion/

If the coolant level is low, water and MB anticorrosion/ antifreeze should be used to bring it up to the proper level (have cooling system checked for signs of leakage).

The water in the cooling system must meet minimum requirements, which are usually satisfied by normal drinking water. If your are not sure about the water quality, consult your authorized Mercedes-Benz Center.

# Anticorrosion/antifreeze

Your vehicle contains a number of aluminum parts. The use of aluminum components in motor vehicle engines necessitates that anticorrosion/antifreeze coolant used in such engines be specifically formulated to protect the aluminum parts. (Failure to use such anticorrosion/antifreeze coolant will result in a significantly shortened service life.)

Therefore the following product is strongly recommended for use in your vehicle: Mercedes-Benz Anticorrosion/antifreeze agent.

Before the start of the winter season (or once a year in the hot southern regions), you should have the anticorrosion/antifreeze concentration checked. The coolant is also regularly checked each time you bring your vehicle to your authorized Mercedes-Benz Center for service.

Anticorrosion/antifreeze quantity

Model	Approx. freeze protection				
	-35°F (-37°C)	-49°F ( -45°C)			
CLK 320	4.8 US qt (4.5 l)	5.3 US qt (5.0 l)			
CLK 430	5.9 US qt (5.6 l)	6.5 US qt (6.1 l)			

### **Consumer information**

This has been prepared as required of all manufactures of passenger cars under Title 49, Code of U.S. Federal Regulations, Part 575 pursuant to the "National Traffic and Motor Vehicle Safety Act of 1966".

# Uniform tire quality grading

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width. For example:

Tread wear 200 Traction AA Temperature A

All passenger vehicle tires must conform to federal safety requirements in addition to these grades.

#### Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half  $(1^{1}/_{2})$  times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and

may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### Traction

The traction grades, from highest to lowest are AA, A, B, and C. Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

# Warning!

The traction grade assigned to this tire is based on straightahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

**Consumer information** 

Operation

Instrument cluster display

**Practical hints** 

Car care

**Technical** Index

data

Consumer information

324

# **Temperature**

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger vehicle tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Driving

# Warning!

The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause excessive heat build up and possible tire failure.

Index	Armrest, rear bench	156
	Ashtray	
	Center console, front	154
$\mathbf{A}$	Audio system	127
ADC (A 21 1 1 1 4 )	Anti-theft system	129
ABS (Antilock brake system)	Button and soft key operation	130
Malfunction indicator lamp	Cassette mode	135
ABS-SYSTEM - malfunction	CD changer	140
and warning messages	CD mode	139
Adjusting headlamp aim	Operating and display elements	128
Adjusting telescoping steering column	Operating safety	127
Air conditioner refrigerant	Operation	131
Air distribution	Operation – audio and telephone	127
Air volume	Radio mode	133
Airbag deactivation system	Telephone operation	143
Airbag OFF indicator lamp233	Audio systems	93
Airbags	Cassette player	95
Alarm system	CD player	94
Antenna	Radio	93
Removal	Automatic central locking	37
Anticorrosion/antifreeze212, 258, 317, 322	Automatic climate control	120
Antiglare night position77	Air distribution	124
Antilock brake system (ABS)	Air recirculation	125
Malfunction indicator lamp231	Air volume	124
Antitheft alarm system42	Basic setting	122
Aquaplaning209	Defogging windows	123

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Central locking system28	COOLANT TEMP. (coolant temperature) -
Automatic central locking37	malfunction and warning messages241
Choosing global or selective mode 31	Coolant temperature gauge86
Electronic main key25	Coolants321
Electronic reserve key26	Anticorrosion/antifreeze quantity321
Locking and unlocking30	Cruise control214
Mechanical keys33	Cup holder
Remote control28	Center console, front153
Changing wheels266	
CHECK ENGINE malfunction indicator lamp228	n.
Check regularly and before a long trip226	D
Checking engine oil level	Daytime running lamps
Via engine oil level indicator112	Deep water
Via oil dipstick256	Driving instructions212
Child restraint 58, 63, 64, 74	DISPLAY DEFECTIVE (engine control unit) -
Cleaning and care of the vehicle302	malfunction and warning messages
Clock, setting106	DISPLAY DEFECTIVE (several systems) -
COMAND, radio and telephone178	malfunction and warning messages235
Combination switch117	Display illumination85
Consumer information323	Doors34
Control and operation of radio transmitters 178	Drinking and driving205
COOLANT (coolant level) -	Drive sensibly - save fuel
malfunction and warning messages240	Driving instructions
Coolant level	Driving off
Adding coolant258	
Checking257	

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
--------------------------	-----------	---------	----------------------------	-----------------	----------	-------------------	-------

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Inde
Index			32	28			

E	
ELEC. STABIL. PROG malfunction	
and warning messages	245
Electronic main key	25
Changing batteries	288
Synchronizing remote control	290
Electronic stability program (ESP)	
Control switch	222
Malfunction and warning messages	245
Malfunction indicator lamp	231
Synchronizing	221
Warning lamp	231
Emergency call	
See Tele Aid	182
Emergency tensioning retractor (ETR)	65
Emergency trunk lid release button	41
Emergency unlocking in case of accident	37
Emission control	181
Emission control label	312
Engine compartment	254
ENGINE FAN - malfunction	
and warning messages	239
Engine malfunction	
CHECK ENGINE malfunction indicator lamp	228
Engine oil additives	319

Engine oil consumption	113
Engine oil level	
Checking 112	, 256
Warning	
ENGINE OIL LEVEL - malfunction	
and warning messages	. 244
Engine oil level indicator	
ENGINE OIL LEVEL NOT WHEN ENGINE ON	
(measuring) - multifunction indicator	113
Engine oils	319
Capacities	317
ESP (Electronic stability program)210, 212, 220	, 278
Control switch	. 222
Malfunction and warning messages	. 245
Malfunction indicator lamp	23
Synchronizing	22
Warning lamp	23
Exterior lamp malfunction	
and warning message	. 242
Exterior lamp switch	114
Exterior lamps	. 280
Adjusting headlamp aim	. 285
Fog lamps	114
Headlamps 114, 242, 243, 281, 285	, 305
Low and high beam117	, 282
Parking lamps114	, 282

Replacing bulbs	G
Side marker lamp, front	Garage door opener158
Standing lamps114, 282 Taillamp assemblies283	Gasoline
Turn signal lamp	Additives321
Turii signai ianip 117, 202	Fuel requirements
	Premium unleaded320
$\mathbf{F}$	General notes on the central locking system27
	Glove box
First aid kit250	
Flexible service system (FSS)109	
Fuel	Н
Gasoline additives321	
Premium unleaded gasoline180, 318, 320	Hazard warning flasher switch
Fuel cap placement warning230	Head restraints
Fuel filler flap	Front51
Manual release298	Rear52
Fuel requirements320	Removal51
Fuel reserve warning230	Headlamp cleaning system
Fuels, coolants, lubricants etc capacities 317	Headlights
Fuses, electrical252	Heated seats56
, <del></del>	Hood

Keys, vehicle ......24

# $\mathbf{M}$

Maintenance	179
Malfunction and indicator lamps	
in the instrument cluster	228
Malfunction and warning messages	234
ABS-SYSTEM	237
BATTERY/ALTERNATOR	236
BRAKE ASSIST	237
BRAKE FLUID	238
BRAKE LINING WEAR	238
COOLANT (coolant level)	240
COOLANT TEMP. (coolant temperature)	
DISPLAY DEFECTIVE (engine control unit) .	235
DISPLAY DEFECTIVE (several systems)	235
ELEC. STABIL. PROG.	245
ENGINE FAN	239
ENGINE OIL LEVEL	244
LIGHT SENSOR	243
LIGHTING SYSTEM	242
PARKING BRAKE	
REMOVE KEY	
STEER. WHEEL ADJUST	243
TELE AID	
WASHER FLUID	

Malfunction message memory	104
Manual operation of soft top	
Mechanical keys	
Memory	
Recalling	49. 79
Storing	
Mirror, exterior, adjusting	
Mirror, exterior, rear view	
Mirror, inside, rear view	
Multicontour seat	
Multifunction display	
Engine oil level indicator	
FSS (Flexible service system)	
Setting the audio volume	
Trip and main odometer	
Vehicle speed	92
Multifunction steering wheel	
9	
N	
Navigation system - Multifunction dis	snlav 101
-	115

Instruments	Operation
and controls	Operation

Instruments and controls	Operation	Driving	Instrument cluster display	Practical hints	Car care	Technical data	Index
Index			33	32			
0				R			
Օ <u>ր</u> Օւ	n-board diagnostic s perator's Manual utside temperature verhead control pan	indicator	8 86	Rain sensor Rear view mirro Exterior Inside	ors	17 	8 77
<b>P</b> Pa	nic button		33	Remote control Battery repla	cement		28
Pa Pa	rcel net in front parkingrking brake rking brakeRKING BRAKE - m and warning mess		207 4, 207, 229, 266	Replacing bulbs Replacing wiper	messages blade insert		30 19
Po	wer assistance wer seats, front Backrestwer windows		206 45 54	Reserve key Residual engine Roadside assista Roadside assista	heat utilization (R anceance	2 REST)12	26 25 10
	Express opening at Opening and closing			See Tele Aid Roll bar		18	

Roller blind

Operated with soft top switch ......148

Synchronizing ......147

Problems with your vehicle ......14

Switch .......52

Warning lamp ......233

# S

Safety guidelines for the seat belt, emergency	
tensioning retractor and airbag	72
Seat belts	58
Fastening	60
Seat belt nonusage warning system	59
Unfastening	61
Warning lamp	232
Seat belts and supplemental	
restraint system (SRS)	58
Service indicator	
See Flexible service system (FSS)	109
Setting the audio volume	108
Shelf below rear window	250
Side marker lamp	284
Snow chains	210
Soft top	162
Emergency operation	
Lowering	164
Raising	
SOS-call	
See Tele Aid	182

Spare parts service	310
Spare wheel	260, 264
Special settings (Automatic climate control)	123
SRS indicator lamp	230
SRS malfunction	67
Start lock-out	27
Starting and turning off the engine	194
STEER. WHEEL ADJUST malfunction	
and warning messages	
Steering column, adjustable	
Steering lock	192
Storage compartment	
Trunk floor	260
Storage compartments	
Center console	152
Glove box	151
Storage compartments, armrest	
and cup holder	151
Stowing things in the vehicle	250
Sun visors	150
Supplemental restraint system (SRS)	65
Synchronizing remote control	

Index

Instruments
and controls

# Operation Driving

# cluster display

Instrument

**Practical hints** 



T	
Tachometer	87
Technical data	313
Electrical system	315
Main dimensions	316
Rims and tires	314
Weights	315
Tele Aid	
Emergency calls	183
Information	
Initiating an emergency call manually .	
Roadside Assistance	186
TELE AID - malfunction	
and warning messages	
Telephone	
General notes	
Incoming call	
Redialing	
Telephone book	
Telephones and two-way radios	178
Telescoping steering column	
Adjusting	76
Indicator lamp	
Telescoping steering column - malfunction	
and warning messages	243

The first 1 000 miles	179
Tire inflation pressure	271
Tire speed rating	
Tire traction	
Tires	
Driving instructions	
Rims and tires	
Rotating wheels	
Tire inflation pressure	
Tire replacement	
Winter driving instructions	
Tow-away alarm	
Towing the vehicle	
Transmission	
Transmission selector lever,	
manually unlocking	279
Traveling abroad	213
Trip computer	
Trip odometer	87
Trunk	38
Opening	31
Release switch	
Separately locked	38
Trunk lamp	
•	

Car care

Technical

data

# 

## W

Warranty coverage	310
WASHER FLUID (headlamp cleaning system) -	
malfunction and warning messages	246
Nashing the vehicle	304
What you should know at the gas station	224
Wheels	262
Light alloy wheels	305
Rims and tires	
Wheels, changing	266
Where to find it	
Wind screen	
Windshield washer/headlamp cleaning system	
Refilling	259
Winter driving	
Winter driving instructions	
Viper blade	
Replacing insert	299

## Service and Literature

Your authorized Mercedes-Benz Center has trained technicians and original Mercedes-Benz parts to service your vehicle properly. For expert advice and quality service, see your authorized Mercedes-Benz Center.

If your are interested in obtaining service literature for your vehicle, please contact your authorized Mercedes-Benz Center. We consider this the best way for you to obtain accurate information for your vehicle.

For further information you can find us on the Mercedes-Benz web-site www.mbusa.com.

# Warning!

To help avoid personal injury, be extremely careful when performing any service work or repairs. Improper or incomplete service or the use of incorrect or inappropriate parts or materials may damage the vehicle or its equipment, which may in turn result in personal injury.

If you have any question about carrying out some service, turn to the advice of an authorized Mercedes-Benz Center.

We reserve the right to modify the technical details of the vehicle as given in the data and illustrations of this Operator's Manual. Reprinting, translation and copying, even of excerpts, is not permitted without our prior authorization in writing.

Title illustration no. P00.00-2729-26

Press time 10/31/00 MBUSA/TI Printed in the U.S.A.