

*Bobbin size  
10.7mm.*

## DO'S AND DON'TS

1. Always be aware of the up-and-down movement of the needle and do not turn your attention from the machine while it is running.
2. When changing the needle, the presser foot, the bobbin or any other parts, always disconnect the machine by pulling the plug out of the wall socket.
3. Do not place anything on the speed controller, otherwise the machine will start inadvertently, or the controller or motor may burn out.
4. The maximum permissible power for the sewing lamp bulb is 15 watts.
5. When using your sewing machine for the first time, place a piece of waste fabric under the presser foot and run the machine without thread for a few minutes. Wipe away any oil which may have appeared.