

TABLE OF CONTENTS

KNOWING YOUR SEWING MACHINE

Names of parts	4-5
How to connect the machine to the power supply	6
How to use the speed controller	6
Sewing lamp	6
Thread and needle chart	7
Changing the needle	8
To select a suitable needle	8
Raising or lowering the presser foot	9
Regulating the presser foot pressure (Patch-O-Matic)	9
Removing and attaching the presser foot ...	10
Removing or attaching the foot holder ...	11
Regulating the thread tension	12
Stitch length dial, reversing button and dropping the feed dog	13
The pattern selector	14
• Selecting stretch stitch	14
Removing the bobbin case and bobbin	15

Winding the bobbin	16
Threading the bobbin case	17
Threading the needle thread	18
Drawing up the bobbin thread	19

BASIC SEWING

Straight stitch and zigzag stitch	20
• Starting sewing	20
• Changing sewing directions	21
• Fastening seams	21
Sewing tubular-shaped articles	22

UTILITY STITCHING

Sewing with a twin needle	23
Triple stretch stitch	24
• Triple straight stretch stitch	24
• Triple zigzag stretch stitch	24
Tricot zigzag stitch	25