

REMOVING AND ATTACHING THE PRESSER FOOT

To Remove:

- ① Turn the balance wheel towards you until the needle is at its highest position. Raise the presser foot by lifting the presser foot lifter.
- ② By lifting the lever on the back of the foot holder, the presser foot will drop off.

Note: *Do not force the presser foot to remove it.

To Attach:

- ① Place the presser foot so that the pin on the foot lies just under the groove of the foot holder. Lower the foot holder.
- ② When the presser foot lifter is raised you'll find the presser foot is locked in place.

